
(Menu)目录


Reader Encrypt Step (English)	2
Tag Encrypt Step (English)	
读卡器加密操作(中文)	
标签加密操作(中文)	


Reader Encrypt Step (English)

1. connects the pc and reader use the serial port, and use the "RFIDDemo.exe";




Press"F8" 5 Time






3. Choose then "Enabled", and set password, then set Parameters [Set Para].



4. Now, the encrypt set succeed;

Tag Encrypt Step (English)

Use the encrypt reader, follow the reader encrypt step,1,2,3,




Now, put the tag on the reader, the reader is not beep;

Presses "Encrypt Tag", until the reader beep, then encrypt succeed;


Note: when the encrypt tag, you can move the tag to accelerate the process of encryption;

读卡器加密操作(中文)

1. 将读卡器通过串口连接电脑,使用 RFIDDemo.exe 联机;



2. 按5次"F8"






3. 选择使能,并输入密码,并设置读卡器参数



4. 至此为读卡器设置密码完成!

标签加密操作(中文)

使用加密的读卡器,使用演示软件按读卡器加密操作步骤执行 1,2,3,进入加密界面;



将卡片悬浮于读卡器上面,不要贴着读卡器,点击加密卡片,直到读卡器有声音,表示加密成功.