

BIM Quantifier Pro

Installation Guide

STEP 1: SYSTEM REQUIREMENTS

- ✓ Revit 2022 or later
- ✓ Windows 10/11
- ✓ 8 GB RAM minimum
- ✓ 50 MB disk space

STEP 2: CLOSE REVIT

⚠ IMPORTANT: Close Revit completely before installation!

1. Save your work in Revit
2. Close all Revit windows
3. Check Task Manager to ensure no Revit processes are running

STEP 3: RUN INSTALLER

1. Double-click "BIMQuantifierPro_Setup_v1.0.0.exe"
2. Click "Yes" if Windows asks for permission

3. Follow the installation wizard
 4. Click "Install"
 5. Wait for installation to complete
 6. Click "Finish"
-

STEP 4: OPEN REVIT

1. Open Revit
 2. Wait for Revit to load completely
 3. Look for "BIM Quantifier" tab in the ribbon
 4. You should see three buttons:
 - BIM Quantifier Pro (main button)
 - License
 - About
-

STEP 5: ACTIVATE LICENSE

1. Click "BIM Quantifier Pro" button
2. Activation dialog will appear
3. Copy your Hardware ID
4. Send Hardware ID to: your-email@gmail.com
5. Receive your license key
6. Enter license key in activation dialog
7. Click "Activate License"
8. Start using BIM Quantifier Pro!

TROUBLESHOOTING

Problem: "BIM Quantifier" tab not appearing

Solution:

- Restart Revit
- Check if files are in correct location
- Contact support

Problem: "Invalid license key" error

Solution:

- Verify Hardware ID matches
- Check license key format
- Contact support

SUPPORT

Email: mj.qahremani@gmail.com

LinkedIn: [linkedin.com/in/mohamad-qahremani-0a581b3b2](https://www.linkedin.com/in/mohamad-qahremani-0a581b3b2)

Thank you for choosing BIM Quantifier Pro!