Harbor pump guide

Fictional equipment. Not operating instructions for real products.

Nominal flow at water temperature 20 C

The table gives nominal flow, not the high-temperature limit.

Model	Flow (L/min)	Water (C)
H1	10	20
H2	12	20
H3	15	20

H2 exception: above 35 C, maximum flow is 8 L/min.

Service conditions

Code C3 requires checking the inlet filter before restarting.

Code C7 uses a timed restart procedure that continues on page 2.

C7 restart procedure

When the Harbor H2 pump reports code C7, stop the motor and

Harbor pump guide - continued

Fictional equipment. Not operating instructions for real products.

wait 8 minutes before restarting it. This delay applies only to code C7.

Maintenance

Replace the H2 inlet filter every 90 operating days.

The H1 filter interval is 60 operating days.