PRINTER HUB 1.20.0

Setup guide

App, relay, home bridge (NAS · Raspberry Pi · PC) and OrcaSlicer

This takes about 15 minutes. Only part 1 is required. Parts 2–4 add access from away, alerts and OrcaSlicer.

PART	WHAT YOU GET	YOU NEED
1. The app	Control and camera at home	iPhone/iPad or a Mac
2. Relay	The cloud mailbox used for access from away	A free Cloudflare account
3. Home bridge	Access from anywhere, alerts with the app closed	Any always-on box with Docker: NAS, Raspberry Pi (64-bit), PC
4. OrcaSlicer	Send prints from Orca, plus a printer panel inside Orca	Mac app + OrcaSlicer 2.5+

```
Phone ⇄ relay (Cloudflare) ⇄ home bridge (NAS / Pi / PC) ⇄ printer
         sealed frames only    end-to-end encrypted with your pairing code
```

1. The app

Download from the latest release.

iPhone / iPad: `PrinterHub-x.y.z.ipa`. The file is unsigned, so install it with **SideStore**, **LiveContainer** or AltStore; they sign it with your own Apple ID. Later updates come through the app (Settings → Updates → Update), which hands the new version to LiveContainer or SideStore.

Mac (Apple Silicon): `PrinterHub-x.y.z.dmg`. Open it and drag Printer Hub to Applications. The first time, right-click the app and choose Open. From 1.18 on, the Mac app installs its own updates and asks you to restart.

Add a printer. Tap **+**. Printers on your network are found automatically; otherwise enter the printer's IP address (from the printer's network screen). That's all you need at home.

Supported: anything running Klipper with Moonraker, including Creality K1/K2 (rooted or stock with Moonraker), Snapmaker U1 and Voron.

2. Relay (once)

The relay is a tiny Cloudflare Worker that passes sealed messages between your phone and your bridge. It cannot read them. The free plan is plenty.

1. Install Node.js (LTS) on any computer.
2. Get the relay: download `printer-hub-relay-x.y.z.tar.gz` from the release and unpack it, or use the `relay/` folder of this repo.
3. In that folder:

```
npm install
npx wrangler login      # opens the browser to sign in to Cloudflare
npx wrangler deploy
```

4. Note the address it prints: `https://printer-hub-relay.<you>.workers.dev`.

---

3. Home bridge

The bridge runs on a device that stays on and is on the same network as the printer. It keeps one outgoing connection to your relay, so you don't open any router ports. It also sends **alerts** (finished, failed, paused, CFS humidity, low spool) to the free **ntfy** app, even when Printer Hub is closed.

The image is published for **amd64** (most NAS units and PCs) and **arm64** (Raspberry Pi 4/5 with a 64-bit OS, ARM NAS units).

Linux, Raspberry Pi or NAS with SSH: one command

```
curl -fsSL https://raw.githubusercontent.com/dragonemprorx90/printer-hub/main/deploy/install.sh | sh
```

It asks for the printer's IP, your relay URL, and whether the printer is a Creality K1/K2, whose camera needs a helper to work from away. It then starts everything in `~/printer-hub-bridge` and prints your **pairing code**. Run it again to change answers; your pairing is kept.

Don't have Docker yet? On a Pi or Linux PC: `curl -fsSL https://get.docker.com | sh`, then log out and back in.

NAS with a web UI (UGREEN, Synology, QNAP, Unraid, TrueNAS)

1. Make a folder, e.g. `docker/printer-hub-bridge`.
2. Put the two files from `deploy/` in it: `docker-compose.yml`, and `.env.example` renamed to `.env`.
3. Edit `.env`: set `PRINTER_HOST` and `RELAY_URL`. For a Creality K1/K2, uncomment the two camera lines.
4. In the NAS's Docker app, create a **Project / Stack** from that folder and start it. Synology calls it Container Manager → Project; UGREEN calls it Docker → Project.
5. Open the bridge container's log. The pairing code (`PHB1:…`) and a QR code are printed there.

Windows or Mac PC with Docker Desktop

1. Install Docker Desktop. In Settings → Resources → Network, turn on **Enable host networking**.
2. Download `docker-compose.yml` and `.env.example` from `deploy/` into a folder. Rename the second file to `.env` and edit it as above.
3. In that folder, run `docker compose up -d`, then `docker compose run --rm bridge --show-code`.

A PC only works while it's on and awake. A NAS or Pi is the better home for the bridge.

Without Docker

Each release has plain binaries (`printer-hub-bridge-x.y.z-linux-x64`, `-linux-arm64`, `-macos-arm64`):

```
chmod +x printer-hub-bridge-*
./printer-hub-bridge-* --relay https://printer-hub-relay.<you>.workers.dev --printer 192.168.1.50
```

Pair the app

In the app, open **Edit printer → Remote access code**. Paste the `PHB1:…` code, or scan the QR code. Treat the code like a password. To lock out every phone and issue a new code, run:

```
docker compose down && docker compose run --rm bridge --reset --show-code && docker compose up -d
```

At home the app talks to the printer directly. Away, it goes through the bridge, and it switches back by itself when you return.

More than one printer

Run one bridge per printer: copy the folder, then change `PRINTER_HOST` in the copy's `.env`. Each copy has its own `data/` and its own pairing code.

Alerts

On first start the bridge log shows an **ntfy topic**. Install ntfy (iOS, Android) and subscribe to that topic. To set quiet hours, humidity and spool limits, or turn alerts off, see the options in `.env`.

Updating the bridge

```
cd ~/printer-hub-bridge && docker compose pull && docker compose up -d
```

---

4. OrcaSlicer (Mac)

Printer Hub on the Mac runs a small local service on `127.0.0.1:7126` (Settings → Orca Slicer).

Send prints. In Orca, open the printer's connection settings:

- Host type: **Octo/Klipper**
- Hostname: `127.0.0.1:7126`. To skip the printer question, add the printer's name, e.g. `127.0.0.1:7126/k2-plus`.

Press **Print** or **Send**. Printer Hub uploads the file (at home or through the bridge) and opens print setup.

Printer panel (Orca 2.5+). Download `printer_hub.py` from the release, or save it from Settings → Orca Slicer. Install it from Orca's **Plugins** dialog. A panel opens beside the 3D view with every printer: camera, progress, temperatures, controls, filaments, spools, history and rules.

Troubleshooting

PROBLEM	FIX
Printer not found	Phone and printer must be on the same Wi-Fi. Enter the IP by hand. Moonraker must be on port 7125 (or set the port).
K2 camera shows "sent no video"	The camera serves one viewer at a time. Close the Creality app or Creality Print on other devices, wait 30 s, then tap Retry.
Camera from away is black (K1/K2)	`.env` needs both `COMPOSE_PROFILES=creality` and the `CAMERA_URL` line. Check `docker compose logs go2rtc`.
App says the bridge is offline	`docker compose logs bridge`. Check that `RELAY_URL` is your own relay and that the NAS can reach the internet.
Lost the pairing code	`docker compose run --rm bridge --show-code`
Mac update didn't install	Printer Hub must live in Applications, and your user must be allowed to change it (admin). Otherwise the app opens the download.

Still stuck? Open an issue with the printer model, app version and the bridge log.

Latest version of this guide: https://github.com/dragonemprorx90/printer-hub/blob/main/docs/SETUP.md