mbedOS 是 ARM 自己打造、主打 IoT 的解决方案,是一个针对 ARM CortexM 系列处理器的嵌入式开源生态。

## 开发工具介绍

mbedOS 支持三种开发工具:

- 1. 在线 IDE
- 2. mbed CLI 控制台
- 3. 第三方开发工具,如 IAR, MDK


在线 IDE 编译很方便快捷,但没有调试功能。第三方的 IDE 对于我们来说也不是重点。我们着重会来介绍 mbed-cli,它可以代码仓库版本控制、依赖管理、代码发布、从其他地方获取代码、调用编译系统及其他。

### Mbed CLI 安装

Windows 安装比较简单,直接到官网

(https://os.mbed.com/docs/latest/tools/installation-and-setup.html) 下载安装,下载链接 http://mbed-os.s3-eu-west-

1. amazonaws. com/builds/Mbed installer v0.4.7. exe



# LINUX 安装


需要先安装以下工具

- Python mbed CLI 是用 Python 写的,并且在 version 2.7.13 上做过完整测试,不兼容 Python3.x.
- Git version 1.9.5 or later
- Mercurial version 2.2.2 or later
- GNU ARM ARM GCC 交叉编译工具
- \$ git clone https://github.com/ARMmbed/mbed-cli
- \$ python setup.py install
- 参考链接 <a href="https://docs.mbed.com/docs/mbed-os-handbook/en/5.1/dev tools/cli/">https://docs.mbed.com/docs/mbed-os-handbook/en/5.1/dev tools/cli/</a>

Windows Mbed CLI 运行



WIN 键+R 键, 进入命令行, 输入 mbed 运行。



显示 Mbed CLI 的常见参数。

mbed config -L 检查配置

如果没有配置下 GCC 的路径(你安装 GNU ARM 的路径),请按如下命令设置: mbed config --global GCC\_ARM\_PATH "C:\Program Files (x86)\GNU Tools ARM Embedded\6 2017-q2-update\bin"

```
C:\Vindows\system32\cmd.exe


C:\Vmbed config -L
[mbed] Global config:
GCC_ARM_PATH=C:\Vrogram Files\GNU Tools ARM Embedded\6 2017-q2-update\bin

[mbed] Local config (C:\V):
Couldn't find valid mbed program in C:\

C:\V_
```

### 快速例子

mbed import https://github.com/modular2/helloworld cd helloworld




mbed compile -S 检查一下支持列表

```
國管理员: 命令提示符
                                                                     _ O X
                     | Supported | Supported | Supported | Support
! NUCLEO_F41@RB
              | Supported | Supported |
ted !
! NUCLEO_F411RE
                     ! Supported ! Supported ! Supported ! Support
ted !
              | Supported | Supported |
| NUCLEO_F412ZG
                     | Supported | Supported | Supported | Support
              | Supported | Supported |
ted !
! NUCLEO_F413ZH
                     ! Supported ! Supported ! Supported ! Support
              | Supported | Supported |
ted !
! NUCLEO_F429ZI
                     ! Supported ! Supported ! Supported ! Support
              | Supported | Supported |
ted !
! NUCLEO_F439ZI
                     ! Supported ! Supported ! Supported ! Support
ted !
              | Supported | Supported |
! NUCLEO_F446RE
                     | Supported | Supported | Supported | Support
              | Supported | Supported |
ted !
! NUCLEO_F446ZE
                     ! Supported ! Supported ! Supported ! Support
              | Supported | Supported |
ted !
                      | Supported | Supported | Supported | Support
! NUCLEO_F746ZG
ted !
              | Supported | Supported |
! NUCLEO_F756ZG
                     | Supported | Supported | Supported | Support
ted !
              | Supported | Supported |
! NUCLEO_F767ZI
                     | Supported | Supported | Supported | Support
ted !
              | Supported | Supported |
                     | Supported |
                                                                  Suppor
! NUCLEO_LØ11K4
ted !
```

针对 Modular-2 进行编译时,开发板选择使用相同 CPU 的 NUCLEO\_F429ZI。 mbed compile -t GCC ARM -m NUCLEO F429ZI



编译结束生成 helloworld. bin 文件。



#### 联机烧录

- 1. 将 modular-2 设备通过 USB(DAPLink 接口)连接开发电脑。
- 2. 将生成的 bin 文件复制到 modular-2 生成的存储盘符中。
- 3. 按复位键启动嵌入式程序。

### 注意事项

最新源码请查看: https://github.com/modular2。

新建文件或项目目录名称不能有空格。

使用虚拟机时, VMware Workstation 环境 mbed import 时有 python 工具问题,建议使用 Oracle VM VirtualBox 环境。