LegacyLink RG-210 — Quick Start Guide

Overview

The LegacyLink RG-210 is a DSL/Ethernet gateway. Installation requires a technician to manually configure WAN settings via the local console or web interface; the unit does not support remote auto-provisioning.

What's in the Box

- LegacyLink RG-210 unit
- RJ11 DSL cable
- RJ45 Ethernet cable
- Power adapter
- RS-232-to-USB console cable

Provisioning

- **Console**: Initial setup is performed over the RS-232 console port at 9600 baud using a terminal emulator. Technicians log in with the default credentials printed on the bottom label and manually enter WAN credentials.
- **Web GUI**: Once the unit is powered on, a local configuration page is reachable at 192.168.1.1 (default static management IP) for further configuration after initial console setup.
- **Other**: WAN connection mode (PPPoE vs. static) is selected via a physical 4-position DIP switch bank on the rear panel before power-on. Incorrect switch settings will prevent WAN negotiation.

DHCP and TR-069 are not supported on this model.

Required Tools

- Phillips (#2) screwdriver, to remove the rear panel and set internal jumpers
- RS-232-to-USB console cable (included) and a laptop with a terminal emulator (e.g. PuTTY, minicom) for initial configuration
- Small flathead screwdriver, to set the DIP switch bank for WAN mode (PPPoE vs. static IP)

Key Features

- 2x FXS ports for analog phone service (VoIP)
- Built-in battery backup connector for lifeline phone service
- Parental controls via MAC address filtering

Specifications

- Wi-Fi Standard: 802.11ac (Wi-Fi 5), dual-band
- WAN Speed: Up to 100 Mbps (ADSL2+/VDSL2)
- Form Factor: Desktop, not wall-mountable

FCC Compliance: This device complies with Part 15 of the FCC Rules.
© 2026 Example Corp. All Rights Reserved.

Cabling & Ports

Port	Type	Notes
DSL	RJ11	Connects to telco NID
LAN1–LAN4	RJ45 Fast Ethernet	Manual VLAN jumpers on rear panel
Console	RS-232 (RJ45-to-DB9)	Requires included adapter cable
Power	DC barrel, 12V	Included adapter only

LED Indicators

LED	Meaning
Power	solid green once the unit finishes its boot self-test
Power	blinking green during boot self-test
DSL	blinking amber while training/syncing with the DSLAM
DSL	solid green once DSL sync is achieved
Status	solid red if DSL sync fails after 3 attempts
Status	blinking red if an internal self-test fails

Installation Steps

1. Power off the unit before removing the rear panel.
2. Set the WAN mode DIP switches per the table in Appendix B.
3. Reattach the rear panel and connect the DSL and power cables.
4. Connect the console cable to a laptop and open a terminal session at 9600 baud.
5. Log in with the default console credentials and enter WAN account credentials as provided by the carrier.
6. Verify the DSL LED reaches solid green before disconnecting the console cable.
7. Optionally browse to 192.168.1.1 to configure Wi-Fi and LAN settings.

FCC Compliance: This device complies with Part 15 of the FCC Rules.
© 2026 Example Corp. All Rights Reserved.