

Nostalgia Photobooth

Mini PC Setup Guide

What you're receiving

A ready-to-run build of the photobooth app: **NostalgiaPhotobooth-MiniPC-2026-07-15.zip** (~150 MB). No installation, no extra software needed — just extract and run.

Setup steps

- 1 Copy the zip file onto the mini PC (USB drive, network share, or download link).
- 2 Extract the entire zip to a folder of your choice (e.g. C:\NostalgiaPhotobooth\). Extract everything — don't just pull out the .exe file, it needs the other files alongside it.
- 3 Double-click **Nostalgia Photobooth.exe** inside the extracted folder. The app opens in fullscreen kiosk mode automatically.

Before your first real session

- **Camera:** connect the Canon camera before launching the app, and make sure no other software (e.g. Canon's own utility) is also using it.
- **Printer:** install the printer's Windows driver as you normally would — the app prints through the standard Windows print system.
- **Touchscreen:** works out of the box; no extra driver needed beyond what Windows already detects.

Auto-start on boot (optional)

- 1 Right-click Nostalgia Photobooth.exe → **Create shortcut**.
- 2 Press Win + R, type shell:startup, hit Enter.
- 3 Move the shortcut into that folder.
- 4 The app now launches automatically whenever the mini PC boots.

Exiting the app

Press Alt + F4, or open Task Manager (Ctrl + Shift + Esc) and close it from there.

If something looks off

Issue	What to check
Camera not detected	Windows camera permissions; close any other app using the camera.
Blank/white screen on launch	Re-extract the zip fresh into a new folder — a partial extraction is the most common cause.
Printer not printing	Confirm the printer is set up and reachable from Windows outside the app first.

Photos save locally to Pictures\NostalgiaPhotobooth\ on the mini PC as a backup, in addition to the cloud gallery.