Bi-directional Programmable DC Power Supply

IT6600C Programming Guide (SAS)



Model: IT6600C Series

Version: V1.0

Notices

© Itech Electronic, Co., Ltd. 2026
No part of this manual may be reproduced in any form or by any means (including electronic storage and retrieval or translation into a foreign language) without prior permission and written consent from Itech Electronics, Co., Ltd. as governed by international copyright laws.

Manual Part Number

IT6600C

Revision

1st Edition: August. 11,

2026

Itech Electronic, Co., Ltd.

Trademarks

Pentium is U.S. registered trademarks of Intel Corporation.

Microsoft, Visual Studio, Windows and MS Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries and regions.

Warranty

The materials contained in this document are provided “as is”, and is subject to change, without prior notice, in future editions. Further, to the maximum extent permitted by applicable laws, ITECH disclaims all warrants, either express or implied, with regard to this manual and any information contained herein, including but not limited to the implied warranties of merchantability and fitness for a particular purpose. ITECH shall not be held liable for errors or for incidental or indirect damages in connection with the furnishing, use or application of this document or of any information contained herein. Should ITECH and the user enter into a separate written agreement with warranty terms covering the materials in this document that conflict with these terms, the warranty terms in the separate agreement shall prevail.

Technology Licenses

The hardware and/or software described herein are furnished under a license and may be used or copied only in accordance with the terms of such license.

Restricted Rights Legend

Restricted permissions of the U.S. government. Permissions for software and technical data which are authorized to the U.S. Government only include those for custom provision to end users ITECH provides this customary commercial license in software and technical data pursuant to FAR 12.211 (Technical Data) and 12.212 (Computer Software) and, for the Department of Defense, DFARS 252.227-7015 (Technical Data – Commercial Items) and DFARS 227.7202-3 (Rights in Commercial Computer Software or Computer Software Documentation).

Safety Notices

CAUTION

A CAUTION sign denotes a hazard.
It calls attention to an operating procedure or practice that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a CAUTION sign until the indicated conditions are fully understood and met.

WARNING

A WARNING sign denotes a hazard. It calls attention to an operating procedure or practice that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a WARNING sign until the indicated conditions are fully understood and met.



NOTE

A NOTE sign denotes important hint. It calls attention to tips or supplementary information that is essential for users to refer to.

Quality Certification and Assurance

We certify that the device meets all the published specifications.

Warranty

ITECH warrants that the product will be free from defects in material and workmanship under normal use for a period of one (1) year from the date of delivery (except those described in the Limitation of Warranty below).
For warranty service or repair, the product must be returned to a service center designated by ITECH.

Note

Visit https://www.itechate.com/en/support/register.html to complete product registration by filling out the necessary information to extend the warranty to two (2) years.

- The product returned to ITECH for warranty service must be shipped PREPAID. And ITECH will pay for return of the product to customer.
- If the product is returned to ITECH for warranty service from overseas, all the freights, duties and other taxes shall be on the account of customer.

Limitation of Warranty

This Warranty will be rendered invalid if the product is:

- Damage caused by circuit installed by customer or using customer own products or accessories;
- Modified or repaired by customer without authorization;
- Damage caused by circuit installed by customer or not operating our products under designated environment;
- The product model or serial number is modified, deleted, removed or illegible;
- Damaged as a result of accidents, including but not limited to lightning, moisture, fire, improper use or negligence.

Safety Symbols

⎓	Direct current	▮	ON (power on)
∼	Alternating current	○	OFF (power off)
⎓ ∼	Both direct and alternating current	⎍	Power-on state
⏚	Protective conductor terminal	⎎	Power-off state
⏚	Earth (ground) terminal	±	Reference terminal
⚠	Caution, risk of electric shock	+	Positive terminal

Copyright © Itech Electronic Co., Ltd.

	Warning, risk of danger (refer to this manual for specific Warning or Caution information)	▬	Negative terminal
	Frame or chassis terminal	-	-

Safety Precautions

The following safety precautions must be observed during all phases of operation of this instrument. Failure to comply with these precautions or specific warnings elsewhere in this manual will constitute a default under safety standards of design, manufacture and intended use of the instrument. ITECH assumes no liability for the customer's failure to comply with these precautions.

WARNING

- Do not use the instrument if it is damaged. Before operation, check the casing to see whether it cracks. Do not operate the instrument in the presence of inflammable gasses, vapors or dusts.
- The instrument is provided with power cord during delivery and should be connected to the distribution box. Before operation, be sure that the instrument is well grounded.
- Make sure to use the power cord supplied by ITECH.
- Check all marks on the instrument before connecting the instrument to power supply.
- Use electric wires of appropriate load. All loading wires should be capable of bearing maximum short-circuit of electronic load without overheating. If there are multiple loads, each pair of the load power cord must be carry out the full rated short-circuit output current of the power securely.
- Ensure the voltage fluctuation of mains supply is less than 10% of the working voltage range in order to reduce risks of fire and electric shock.
- Do not install alternative parts on the instrument or perform any unauthorized modification.
- Do not use the instrument if the detachable cover is removed or loose.
- To prevent the possibility of accidental injuries, be sure to use the power adapter supplied by the manufacturer only.
- We do not accept responsibility for any direct or indirect financial damage or loss of profit that might occur when using the instrument.
- This instrument is used for industrial purposes. Do not apply this product to IT power supply system.
- Never use the instrument with a life-support system or any other equipment subject to safety requirements.

CAUTION

- Failure to use the instrument as directed by the manufacturer may render its protective features void.
- Always clean the casing with a dry cloth. Do not clean the internals.
- Make sure the vent hole is always unblocked.

Copyright © Itech Electronic Co., Ltd.

Environmental Conditions

The instrument is designed for indoor use and an area with low condensation. The table below shows the general environmental requirements for the instrument.

Environmental Conditions	Requirements
Operating temperature	0°C to 40°C
Operating humidity	20%-80% (non-condensation)
Storage temperature	-20°C to 70 °C
Altitude	Operating up to 2,000 meters
Pollution degree	Pollution degree 2
Installation category	II

NOTE

To make accurate measurements, allow the instrument to warm up for 30 min before operation.

Regulatory Markings

CE	The CE tag shows that the product complies with the provisions of all relevant European laws (if the year is shown, it indicates that the year when the design is approved).
UKCA	The UKCA tag shows that the product complies with the provisions of all relevant United Kingdom laws (if the year is shown, it indicates that the year when the design is approved).
	This instrument complies with the WEEE directive (2002/96/EC) tag requirements. This attached product tag shows that the electrical/electronic product cannot be discarded in household waste.
	This symbol indicates that no danger will happen or toxic substances will not leak or cause damage in normal use within the specified period. The service life of the product is 10 years. The product can be used safely within the environmental protection period; otherwise, the product should be put into the recycling system.

Copyright © Itech Electronic Co., Ltd.

Waste Electrical and Electronic Equipment (WEEE) Directive



2002/96/EC Waste Electrical and Electronic Equipment (WEEE) Directive

This product complies with the WEEE Directive (2002/96/EC) marking requirement. This affix product label indicates that you must not discard the electrical/electronic product in domestic household waste.

Product Category

With reference to the equipment classifications described in the Annex I of the WEEE Directive, this instrument is classified as a “Monitoring and Control Instrument” product.

To return this unwanted instrument, contact your nearest ITECH office.

Copyright © Itech Electronic Co., Ltd.

Compliance Information

Complies with the essential requirements of the following applicable European Directives, and carries the CE marking accordingly:

- Electromagnetic Compatibility (EMC) Directive 2014/30/EU
- Low-Voltage Directive (Safety) 2014/35/EU

Conforms with the following product standards:

EMC Standard

IEC 61326-1 / EN 61326-1 [123]

Reference Standards

CISPR 11, Class A
IEC 61000-3-2
IEC 61000-3-3
IEC 61000-4-2
IEC 61000-4-3
IEC 61000-4-4
IEC 61000-4-5
IEC 61000-4-6
IEC 61000-4-11

Chapter 1 The product is intended for use in non-residential/non-domestic environments. Use of the product in residential/domestic environments may cause electromagnetic interference.

Chapter 2 Connection of the instrument to a test object may produce radiations beyond the specified limit.

Chapter 3 Use high-performance shielded interface cable to ensure conformity with the EMC standards listed above.

Safety Standard

IEC 61010-1:2010+A1:2019

Note

This section provides general and universal terms. For more detailed information on the Declaration of Conformity, please contact ITECH personnel.

Copyright © Itech Electronic Co., Ltd.

Content

Quality Certification and Assurance i
Warranty i
Limitation of Warranty i
Safety Symbols i
Safety Precautions ii
Environmental Conditions iii
Regulatory Markings iii
Waste Electrical and Electronic Equipment (WEEE) Directive iv


Compliance Information v

Chapter 1 SCPI Introduction 1

1.1 Overview 1
1.2 Command Type of SCPI 1
1.3 Message Type of SCPI 3
1.4 Response Data Type 5
1.5 Command Format 5
1.6 Data Type 7
1.7 Remote Interface Connections 9
1.8 Multi-channel @chanlist Introduction 9

Chapter 2 SOLar Subsystem 10

SOLar[:STATe] <state>[,(@chanlist)] 10
SOLar:MODE <mode>[,(@chanlist)] 10
SOLar:Vmax <level>[,(@chanlist)] 11
SOLar:USER:VOC <level>[,(@chanlist)] 11
SOLar:USER:IMP <level>[,(@chanlist)] 12
SOLar:USER:VMP <level>[,(@chanlist)] 12
SOLar:USER:ISC <level>[,(@chanlist)] 13
SOLar:EDIT:SAS:VMP [(@chanlist)] 13
SOLar:EDIT:SAS:PMP [(@chanlist)] 14
SOLar:EDIT:SAS:FORMula <CPD>[,(@chanlist)] 14
SOLar:EDIT:SAS:MATERial <NR1>[,(@chanlist)] 15
SOLar:FILTer:LEVel <CPD>[,(@chanlist)] 16

Chapter 3 Example 17

Example: SAS 17
Four-point method 17
Regulations 17

Copyright © Itech Electronic Co., Ltd.

Chapter 1 SCPI Introduction

1.1 Overview

SCPI is short for Standard Commands for Programmable Instruments which defines a communication method of bus controller and instrument. It is based on ASCII and supply for testing and measuring instruments. SCPI command is based on hierarchical architecture which also known as tree system. In this system, Relevant Command is returned to a common node or root, so that a subsystem is formed. A part of OUTPut subsystem is listed below:

OUTPut:


- **SYNC {OFF|0|ON|1}**
- **SYNC:**
  - **MODE {NORMal|CARRier}**
  - **POLarity {NORMal|INVerted}**

OUTPut is the root class keyword, SYNC is the second keyword, MODE and POLarity are the third keyword. Colon(:) is used for separating the command keyword and the next level keyword.

1.2 Command Type of SCPI

SCPI has two types of commands, common and subsystem.

- Common commands generally are not related to specific operation but to controlling overall instrument functions, such as reset, status, and synchronization. All commoncommands consist of a three-letter mnemonic preceded by an asterisk: ***RST *IDN? *SRE 8**.
- Subsystem commands perform specific instrument functions. They are organized into an inverted tree structure with the "root" at the top. The following figure shows a portion of a subsystem command tree, from which you access the commands located along the various paths.



Multiple Commands in a Message

Multiple SCPI commands can be combined and sent as a single message with one message terminator. There are two important considerations when sending several commands within a single message:

Copyright © Itech Electronic Co., Ltd.

- Use a semicolon to separate commands within a message.
- Head paths influence how the instrument interprets commands.

We consider the head path as a string which will be inserted in front of every command of a message. As for the first command of a message, the head path is a null string; for each subsequent command, the head path is a string which is defined to form the current command until and including the head of the last colon separator. A message with two combined commands:

CURR:LEV 3;PROT:STAT OFF

The example indicates the effect of semicolon and explains the concept of head path. Since the head path is defined to be "CURR" after "curr: lev 3", the head of the second command, "curr", is deleted and the instrument explains the second command as:

CURR:PROT:STAT OFF

If "curr" is explicitly included in the second command, it is semantically wrong. Since combining it with the head path will become "CURR:CURR:PROT:STAT OFF", resulting in wrong command.

Movement in the Subsystem

In order to combine commands from different subsystems, you need to be able to reset the header path to a null string within a message. You do this by beginning the command with a colon (:), which discards any previous header path. For example, you could clear the output protection and check the status of the Operation Condition register in one message by using a root specifier as follows:

PROTection:CLEAr;:STATus:OPERation:CONDition?

The following message shows how to combine commands from different subsystems as well as within the same subsystem:

POWer:LEVel 200;PROTection 28; :CURRent:LEVel 3;PROTection:STATe ON

Note the use of the optional header LEVel to maintain the correct path within the voltage and current subsystems, and the use of the root specifier to move between subsystems.

Including Common Commands

You can combine common commands with subsystem commands in the same message. Treat the common command as a message unit by separating it with a semicolon (the message unit separator). Common commands do not affect the header path; you may insert them anywhere in the message.

VOLTage:TRIGgered 17.5;:INITialize;*TRG

OUTPut OFF;*RCL 2;OUTPut ON

Case Sensitivity

Common commands and SCPI commands are not case sensitive. You can use upper or lower, for example:

Copyright © Itech Electronic Co., Ltd.

***RST = *rst**

:DATA? = :data?

:SYSTem:PRESet = :system:preset

Long-Form and Short-Form Versions

A SCPI command word can be sent in its long-form or short-form version. However, the short-form version is indicated by upper case characters. Examples:

:SYSTem:PRESet long-form

:SYST:PRES short form

:SYSTem:PRES long-form and short-form combination

Note that each command word must be in long-form or short-form, and not something in between.

For example, **:SYSTe:PRESe** is illegal and will generate an error. The command will not be executed.

Query

Observe the following precautions with queries:


- Set up the proper number of variables for the returned data. For example, if you are reading back a measurement array, you must dimension the array according to the number of measurements that you have placed in the measurement buffer.
- Read back all the results of a query before sending another command to the instrument. Otherwise a Query Interrupted error will occur and the unreturned data will be lost.

1.3 Message Type of SCPI

There are two types of SCPI messages, program and response.

- Program message: A program message consists of one or more properly formatted SCPI commands sent from the controller to the instrument. The message, which may be sent at any time, requests the instrument to perform some action.
- Response message: A response message consists of data in a specific SCPI format sent from the instrument to the controller. The instrument sends the message only when commanded by a program message called a "query."

The next figure illustrates SCPI message structure:



Copyright © Itech Electronic Co., Ltd.

The message unit

The simplest SCPI command is a single message unit consisting of a command header (or keyword) followed by a message terminator. The message unit may include a parameter after the header. The parameter can be numeric or a string.

ABORt<NL>

VOLTage 20<NL>

Headers

Headers, also referred to as keywords, are instructions recognized by the instrument. Headers may be either in the long form or the short form. In the long form, the header is completely spelled out, such as VOLTAGE, STATUS and DELAY. In the short form, the header has only the first three or four letters, such as VOLT, STAT and DEL.

Query indicator

Following a header with a question mark turns it into a query (**VOLTage?**, **VOLTage:PROTection?**). If a query contains a parameter, place the query indicator at the end of the last header (**VOLTage:PROTection?MAX**).

Message unit separator

When two or more message units are combined into a compound message, separate the units with a semicolon (**STATus:OPERation?;QUEStionable?**).

Root specifier

When it precedes the first header of a message unit, the colon becomes the root specifier. It tells the command parser that this is the root or the top node of the command tree.

Message terminator

A terminator informs SCPI that it has reached the end of a message. Three permitted message terminators are:

- newline (<NL>), decimal 10 or hexadecimal 0X0A in ASCII.
- end or identify (<END>)
- both of the above (<NL><END>).

In the examples of this guide, there is an assumed message terminator at the end of each message.

Command execution rules

- Commands execute in the order that they are presented in the program message.
- An invalid command generates an error and, of course, is not executed.
- Valid commands that precede an invalid command in a multiple command program message are executed.
- Valid commands that follow an invalid command in a multiple command program message are ignored.

Copyright © Itech Electronic Co., Ltd.

1.4 Response Data Type

Character strings returned by query statements may take either of the following forms, depending on the length of the returned string:

- **<CRD>**: character response data. Permits the return of character strings.
- **<AARD>**: arbitrary ASCII response data. Permits the return of undelimited 7-bit ASCII. This data type has an implied message terminator.
- **<SRD>**: string response data. Returns string parameters enclosed in double quotes.
- **<Block>**: arbitrary block data.

Response messages

A response message is the message sent by the instrument to the computer in response to a query command.

Sending a response message

After sending a query command, the response message is placed in the Output Queue. When the instrument is then addressed to talk, the response message is sent from the Output Queue to the computer

Multiple response messages

If you send more than one query command in the same program message, the multiple response messages for all the queries is sent to the computer when the instrument is addressed to talk. The responses are sent in the order that the query commands were sent and are separated by semicolons (;). Items within the same query are separated by commas (,). The following example shows the response message for a program message that contains four single item query commands:

0; 1; 1; 0

Response message terminator (RMT)

Each response is terminated with an LF (line feed) and EOI (end or identify). The following example shows how a multiple response message is terminated:

0; 1; 1; 0; <RMT>

Message exchange protocol

Two rules summarize the message exchange protocol:

- **Rule 1**: You must always tell the instrument what to send to the computer.

  The following two steps must always be performed to send information from the instrument other computer:
  1. Send the appropriate query command(s) in a program message.
  2. Address the instrument to talk.
- **Rule 2**: The complete response message must be received by the computer before another program message can be sent to the instrument.

1.5 Command Format

Formats for command display are as follows:

[SOURce[1|2]:]VOLTage:UNIT {VPP|VRMS|DBM}

Copyright © Itech Electronic Co., Ltd.

[SOURce[1|2]:]FREQuency:CENTer {<frequency>|MINimum|MAXimum|DEFault}

Based on the command syntax, most commands (and certain Parameter) are expressed in both upper and lower cases. Upper case refers to abbreviation of commands. Shorter program line may send commands in abbreviated format. Long-format commands may be sent to ensure better program readability.

For example, both formats of VOLT and VOLTAGE are acceptable in the above syntax statements. Upper or lower case may be used. Therefore, formats of VOLTAGE, volt and Volt are all acceptable. Other formats (such as VOL and VOLTAG) are invalid and will cause errors.

- Parameter options with given command strings are included in the brace ({ }). The brace is not sent along with command strings.
- Vertical stripes (|) separate several parameter options with given command strings. For example, {VPP|VRMS|DBM} indicates that you may assign "APP", "VRMS" or "DBM" in the above commands. Vertical stripes are not sent along with command strings.
- Angle brackets (< >) in the second example indicates that a value must be assigned to the parameter in the brace. For example, the parameter in the angle bracket is <frequency> in the above syntax statements. Angle brackets are not sent along with command strings. You must assign a value (such as "FREQ:CENT 1000") to the parameter, unless you select other options displayed in the syntax (such as "FREQ:CENT MIN").
- Some syntax elements (such as nodes and Parameter) are included in square brackets ([ ]). It indicates that these elements can be selected and omitted. Angle brackets are not sent along with command strings. If no value is assigned to the optional Parameter, the instrument will select a default value. In the above examples, "SOURce[1|2]" indicates that you may refer to source channel 1 by "SOURce" or "SOURce1" or "SOUR1" or "SOUR". In addition, since the whole SOURce node is optional (in the square bracket), you can refer to the channel 1 by omitting the whole SOURce node. It is because the channel 1 is the default channel for SOURce language node. On the other hand, if you want to refer to channel 2, "SOURce2" or "SOUR2" must be used in the program line.

Colon (:)

It is used to separate key words of a command with the key words in next level. As shown below:

APPL:SIN 455E3,1.15,0.0

In this example, APPLy command assigns a sine wave with frequency of 455 KHz, amplitude of 1.15 V and DC offset of 0.0 V.

Semicolon (;)

It is used to separate several commands in the same subsystem and can also minimize typing. For example, to send the following command string:

TRIG:SOUR EXT; COUNT 10

has the same effect as sending the following two commands:

TRIG:SOUR EXT
TRIG:COUNT 10

Copyright © Itech Electronic Co., Ltd.

Question mark (?)

You can insert question marks into a command to query current values of most Parameter. For example, the following commands will trigger to set the count as 10:

TRIG:COUN 10

Then, you may query count value by sending the following command:

TRIG:COUN?

You may also query the allowable minimum or maximum count as follows:

TRIG:COUN?MIN
TRIG:COUN?MAX

Comma (,)

If a command requires several Parameter, then a comma must be used to separate adjacent Parameter.

Space

You must use blank characters, [TAB] or [Space] to separate Parameter with key words of commands.

Common commands (*)

The IEEE-488.2 standard defines a set of common commands that perform functions such as reset, self-test, and status operations. Common commands always start with a asterisk (*) and occupy 3 character sizes, including one or more Parameter. Key words of a command and the first parameter are separated by a space. Semicolon (;) can separate several commands as follows:

***RST; *CLS; *ESE 32; *OPC?**

Command terminator

Command strings sent to the instrument must end with a <Newline> (<NL>) character. IEEE-488 EOI (End or Identify) information can be used as <NL> character to replace termination command string of <NL> character. It is acceptable to place one <NL> after a <Enter>. Termination of command string always resets current SCPI command path to root level.

NOTE

As for every SCPI message with one query sent to the instrument, the instrument will use a <NL> or newline sign (EOI) to terminate response of return. For example, if "DISP:TEXT?" is sent, <NL> will be placed after the returned data string to terminate response. If an SCPI message includes several queries separated by semicolon (such as "DISP?;DISP:TEXT?"), <NL> will terminate response returned after response to the last query. In all cases, the program must read <NL> in response before another command is sent to the instrument, otherwise errors will be caused.

1.6 Data Type

SCPI language defines several data types used for program message and response messages.

Copyright © Itech Electronic Co., Ltd.

- Numerical parameter

  Commands requiring numerical parameter support the notations of all common decimal notations, including optional signs, decimal points, scientific notation, etc. Special values of numerical parameter are also acceptable, such as MIN, MAX and DEF. In addition, suffixes for engineering units can also be sent together with numerical parameter (including M, k, m or u). If the command accepts only some specific values, the instrument will automatically round the input parameter to acceptable values. The following commands require numerical parameter of frequency value:
  [SOURce[1|2]:]FREQuency:CENTer
  {<Frequency>|MINimum|MAXimum}
  - **<NR1>**: represents an integer value, such as 273;
  - **<NR2>**: represents a real number in floating-point format, such as .273;
  - **<NR3>**: represents a real number in scientific notation, such as 2.73E+2;
  - **<Nrf>**: The extensible form includes <NR1>, <NR2> and <NR3>;
  - **<Nrf+>**: The extensible decimal form includes <Nrf>, MIN, MAX and DEF. MIN and MAX are the minimum and maximum finite number. Within the range of the parameter definition, DEF is the default of the parameter.

- Discrete parameter

  Discrete parameter are used for settings with limited number of programming values (such as IMMediate, EXTernal or BUS). They can use short and long format like key words of commands. They may be expressed in both upper and lower case. The query response always returns uppercase Parameter in short format. The following commands require discrete parameter in voltage unit:
  [SOURce[1|2]:]VOLTage:UNIT {VPP|VRMS|DBM}

- Boolean parameter

  Boolean parameter refer to true or false binary conditions. In case of false conditions, the instrument will accept "OFF" or "0". In case of true conditions, the instrument will accept "ON" or "1". In query of Boolean settings, the instrument will always return "0" or "1". Boolean parameter are required by the following commands:
  DISPlay {OFF|0|ON|1}

- ASCII string parameter

  String parameter may actually include all ASCII character sets. Character strings must start and end with paired quotation marks; and single quotation marks or double quotation marks are both allowed. Quotation mark separators may also act as one part of a string, they can be typed twice without any character added between them. String parameter is used in the following command:
  DISPlay:TEXT <quoted string>
  For example, the following commands display message of "WAITING..." (without quotation marks) on the front panel of the instrument.
  DISP:TEXT "WAITING..."
  Single quotation marks may also be used to display the same message.
  DISP:TEXT 'WAITING...'
  - **<SPD>**: string program data. String parameters enclosed in single or double quotes.
  - **<CPD>**: character program data.

Copyright © Itech Electronic Co., Ltd.

1.7 Remote Interface Connections

Please refer to user manual for detailed introductions of the remote interface.

Note

If the user want to change the settings of the instrument, for instance, the output setting value, the command **SYST:REM** must be sent to the instrument after finishing the connection between the instrument and PC.

1.8 Multi-channel @chanlist Introduction

Most of the commands in this programming guide support the use of the @Chanlist parameter. When using this parameter, please pay attention to its proper usage to ensure the command takes effect as expected.

For example, in the OUTPut[:STATe] <Bool>[,(@chanlist)] command:

- OUTP 1,(@1,2) turns on the output of both channel 1 and channel 2;
- OUTP 1,(@1) turns on the output of channel 1 only;
- OUTP 1,(@2) turns on the output of channel 2 only;
- OUTP 1 turns on the output of channel 1 by default.

In series or parallel mode, the @chanlist parameter is not required, and the command format should be OUTP 1.

Copyright © Itech Electronic Co., Ltd.

Chapter 2 SOLar Subsystem

The SOLAR subsystem contains instructions for the photovoltaic curve simulation function.

SOLar[:STATe] <state>[,(@chanlist)]

This command is used to control whether the switch of the photovoltaic curve simulation function is turned on.

- 0|OFF: No
- 1|ON: Yes

Syntax

SOLar[:STATe] <state>[,(@chanlist)]

Arguments

Bool

0|OFF|1|ON

Default Value

0

Example

SOL 1,(@1)

Query Syntax

SOLar[:STATe]? [(@chanlist)]

Returns

Bool

SOLar:MODE <mode>[,(@chanlist)]

This command is used to select the PV simulation curve. Choose regulatory mode or user-defined curve simulation.

Syntax

SOLar:MODE <mode>[,(@chanlist)]

Arguments

CPD

STATic|TABLE_C|SHADow|TABLE_P|DEF_C

Copyright © Itech Electronic Co., Ltd.

Default Value

STATic

Example

SOLar:MODE SHADow

Query Syntax

SOLar:MODE? [(@chanlist)]

Returns

CRD

SOLar:Vmax <level>[,(@chanlist)]

This command is used to set the maximum output voltage value in photovoltaic mode.

Syntax

SOLar:Vmax <level>[,(@chanlist)]

Arguments

<NRf+>

<MIN～MAX>|MINimum|MAXimum|DEFault

Default Value

MAX

Example

SOLar:Vmax MAX

SOLar:Vmax MAX,(@1)

SOLar:Vmax MAX,(@2)

SOLar:Vmax MAX,(@1:2)

SOLar:Vmax 100,(@1:2)

Query Syntax

SOLar:Vmax? [(@chanlist)]

Returns

<NRf>

SOLar:USER:VOC <level>[,(@chanlist)]

This command is used to set the open circuit voltage value.

Copyright © Itech Electronic Co., Ltd.

Syntax

SOLar:USER:VOC <level>[,(@chanlist)]

Arguments

<NRf+>

<MIN～MAX>|MINimum|MAXimum|DEFault

Default Value

MIN

Example

SOLar:USER:VOC 20

Query Syntax

SOLar:USER:VOC? [(@chanlist)]

Returns

<NRf>

SOLar:USER:IMP <level>[,(@chanlist)]

This command is used to set the maximum power current value.

Syntax

SOLar:USER:IMP <level>[,(@chanlist)]

Arguments

<NRf+>

<MIN～MAX>|MINimum|MAXimum|DEFault

Default Value

MIN

Example

SOLar:USER:IMP 5

Query Syntax

SOLar:USER:IMP? [(@chanlist)]

Returns

<NRf>

SOLar:USER:VMP <level>[,(@chanlist)]

This command is used to set the maximum power voltage value.

Copyright © Itech Electronic Co., Ltd.

Syntax

SOLar:USER:VMP <level>[,(@chanlist)]

Arguments

<NRf+>

<MIN～MAX>|MINimum|MAXimum|DEFault

Default Value

MIN

Example

SOLar:USER:VMP 40

Query Syntax

SOLar:USER:VMP? [(@chanlist)]

Returns

<NRf>

SOLar:USER:ISC <level>[,(@chanlist)]

This command is used to set the short-circuit current value.

Syntax

SOLar:USER:ISC <level>[,(@chanlist)]

Arguments

<NRf+>

<MIN～MAX>|MINimum|MAXimum|DEFault

Default Value

MIN

Example

SOLar:USER:ISC 5

Query Syntax

SOLar:USER:ISC? [(@chanlist)]

Returns

<NRf>

SOLar:EDIT:SAS:VMP [(@chanlist)]

This command is used to set the maximum power voltage value.

Copyright © Itech Electronic Co., Ltd.

Syntax

SOLar:EDIT:SAS:VMP [(@chanlist)]

Arguments

<NRf+>

<MIN～MAX>|MINimum|MAXimum|DEFault

Default Value

MIN

Example

SOLar:EDIT:SAS:VMP 20

Query Syntax

SOLar:EDIT:SAS:VMP? [(@chanlist)]

Returns

<NRf>

SOLar:EDIT:SAS:PMP [(@chanlist)]

This command is used to set the maximum power value.

Syntax

SOLar:EDIT:SAS:PMP [(@chanlist)]

Arguments

<NRf+>

<MIN～MAX>|MINimum|MAXimum|DEFault

Default Value

MIN

Example

SOLar:EDIT:SAS:PMP 50

Query Syntax

SOLar:EDIT:SAS:PMP? [(@chanlist)]

Returns

<NRf>

SOLar:EDIT:SAS:FORMula <CPD>[,(@chanlist)]

This command is used to set the legal selection in the legal mode

Copyright © Itech Electronic Co., Ltd.

(SANDIA|EN50530).

- When set to SANDIA, the following configuration needs to be done: SOlar:EDIT:SAS:TEMPture 50; SOLar:EDIT:SAS:IRR 1000
- When setting to EN50540, the following configuration needs to be done: SOlar:EDIT:SAS:TEMPture 25; SOLar:EDIT:SAS:IRR 1000

Note: If other values are configured, the regulation curve will be abnormal.

Syntax

SOLar:EDIT:SAS:FORMula <CPD>[,(@chanlist)]

Arguments

<CPD>

SANDIA|EN50530

Default Value

SANDIA

Example

SOLar:EDIT:SAS:FORMula EN50530,(@1)

Query Syntax

SOLar:EDIT:SAS:FORMula? [(@chanlist)]

Returns

<CRD>

SANDIA|EN50530

SOLar:EDIT:SAS:MATERial <NR1>[,(@chanlist)]

This command is used to select materials. Values 0,1,2 can be set.

- When the law is selected as SANDIA, setting 0 means TF, setting 1 means SCMC, and setting 2 means HEC.
- When EN50530 is selected as the regulation, setting 0 means TF and setting 1 means cSi.

Syntax

SOLar:EDIT:SAS:MATERial <NR1>[,(@chanlist)]

Arguments

<NR1>

0|1|2

Copyright © Itech Electronic Co., Ltd.

Default Value

0

Example

SOLar:EDIT:SAS:MATERial 1,(@1)

Query Syntax

SOLar:EDIT:SAS:MATERial? [(@chanlist)]

Returns

<NR1>

0|1|2

SOLar:FILTer:LEVel <CPD>[,(@chanlist)]

This command is used to select the filter speed. Filter the input voltage to reduce interference.

- LOW: Low speed
- MEDium: Medium speed
- FAST: High speed

Syntax

SOLar:FILTer:LEVel <CPD>[,(@chanlist)]

Arguments

<CPD>

LOW|MEDium|FAST

Default Value

MEDium

Example

SOLar:FILTer:LEVel FAST,(@2)

Query Syntax

SOLar:FILTer:LEVel? [(@chanlist)]

Returns

<CRD>

LOW|MEDium|FAST

Copyright © Itech Electronic Co., Ltd.

Chapter 3 Example

This chapter displays the programming examples to remotely control IT6600C power supply using SCPI commands.

Note

- If the user want to change the settings of the instrument, for instance, the output setting value, the command **SYST:REM** must be sent to the instrument after finishing the connection between the instrument and PC.
- " - >" indicates the commands that you send to the IT6600C power supply.

Example: SAS

Four-point method

SYST:REM

SOL:MODE DEF_C

SOLar:Vmax 500

SOLar:USER:VOC 50

SOLar:USER:IMP 10

SOLar:USER:VMP 35

SOLar:USER:ISC 20

SOLar:FILTer:LEVel FAST

SOL 1

OUTP 1

Regulations

SYST:REM

SOL:MODE STAT

SOLar:Vmax 500

SOLar:EDIT:SAS:PMP 400

SOLar:EDIT:SAS:VMP 80

SOLar:EDIT:SAS:MATERial 0

SOLar:EDIT:SAS:FORMula SANDIA

SOLar:EDIT:SAS:TEMPture 50

SOLar:EDIT:SAS:IRR 1000

Copyright © Itech Electronic Co., Ltd.

```
SOLar:FILTer:LEVel FAST
SOL 1
OUTP 1
```

Copyright © Itech Electronic Co., Ltd.

Contact US

Thank you for purchasing ITECH products. If you have any doubt about this product, please contact us as follow.

1. Visit ITECH website www.itechate.com .
2. Select the most convenient contact for further consultation.