0

Conveyor machine operating state
EQ
Source A MachineState 0
Source B 0

Cmd_Run

Conveyor machine operating state
MOVE
Source 1
Dest MachineState 0

1

Conveyor machine operating state
EQ
Source A MachineState 0
Source B 1

Conv_AtSpeed

Conveyor machine operating state
MOVE
Source 2
Dest MachineState 0

2

Conveyor machine operating state
EQ
Source A MachineState 0
Source B 2

Cmd_Run

Conveyor machine operating state
MOVE
Source 3
Dest MachineState 0

3

Conveyor machine operating state
EQ
Source A MachineState 0
Source B 3

LT
Source A Conv_SpeedFb_Hz 0.0
Source B 0.2

Conveyor machine operating state
MOVE
Source 0
Dest MachineState 0

(End)