


# 8-Bit Current Digital to Analog Converter (IDAC8)

1.70

### **Features**

- Three ranges: 2040 μA, 255 μA, and 31.875 μA
- Current sink or source selectable
- Software- or clock-driven output strobe
- Data source may be CPU, DMA, or UDB



## **General Description**

The IDAC8 component is an 8-bit current output DAC (Digital to Analog Converter). The output can source or sink current in three ranges. The IDAC8 can be controlled by hardware, software, or by a combination of both hardware and software.

# Input/Output Connections

This section describes the various input and output connections for the IDAC8. An asterisk (\*) in the list of I/Os indicates that the I/O may be hidden on the symbol under the conditions listed in the description of that I/O.

### lout - Analog

The lout terminal is the connection to the current source/sink. It can be routed to any analog-compatible pin on the device. When the highest current range is selected (2040  $\mu$ A), the output should only be routed to a specific set of pins that provide a direct low resistive path. These port pins are P0[6], P0[7], P3[0], or P3[1].

## data[7:0] - Input \*

This 8-bit-wide data signal connects the IDAC8 directly to the DAC bus. The DAC bus may be driven by UDB-based components or control registers, or routed directly from GPIO pins. Enable this input by setting the **Data Source** parameter to **DAC Bus**. If you select the **CPU or DMA** option instead, the bus connection disappears from the component symbol.

Use the data[7:0] input when hardware is capable of setting the proper value without CPU intervention. When using this option, you should enable **Strobe Mode** as well.

For many applications this input is not required, but instead the CPU or DMA will write a value directly to the data register. In firmware, you may use the IDAC\_SetValue() function or directly write a value to the IDAC8\_1\_Data register (assuming an instance name of "IDAC8\_1").

#### strobe - Input \*


The strobe input is an optional signal input and is selected with the **Strobe Mode** parameter. If **Strobe Mode** is set to **External**, the pin is visible and must be connected to a valid digital source. In this mode, the data is transferred from the IDAC8 register to the DAC on the next positive edge of the strobe signal.

If this parameter is set to **Register Write** the pin disappears from the symbol and any write to the data registers is immediately transferred to the DAC.

For audio or periodic sampling applications, the same clock used to clock the data into the DAC can also be used to generate an interrupt. In this case, each rising edge of the clock transfers data to the DAC and causes an interrupt to get the next value loaded into the DAC register.

## **Component Parameters**

Drag an IDAC8 component onto your design and double click it to open the **Configure** dialog.





The IDAC8 component provides the following parameters.

#### **Polarity**

The **Polarity** parameter allows you to select whether the IDAC8 sinks or sources current to its load. When the **Positive (Source)** option is selected, the output of the DAC sources current to a load that is connected to  $V_{SS}$  or other voltage that is at least 1.0 V below  $V_{DDA}$ . In the **Negative (Sink)** mode, it supplies current to a load that is connected to  $V_{DD}$  or other voltage at least 1.0 V above  $V_{SS}$ . Depending on which polarity is selected, the symbol shows the direction of the current.

#### Range

This parameter allows you to set one of three current ranges as the default value. The range may be changed at any time during runtime with the IDAC\_SetRange() function. If you select the highest current range, **0 – 2040 uA**, you should route the output to one of the special pins that provide a low resistive path. These pins are P0[6], P0[7], P3[0], and P3[1].

Range	Lowest Value	Highest Value	Step Size
0 – 31.875 uA	0.0 μΑ	31.875 μΑ	0.125 μΑ
0 – 255 uA	0.0 μΑ	255 μΑ	1 μΑ
0 – 2040 uA	0.0 μΑ	2040 μΑ	8 μΑ

#### Value

This is the initial value the IDAC8 presents after the IDAC\_Start() command is executed. The IDAC\_SetValue() function or a direct write to the DAC register overrides the default value at any time. Legal values are between 0 and FF, inclusive. The **uA** field represents IDAC8 source and sink current in microamps. **8 bit Hex** represents IDAC8 input data value in hexadecimal format.

#### **Data Source**

This parameter selects the source of the data to be written into the DAC register. If the CPU (firmware) or the DMA will write data to the IDAC8, then select **CPU or DMA (Data Bus)**. If data is written directly from the UDBs or a UDB-based component, then select **DAC Bus**. Note that there is only one DAC bus that is shared by all of the viDAC8 analog blocks. When **Data Source** is set as **DAC Bus**, the customizer automatically sets the **Strobe Mode** to **External** and disables the option so that you cannot change it.

## **Speed**

This parameter provides two settings for the designer, **Low Speed** and **High Speed**. In the Low Speed mode, the settling time is slower but it consumes less operating current. In the High Speed mode, the current settles much faster, but at a cost of more operating current.



Document Number: 001-70060 Rev. \*\* Page 3 of 19

#### **Strobe Mode**

This parameter selects whether the data is immediately written to the DAC as soon as the data is written into the IDAC8 data register. This mode is selected when the **Register Write** option is selected. When the **External** option is selected, a clock or signal from UDBs controls when the data is written from the DAC register to the actual DAC.

#### Resources

			API M	_				
Analog Blocks	Datapaths	Macro Status Control Datapaths cells Registers Registers Counter7				Flash	RAM	Pins (per External I/O)
1 VIDAC fixed block	N/A	N/A	N/A	N/A	N/A	417	3	1

The IDAC8 uses one vIDAC8 analog block.

# **Application Programming Interface**

Application Programming Interface (API) routines allow you to configure the component using software. The following table lists and describes the interface to each function. The subsequent sections cover each function in more detail.

By default, PSoC Creator assigns the instance name "IDAC8\_1" to the first instance of a component in a given design. You can rename the instance to any unique value that follows the syntactic rules for identifiers. The instance name becomes the prefix of every global function name, variable, and constant symbol. For readability, the instance name used in the following table is "IDAC8."

Function	Description
IDAC8_Start()	Initializes the IDAC8 with default customizer values. Enables and powers up the IDAC8.
IDAC8_Stop()	Disables the IDAC8 and sets it to the lowest power state.
IDAC8_SetSpeed()	Sets DAC speed.
IDAC8_SetPolarity()	Sets the output mode to current sink or source.
IDAC8_SetRange()	Sets full-scale range for IDAC8.
IDAC8_SetValue()	Sets value between 0 and 255 with the given range.
IDAC8_Sleep()	Stops and saves the user configuration.
IDAC8_WakeUp()	Restores and enables the user configuration.
IDAC8_Init()	Initializes or restores default IDAC8 configuration



Function	Description
IDAC8_Enable()	Enables the IDAC8.
IDAC8_SaveConfig()	Saves the current configuration
IDAC8_RestoreConfig()	Restores the configuration.

#### **Global Variables**

Variable	Description
IDAC8_initVar	Indicates whether the IDAC8 has been initialized. The variable is initialized to 0 and set to 1 the first time IDAC8_Start() is called. This allows the component to restart without reinitialization after the first call to the IDAC8_Start() routine.
	If reinitialization of the component is required, then the IDAC8_Init() function can be called before the IDAC8_Start() or IDAC8_Enable() function.

### void IDAC8\_Start(void)

**Description:** This is the preferred method to begin component operation. IDAC8\_Start() sets the initVar

variable, calls the IDAC8\_Init() function, and then calls the IDAC8\_Enable() function. Enables and powers up the IDAC8 to the given power level. A power level of 0 is the same as

executing the stop function.

Parameters: None Return Value: None

Side Effects: If the initVar variable is already set, this function only calls the IDAC Enable() function.

## void IDAC8\_Stop(void)

**Description:** Powers down IDAC8 to lowest power state and disables output.

Parameters: None
Return Value: None
Side Effects: None



## void IDAC8\_SetSpeed(uint8 speed)

**Description:** Sets DAC speed.

**Parameters:** uint8 speed: Sets DAC speed, see the following table for valid parameters.

Option	Description
IDAC8_LOWSPEED	Low speed (low power)
IDAC8_HIGHSPEED	High speed (high power)

Return Value: None
Side Effects: None

## void IDAC8\_SetPolarity(uint8 polarity)

**Description:** Sets output polarity to sink or source.

**Parameters:** uint8 polarity: Sets current sink or source functionality, see the following table.

Option	Description
IDAC8_SOURCE	Set mode as current source.
IDAC8_SINK	Set mode to current sink.

Return Value: None
Side Effects: None

## void IDAC8\_SetRange(uint8 range)

**Description:** Sets full-scale range for IDAC8

**Parameters:** uint8 range: Sets full-scale range for IDAC8. See the following table for ranges.

Option	Description
IDAC8_RANGE_32uA	Set full scale range to 31.875 μA
IDAC8_RANGE_255uA	Set full scale range to 255 μA
IDAC8_RANGE_2mA	Set full scale range to 2.040 mA

Return Value: None
Side Effects: None



### void IDAC8\_SetValue(uint8 value)

**Description:** Sets value to output on IDAC8. Valid values are between 0 and 255.

Parameters: uint8 value: Value between 0 and 255. A value of 0 is the lowest (zero) and a value of 255 is

the full-scale value. The full-scale value depends on the range, which is selected with the

IDAC SetRange() API.

Return Value: None

Side Effects: On PSoC 3 ES2, PSoC 3 Production, and PSoC 5, the IDAC8\_SetValue() function should be

called after enabling the power to the IDAC.

### void IDAC8\_Sleep(void)

**Description:** This is the preferred API to prepare the component for sleep. The IDAC8 Sleep() API saves

the current component state. Then it calls the IDAC8\_Stop() function and calls

IDAC8\_SaveConfig() to save the hardware configuration.

Call the IDAC\_Sleep() function before calling the CyPmSleep() or the CyPmHibernate() function. Refer to the PSoC Creator *System Reference Guide* for more information about

power-management functions.

Parameters: None
Return Value: None
Side Effects: None

## void IDAC8\_Wakeup(void)

**Description:** This is the preferred API to restore the component to the state when IDAC8 Sleep() was

called. The IDAC8\_Wakeup() function calls the IDAC8\_RestoreConfig() function to restore the configuration. If the component was enabled before the IDAC8\_Sleep() function was

called, the IDAC Wakeup() function will also re-enable the component.

Parameters: None
Return Value: None

Side Effects: Calling the IDAC8 Wakeup() function without first calling the IDAC8 Sleep() or

IDAC8 SaveConfig() function may produce unexpected behavior.



### void IDAC8\_Init(void)

**Description:** Initializes or restores the component according to the customizer Configure dialog settings. It

is not necessary to call IDAC8\_Init() because the IDAC8\_Start() API calls this function and is

the preferred method to begin component operation.

Parameters: None Return Value: None

Side Effects: All registers will be set to values according to the customizer Configure dialog. This will

reinitialize the component. Calling the IDAC8\_Init() function requires a call to

IDAC8\_SetValue() if you intend to set a new value other than what is currently in the register.

### void IDAC8\_Enable(void)

**Description:** Activates the hardware and begins component operation. It is not necessary to call

IDAC8\_Enable() because the IDAC8\_Start() API calls this function, which is the preferred

method to begin component operation.

Parameters: None
Return Value: None
Side Effects: None

### void IDAC8\_SaveConfig(void)

**Description:** This function saves the component configuration and nonretention registers. It also saves the

current component parameter values, as defined in the Configure dialog or as modified by

appropriate APIs. This function is called by the IDAC8 Sleep() function.

Parameters: None
Return Value: None
Side Effects: None

## void IDAC8\_RestoreConfig(void)

**Description:** This function restores the component configuration and nonretention registers. This function

also restores the component parameter values to what they were before calling the

IDAC8\_Sleep() function.

Parameters: None Return Value: None

Side Effects: Calling this function without first calling the IDAC8\_Sleep() or IDAC8\_SaveConfig() function

may produce unexpected behavior.



## Sample Firmware Source Code

PSoC Creator provides numerous example projects that include schematics and example code in the Find Example Project dialog. For component-specific examples, open the dialog from the Component Catalog or an instance of the component in a schematic. For general examples, open the dialog from the Start Page or **File** menu. As needed, use the **Filter Options** in the dialog to narrow the list of projects available to select.

Refer to the "Find Example Project" topic in the PSoC Creator Help for more information.

# **Functional Description**

The DAC generates either a voltage or a current output. It is built using current mirror architecture; current is mirrored from a reference source to a mirror DAC. Calibration and value current mirrors are responsible for the 8-bit calibration [DACx\_TR] and the 8-bit DAC value. The current is then diverted into the scaler to generate the current corresponding to the DAC value. The DAC value can either be gotten from the register DACx\_D or from eight lines from the UDB. This is selected using the DACx\_CR1[5] bit.

The DAC is strobed to get its output to change for the input code. The strobe control is enabled by the DACx\_STROBE[3] bit. The strobe sources for the DAC can be selected from the bus write strobe, analog clock strobe, or any UDB signal strobe. This is selected based on the setting in DACx\_STROBE[2:0].

### **Current (IDAC) Mode**

The two mirrors for the current source and sink provide output as a current source or current sink, respectively. These mirrors also provide range options in the current mode.

When used as an IDAC, the output is an 8-bit digital-to-analog conversion current. This is done by setting the DACx\_CR0 [4] register. The reference source is a current reference from the analog reference, called IREF(DAC). In this mode, there are three output ranges selected by register DACx\_CR0 [3:2]:

- 0 to 2.040 mA, 8 μA/bit
- 0 to 255 μA, 1 μA/bit
- 0 to 31.875 μA, 0.125 μA/bit

For each level, there are 255 equal steps of M/256 where M = 2.040 mA, 255  $\mu$ A, or 31.875  $\mu$ A. In the 2.040-mA configuration, the block is intended to output a current into an external 600- $\Omega$  load. The output may be delivered into any resistance or to a fixed voltage, as long as the minimum headroom requirement of 1.0 V is met. This means that the maximum voltage for sourced current is V<sub>DDA</sub> – 1.0 V and the minimum output voltage for sunk current is 1.0 V above V<sub>SSA</sub>.



Document Number: 001-70060 Rev. \*\* Page 9 of 19

The IDAC is calibrated at  $V_{OUT}$  = 0.0 V for current source and  $V_{OUT}$ =  $V_{DD}$  for current sink. When sourcing current, the value of the output current is slightly sensitive to the terminating voltage. At output voltages higher than 0.0 V, the output current is reduced. The current deviation is directly proportional to the code value and proportional to the ratio of the output voltage to the supply voltage. The deviation follows the form:

$$\%I_{ERROR} = -\frac{\text{code}}{255} \left( 0.8 \left( \frac{V_{OUT}}{V_{DD}} \right) + 0.8 \left( \frac{V_{OUT}}{V_{DD}} \right)^2 \right)$$

The typical deviation is less than 1.2 percent of full scale range for  $V_{DD} > 3.3 \text{ V}$  and  $V_{OUT} < V_{DD} = 1.0 \text{ V}$ . At maximum current, routing resistance slightly affects the output and the current deviation increases. At  $V_{DD} = 1.71 \text{ V}$ , there is not enough headroom for the IDAC to operate properly at currents larger than 1.0 mA.

**Note** This paragraph may be modified or expanded when current sink performance is evaluated.

The IDAC can convert up to 8 Msps. You can also select whether the output is a current source or a sink. This is done by the DACx\_CR1[2] register. The selection between source and sink for the IDAC can also be made using a UDB input. UDB control for the source sink selection is enabled using the DACx\_CR1[3] bit.

#### **DMA**

IDAC8 components do not require implementation of a DMA Request signal. The typical usage is signal generation. The data rate to IDAC8 components should be controlled externally. The DMA Wizard can be used to configure DMA operation as follows:


Name of DMA Source/Destination in DMA Wizard	Direction	DMA Req Signal	DMA Req Type	Description
IDAC8_Data_PTR	Destination	N/A	N/A	Stores the DAC value between 0 to 255



# **Block Diagram and Configuration**

Figure 1 shows the block diagram for the IDAC8 component.

Figure 1. Block Diagram



# **Registers**

The functions provided support most of the common runtime functions that are required for most applications. The following register reference provides a brief description for the advanced user. The IDAC8\_Data register may be used to write data directly to the DAC without using the API. This may be useful for either the CPU or DMA.

### IDAC8\_CR0

Bits	7	6	5	4	3	2	1	0
Value		reserved		mode	range	e[1:0]	hs	reserved

mode: Sets DAC to either voltage or current mode

range[1:0]: DAC range settings

hs: Sets data speed

# IDAC8\_CR1

Bits	7	6	5	4	3	2	1	0
Value	rese	rved	mx_data	reset_udb_e n	mx_idir	idirbit	Mx_ioff	ioffbit

mx data: Selects data source



Document Number: 001-70060 Rev. \*\* Page 11 of 19

reset\_udb\_en: DAC reset enable

mx\_idir: Mux selection for DAC current direction control

idirbit: Register source for DAC current direction

mx\_off: Mux selection for DAC current off control

ioffbit: Register source for DAC current off

## **IDAC8\_DATA**

Bits	7	6	5	4	3	2	1	0
Value				Data	a[7:0]			

Data[7:0]: DAC data register

## **DC and AC Electrical Characteristics**

Unless otherwise specified: Typical = 25 °C,  $V_{DDA}$  = 5.0 V, headroom = 1.0 V minimum, specifications apply to all ranges: 0 to 31.875  $\mu$ A, 0 to 255  $\mu$ A, 0 to 2.04 mA.

#### **IDAC8 DC Characteristics**

Parameter	Description	Conditions	Min	Тур	Max	Units
	Resolution		_	_	8	bits
I <sub>OUT</sub>	Output current at code = 255	Range = 2.040 mA, code = 255, $V_{DDA} \ge 2.7$ V, $R_{LOAD}$ = 600 $\Omega$	-	2.040	_	mA
		Range = 2.040 mA, High mode, code = 255, $V_{DDA} \le 2.7 \text{ V}$ , $R_{LOAD}$ = 300 $\Omega$	_	2.040	_	mA
		Range = 255 $\mu$ A, code = 255, R <sub>LOAD</sub> = 600 $\Omega$	-	255	_	μΑ
		Range = 31.875 $\mu$ A, code = 255, R <sub>LOAD</sub> = 600 $\Omega$	-	31.875	-	μΑ
	Monotonicity		_	_	Yes	
Ezs	Zero scale error		_	0	±1	LSB
Eg	Gain error	Range = 2.04 mA, 25 °C	_	_	±2.5	%
		Range = 255 μA, 25 °C	_	_	±2.5	%
		Range = 31.875 µA, 25 °C	_	_	±3.5	%



Parameter	Description	Conditions	Min	Тур	Max	Units
TC_Eg	Temperature coefficient of gain error	Range = 2.04 mA	_	_	0.04	%/°C
		Range = 255 μA	_	_	0.04	% / °C
		Range = 31.875 μA	_	_	0.05	% / °C
INL	Integral nonlinearity	Sink mode, range = 255 $\mu$ A, Codes 8 to 255, R <sub>LOAD</sub> = 2.4 k $\Omega$ , C <sub>LOAD</sub> = 15 pF	_	±0.9	±1	LSB
		Source mode, range = 255 $\mu$ A, Codes 8 – 255, R <sub>LOAD</sub> = 2.4 k $\Omega$ , C <sub>LOAD</sub> = 15 pF	-	±1.2	±1.5	LSB
DNL	Differential nonlinearity	Sink mode, range = 255 $\mu$ A, R <sub>LOAD</sub> = 2.4 k $\Omega$ , C <sub>LOAD</sub> = 15 pF	_	±0.3	±1	LSB
		Source mode, range = 255 $\mu$ A, R <sub>LOAD</sub> = 2.4 k $\Omega$ , C <sub>LOAD</sub> = 15 pF	_	±0.3	±1	LSB
Vcompliance	Dropout voltage, source or sink mode	Voltage headroom at max current, $R_{\text{LOAD}}$ to $V_{\text{DDA}}$ or $R_{\text{LOAD}}$ to $V_{\text{SSA}},V_{\text{DIFF}}$ from $V_{\text{DDA}}$	1	-	_	V
ldev	Voltage-dependent current deviation	Source mode, $V_{OUT} = 0.0 \text{ V}$ Sink mode, $V_{OUT} = V_{DD}$	_	1.0%	_	μA
I <sub>DD</sub>	Operating current, code = 0	Slow mode, source mode, range = 31.875 μA	_	44	100	μA
		Slow mode, source mode, range = 255 µA,	_	33	100	μA
		Slow mode, source mode, range = 2.04 mA	_	33	100	μA
		Slow mode, sink mode, range = 31.875 μA	_	36	100	μA
		Slow mode, sink mode, range = 255 μA	_	33	100	μA
		Slow mode, sink mode, range = 2.04 mA	_	33	100	μΑ
		Fast mode, source mode, range = 31.875 μA	_	310	500	μΑ
		Fast mode, source mode, range = 255 μA	_	305	500	μA
		Fast mode, source mode, range = 2.04 mA	_	305	500	μA
		Fast mode, sink mode, range = 31.875 μA	_	310	500	μA



Document Number: 001-70060 Rev. \*\* Page 13 of 19

Parameter	Description	Conditions	Min	Тур	Max	Units
		Fast mode, sink mode, range = 255 µA	1	300	500	μΑ
		Fast mode, sink mode, range = 2.04 mA	ı	300	500	μΑ

### **Figures**

INL versus DAC Code, Range = 255 μA, Source Mode



INL versus DAC Code, Range = 255 μA, Sink Mode




INL versus DAC Code, Range = 2.040 mA, Source Mode




INL versus DAC Code, Range = 2.040 mA, Sink Mode




DNL versus DAC Code, Range = 31.875 µA, Source Mode




DNL versus DAC Code, Range = 31.875 µA, Sink Mode




DNL versus DAC Code, Range = 255 µA, Source Mode




DNL versus DAC Code, Range = 255 µA, Sink Mode



DNL versus DAC Code, Range = 2.04 mA, Source Mode




DNL versus DAC Code, Range = 2.04 mA, Sink Mode






Document Number: 001-70060 Rev. \*\*


IDAC INL versus Temperature, Range = 255 μA, Fast Mode




IDAC Full Scale Error versus Temperature, Range =  $255 \mu A$ , Source Mode




IDAC Operating Current versus Temperature, Range =  $255 \mu A$ , Code = 0, Source Mode




IDAC DNL versus Temperature, Range = 255 μA, Fast Mode





IDAC Full Scale Error versus Temperature, Range =  $255 \mu A$ , Sink Mode



IDAC Operating Current versus Temperature, Range =  $255 \mu A$ , Code = 0, Sink Mode







## **IDAC8 AC Characteristics**


Parameter	Description	Conditions	Min	Тур	Max	Units
F <sub>DAC</sub>	Update rate		_	_	8	Msps
T <sub>SETTLE</sub>	Settling time to 0.5 LSB	Independent of IDAC range setting ( $I_{OUT}$ ), full-scale transition, $600-\Omega$ load, $C_L$ = 15 pF, Fast mode	_	_	125	ns
		Independent of IDAC range setting ( $I_{OUT}$ ), full-scale transition, $600-\Omega$ load, $C_L$ = 15 pF, Slow mode	_	_	1000	ns
In2040 μA	Current Noise	Fast mode, source mode, range = 2040 $\mu$ A, code = 255, $V_{DDA}$ = 5 V, 10 kHz	_	2.7	_	nA/rtHz
In255 μA		Fast mode, source mode, range = 255 µA, code = 255, V <sub>DDA</sub> = 5 V, 10 kHz	_	340	_	pA/rtHz
In32 μA		Fast mode, source mode, range = 31.875 µA, code = 255, V <sub>DDA</sub> = 5 V, 10 kHz	_	40	_	pA/rtHz




Document Number: 001-70060 Rev. \*\* Page 17 of 19

## **Figures**


#### Noise versus Frequency, 2040 µA



#### Noise versus Frequency, 255 µA



#### Noise versus Frequency, 32 µA





# **Component Changes**

This section lists the major changes in the component from the previous version.

Version	Description of Changes	Reason for Changes / Impact
1.70	IDAC8_Stop() API changes for PSoC 5	Change required to prevent the component from impacting unrelated analog signals when stopped, when used with PSoC 5.
	Updated IDAC8 customizer GUI	To allow user to enter float values in uA field.
		■ To force the Strobe mode to External when Data Source is selected as DAC Bus.
		■ To make IDAC8 GUI consistent with VDAC8 GUI.
1.60 Added a GUI Configuration Editor		Previous configuration window did not provide enough information for ease of use.
	Added characterization data to datasheet	
	Minor datasheet edits and updates	
1.50	Added Sleep/Wakeup and Init/Enable APIs.	To support low-power modes, as well as to provide common interfaces to separate control of initialization and enabling of most components.
	Added DMA capabilities file to the component.	This file allows the IDAC8 to be supported by the DMA Wizard tool in PSoC Creator.

© Cypress Semiconductor Corporation, 2011. The information contained herein is subject to change without notice. Cypress Semiconductor Corporation assumes no responsibility for the use of any circuitry other than circuitry embodied in a Cypress product. Nor does it convey or imply any license under patent or other rights. Cypress products are not warranted nor intended to be used for medical, life support, life saving, critical control or safety applications, unless pursuant to an express written agreement with Cypress. Furthermore, Cypress does not authorize its products for use as critical components in life-support systems where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress products in life-support systems application implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress against all charges.

PSoC® is a registered trademark, and PSoC Creator™ and Programmable System-on-Chip™ are trademarks of Cypress Semiconductor Corp. All other trademarks or registered trademarks referenced herein are property of the respective corporations.

Any Source Code (software and/or firmware) is owned by Cypress Semiconductor Corporation (Cypress) and is protected by and subject to worldwide patent protection (United States and foreign), United States copyright laws and international treaty provisions. Cypress hereby grants to licensee a personal, non-exclusive, non-transferable license to copy, use, modify, create derivative works of, and compile the Cypress Source Code and derivative works for the sole purpose of creating custom software and or firmware in support of licensee product to be used only in conjunction with a Cypress integrated circuit as specified in the applicable agreement. Any reproduction, modification, translation, compilation, or representation of this Source Code except as specified above is prohibited without the express written permission of Cypress.

Disclaimer: CYPRESS MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Cypress reserves the right to make changes without further notice to the materials described herein. Cypress does not assume any liability arising out of the application or use of any product or circuit described herein. Cypress does not authorize its products for use as critical components in life-support systems where a malfunction or failure may reasonably be expected to result in significant injury to the user. The inclusion of Cypress' product in a life-support systems application implies that the manufacturer assumes all risk of such use and in doing so indemnifies Cypress against all charges.

Use may be limited by and subject to the applicable Cypress software license agreement



Document Number: 001-70060 Rev. \*\* Page 19 of 19