

N.º de ficha	Título		Índice	Atualização do guia técnico
4.10.	Anexo 1	Parâmetros e valores de configuração AAM Projetos LCV	-	1/3/2024

PARAMETER	FUNCTIONALITY	Apenas ICE	TCS XDD TCS XDE	DECIMAL PHYSICAL VALUE IN RENAULT PLANT	MEANING
VH_TYPE	This calibration is used to configure the Vehicle Type			1	X82 ph2
				2	XFK
			XDD	3	XDD
			XDE	3	XDD
TRAILER_CF	This calibration is used to activate the Trailer feature		TPRWR	0	Trailer feature not activated
			THMPW, TWBPW, TWHPW	1	Trailer feature activated
RALAC_CF	This calibration is used to activate the RALAC feature	X	NODBW, ELECX	0	RALAC feature not activated
			DBWIA/DISEL	1	RALAC feature activated
RALAC_SW_TYPE_CF	This calibration is used to set button type for RALAC	X	NODBW, ELECX	0	bistable button
			DBWIA/DISEL	1	monostable button (impulse button)
FRIDGE_DRIVE_CF	This calibration is used to activate the Fridge drive feature	X	XDD, XDE	0	Fridge drive feature not activated
				0	Fridge drive feature not activated
				1	Fridge drive feature activated
FRIDGE_RPM_MAX_CF	This calibration is used to select the maximum engine speed for fridge drive activation	X	XDD, XDE	3700	Maximum engine speed caso XFK HR13 3600 rpm GMP = 4500 rpm compressor de refrigeração (5000 rpm regime máx. comp.) 3700 rpm GMP = 4600 rpm compressor 130 km/h => 2872 rpm GMP em 6.ª e 3430 rpm em 5.ª
FRIDGE_RPM_MIN_CF	This calibration is used to select the minimum engine speed for fridge drive activation	X	XDD, XDE	600	Minimum engine speed Baixo valor para permitir a transmissão do compressor de refrigeração em todos os casos de motor autónomo
BAT_STABILIZED_CF	This calibration is used to activate the Battery stabilized feature		NODBW	0	Battery stabilized feature not activated
			DBWIA	1	Battery stabilized feature activated
BAT_STABILIZED_MIN_VOLTAGE_CF	This calibration is used to select the minimum voltage for the Battery Stabilized feature		XDD, XDE	14	Passar este valor para 13,5 V no caso de uma bateria de iões de lítio (não exceder 13,8 V, caso contrário a bateria de iões de lítio fica em sobretensão)
BAT_STABILIZED_VOLTAGE_RATE_CF	This calibration is used to select the voltage rate for the Battery Stabilized feature		XDD, XDE	1	Rate 1 (a correspondência entre o Rate e V/S é efetuada através da configuração do calculador USM)
BAT_STABILIZED_SW_TYPE_CF	This calibration is used to set button type for Battery stabilized feature		NODBW	0	bistable button
			DBWIA	1	monostable button (impulse button)
BATT_COUPLING_CF	This calibration is used to activate the Battery coupling feature		NODBW	0	Battery coupling feature not activated
			DBWIA	1	Battery coupling feature activated
SEL_PWR_LIM_CUT_OFF	This calibration is used to activate to Output power cut off		NODBW	0	Output power cut off not activated
			DBWIA	1	Output power cut off activated
O_PWM_1	This calibration is used to set the Output PWM 1 signal		NODBW	0	No Configuration
			DBWIA	1	VehicleSpeed
O_PWM_2	This calibration is used to set the Output PWM 2 signal		NODBW, ELECX	0	No Configuration
			DBWIA/DISEL	2	EngineRPM
O_PWM_3	This calibration is used to set the Output PWM 3 signal		NODBW	0	No Configuration
			DBWIA	3	ExternalTemperature
O_PWM_4	This calibration is used to set the Output PWM 4 signal		NODBW	0	No Configuration
			DBWIA	4	EngineCoolantTemp

O_PWM_5	This calibration is used to set the Output PWM 5 signal		NODBW, ELEX	0	No Configuration
			DBWIA/DISEL	5	FuelLevelDisplayed
O_PWM_6	This calibration is used to set the Output PWM 6 signal		NODBW, DISEL	0	No Configuration
			DBWIA/ELEX	6	HVBatteryEnergyLevel
O_PWM_7	This calibration is used to set the Output PWM 7 signal		NODBW	0	No Configuration
			DBWIA	7	NightRheostatedLightMaxPercent
O_LOG_1_power_limitation	This calibration is used to configure the power limitation for Output logical 1 pin		XDD, XDE	1	No power limitation on Output logical 1 pin. Output logical 1 has a priority behaviour.
O_LOG_2_power_limitation	This calibration is used to configure the power limitation for Output logical 2 pin		XDD, XDE	1	No power limitation on Output logical 2 pin. Output logical 2 has a priority behaviour.
O_LOG_3_power_limitation	This calibration is used to configure the power limitation for Output logical 3 pin		XDD, XDE	0	Power limitation on Output logical 3 pin.
O_LOG_4_power_limitation	This calibration is used to configure the power limitation for Output logical 4 pin		XDD, XDE	1	No power limitation on Output logical 4 pin. Output logical 4 has a priority behaviour.
O_LOG_5_power_limitation	This calibration is used to configure the power limitation for Output logical 5 pin		XDD, XDE	1	No power limitation on Output logical 5 pin. Output logical 5 has a priority behaviour.
O_LOG_6_power_limitation	This calibration is used to configure the power limitation for Output logical 6 pin		XDD, XDE	1	No power limitation on Output logical 6 pin. Output logical 6 has a priority behaviour.
O_LOG_7_power_limitation	This calibration is used to configure the power limitation for Output logical 7 pin		XDD, XDE	1	No power limitation on Output logical 7 pin. Output logical 7 has a priority behaviour.
O_LOG_8_power_limitation	This calibration is used to configure the power limitation for Output logical 8 pin		XDD, XDE	1	No power limitation on Output logical 8 pin. Output logical 8 has a priority behaviour.
O_LOG_9_power_limitation	This calibration is used to configure the power limitation for Output logical 9 pin		XDD, XDE	1	No power limitation on Output logical 9 pin. Output logical 9 has a priority behaviour.
O_LOG_10_power_limitation	This calibration is used to configure the power limitation for Output logical 10 pin		XDD, XDE	1	No power limitation on Output logical 10 pin. Output logical 10 has a priority behaviour.
O_LOGICAL_1_SWITCH_OFF_CONDITION	This calibration is used to configure the switch off conditions for the Output logical 1		XDD, XDE	0	No switch off
O_LOGICAL_2_SWITCH_OFF_CONDITION	This calibration is used to configure the switch off conditions for the Output logical 2		XDD, XDE	0	No switch off
O_LOGICAL_3_SWITCH_OFF_CONDITION	This calibration is used to configure the switch off conditions for the Output logical 3		XDD, XDE	0	No switch off
O_LOGICAL_4_SWITCH_OFF_CONDITION	This calibration is used to configure the switch off conditions for the Output logical 4		XDD, XDE	0	No switch off
O_LOGICAL_5_SWITCH_OFF_CONDITION	This calibration is used to configure the switch off conditions for the Output logical 5		XDD, XDE	0	No switch off
O_LOGICAL_6_SWITCH_OFF_CONDITION	This calibration is used to configure the switch off conditions for the Output logical 6		XDD, XDE	0	No switch off
O_LOGICAL_7_SWITCH_OFF_CONDITION	This calibration is used to configure the switch off conditions for the Output logical 7		XDD, XDE	0	No switch off
O_LOGICAL_8_SWITCH_OFF_CONDITION	This calibration is used to configure the switch off conditions for the Output logical 8		XDD, XDE	0	No switch off

O_LOGICAL_9_SWITCH_OFF_CONDITION	This calibration is used to configure the switch off conditions for the Output logical 9		XDD, XDE	0	No switch off	
O_LOGICAL_10_SWITCH_OFF_CONDITION	This calibration is used to configure the switch off conditions for the Output logical 10		XDD, XDE	0	No switch off	
						Comentário
O_LOG_1	This calibration is used to set the Output logical 1 signal		NODBW, ELECX	0	No Configuration	
			DBWIA/DISEL	49	EngIdleSpeedIncreaseStatus	
O_LOG_2	This calibration is used to set the Output logical 2 signal		NODBW	0	No Configuration	
			DBWIA	52	VoltageRegulationStatus_V2	
O_LOG_3	This calibration is used to set the Output logical 3 signal		NODBW	0	No Configuration	
			DBWIA	57	Battery coupling	
O_LOG_4	This calibration is used to set the Output logical 4 signal		NODBW	0	No Configuration	
				0	No Configuration	
				56	Fridge drive activated	
			DBWIA	59	Configurable algorithm 1 activated. Used for Parking Hand Brake	
O_LOG_5	This calibration is used to set the Output logical 5 signal		NODBW	0	No Configuration	
				4	DoorSwitches	
			DBWIA	58	Footstep activated	
O_LOG_6	This calibration is used to set the Output logical 6 signal		NODBW	0	No Configuration	
				6	DoorsLocked	Parâmetro CAN_EXT utilizado = VehicleOutsideLockedState
			DBWIA	48	AAM_DigitalInputMonitoring5	Parâmetro CAN_EXT utilizado = AAM_DigitalInputMonitoring5
O_LOG_7	This calibration is used to set the Output logical 7 signal		NODBW	0	No Configuration	
			DBWIA	1	BrakeInfoStatus	Parâmetro CAN_EXT utilizado = BrakeInfoStatus
O_LOG_8	This calibration is used to set the Output logical 8 signal		NODBW	0	No Configuration	
			DBWIA	12	NeutralContact	
O_LOG_9	This calibration is used to set the Output logical 9 signal		NODBW	0	No Configuration	
			DBWIA	36	IgnitionLevel	Parâmetro CAN_EXT utilizado = VehicleStates
O_LOG_10	This calibration is used to set the Output logical 10 signal		NODBW, ELECX	0	No Configuration	
			DBWIA/DISEL	9	AutoStart	Parâmetro CAN_EXT utilizado = VehicleStates

FRIDGE_RPM_HYST_CF	This calibration is used to select the engine speed hysteresis	X	XDD, XDE	0	Hysterisis value in % for Minimum & Maximum engine speed Exemplo: 3700 - 10% 600-10% Resolução = 0,392 = 100/255 (8 bits)
				0	
				10	
ENG_RESTART_CF	This calibration is used to active the engine restart feature	X	NODBW, ELECX	0	Engine Restart feature not activated
			DBWIA/DISEL	1	Engine Restart feature activated. (function used only for Stop/start vehicle)
MUTE_CF	This calibration is used to activate or deactivate the radio mute feature		NODBW	0	Mute feature not activated
			DBWIA	1	Mute feature activated
MUTE_SW_TYPE_CF	This calibration is used to set the button type for Radio Mute		XDD, XDE	0	bistable button
DOOR_MUTE_DRIVER_CF	This calibration is used to enable driver door to mute Radio		XDD, XDE	0	No mute radio when opening a door
DOOR_MUTE_PASSENGER_CF	This calibration is used to enable passenger door to mute Radio		XDD, XDE	0	No mute radio when opening a door
DOOR_MUTE_REAR_RIGHT_CF	This calibration is used to enable rear right lateral door to mute Radio		XDD, XDE	0	No mute radio when opening a door
DOOR_MUTE_REAR_LEFT_CF	This calibration is used to enable rear left lateral door to mute Radio		XDD, XDE	0	No mute radio when opening a door
DOOR_MUTE_TAILGATE_CF	This calibration is used to enable tailgate door to mute Radio		XDD, XDE	0	No mute radio when opening a door
PRODUCER_LOAD_LOW_CF	This calibration is used to configure the Low threshold		XDD, XDE	70	Low Threshold of Producer load

PRODUCER_LOAD_HIGH_CF	This calibration is used to configure the High threshold		XDD, XDE	98	High Threshold of Producer load
PRODUCER_LOAD_HIGH_DELAY_CF	This calibration is used to configure the Producer_load delay for the High threshold		XDD, XDE	2	Delay for the High Threshold of Producer load
O_POWER_CF	This calibration is used to activate the O_POWER supply feature		NODBW	0	Output power supply not activated
			DBWIA	1	Output power supply activated
FOOTSTEP_VEH_SPEED_MIN_CF	This calibration is used to configure the Minimum threshold for the footstep feature		XDD, XDE	3	3 km/h
FOOTSTEP_VEH_SPEED_HYST_CF	This calibration is used to configure the hysteresis threshold for footstep feature		XDD, XDE	2	2 km/h
CONFIGURABLE_ALGORITHM_CF.VAR1	This calibration is used to define the VAR1 of the Configurable Algorithm			0	No Configuration
			XDD, XDE	21	CAN_EXT_ParkingBrakeStatus
CONFIGURABLE_ALGORITHM_CF.OP1	This calibration is used to define the OP1 of the Configurable Algorithm			0	No Configuration
			XDD, XDE	1	=
CONFIGURABLE_ALGORITHM_CF.VALUE1	This calibration is used to define the VALUE 1 of the Configurable Algorithm			0	No Configuration
			XDD, XDE	2	Parking brake applied
CONFIGURABLE_ALGORITHM_CF.COMB OP	This calibration is used to define the COMB OP of the Configurable Algorithm		XDD, XDE	0	NC
CONFIGURABLE_ALGORITHM_CF.VAR2	This calibration is used to define the VAR2 of the Configurable Algorithm		XDD, XDE	0	NC
CONFIGURABLE_ALGORITHM_CF.OP2	This calibration is used to define the OP2 of the Configurable Algorithm		XDD, XDE	0	NC
CONFIGURABLE_ALGORITHM_CF.VALUE2	This calibration is used to define the VALUE 2 of the Configurable Algorithm		XDD, XDE	0	NC
CONFIGURABLE_ALGORITHM_CF.SAFE_VAL	This calibration is used to define the SAFE_VAL of the Configurable Algorithm		XDD, XDE	0	Safe value = 0
I_ANALOG_1_CF	This calibration is used to enable/disable the data sent on CAN_EXT and/or CAN_ADAPT_1		NODBW	0	data not sent on CAN-EXT and not sent on CAN_ADAPT_1
			DBWIA	3	data sent on CAN_EXT and sent on CAN_ADAPT_1
I_ANALOG_2_CF	This calibration is used to enable/disable the data sent on CAN_EXT and/or CAN_ADAPT_1		NODBW	0	data not sent on CAN-EXT and not sent on CAN_ADAPT_1
			DBWIA	3	data sent on CAN_EXT and sent on CAN_ADAPT_1
I_ANALOG_3_CF	This calibration is used to enable/disable the data sent on CAN_EXT and/or CAN_ADAPT_1		NODBW	0	data not sent on CAN-EXT and not sent on CAN_ADAPT_1
			DBWIA	3	data sent on CAN_EXT and sent on CAN_ADAPT_1
I_LOG_1_CF	This calibration is used to enable/disable data sent on CAN_EXT and/or CAN_ADAPT_1		NODBW	0	data not sent on CAN-EXT and not sent on CAN_ADAPT_1
			DBWIA	3	data sent on CAN_EXT and sent on CAN_ADAPT_1
I_LOG_2_CF	This calibration is used to enable/disable data sent on CAN_EXT and/or CAN_ADAPT_1		NODBW	0	data not sent on CAN-EXT and not sent on CAN_ADAPT_1
			DBWIA	3	data sent on CAN_EXT and sent on CAN_ADAPT_1
	This calibration is used to enable/disable data sent on CAN_EXT and/or CAN_ADAPT_1		NODBW	0	data not sent on CAN-EXT and not sent on CAN_ADAPT_1

I_LOG_3_CF			DBWIA	3	data sent on CAN_EXT and sent on CAN_ADAPT_1
I_LOG_4_CF	This calibration is used to enable/disable data sent on CAN_EXT and/or CAN_ADAPT_1		NODBW	0	data not sent on CAN_EXT and not sent on CAN_ADAPT_1
			DBWIA	3	data sent on CAN_EXT and sent on CAN_ADAPT_1
I_LOG_5_CF	This calibration is used to enable/disable data sent on CAN_EXT and/or CAN_ADAPT_1		NODBW	0	data not sent on CAN_EXT and not sent on CAN_ADAPT_1
			DBWIA	3	data sent on CAN_EXT and sent on CAN_ADAPT_1

CONFIGURABLE_ALGORITHM_2_CF.VAR1	This calibration is used to define the VAR1 of the Configurable Algorithm 2		XDD, XDE	49	CAN_EXT_VehicleStates
CONFIGURABLE_ALGORITHM_2_CF.OP1	This calibration is used to define the OP1 of the Configurable Algorithm 2		XDD, XDE/ELECX	2	>
			XDD, XDE/DISEL	1	=
CONFIGURABLE_ALGORITHM_2_CF.VALUE1	This calibration is used to define the VALUE 1 of the Configurable Algorithm 2		XDD, XDE/ELECX	0	0000 = Sleeping
			XDD, XDE/DISEL	7	0111 = PowertrainRunning
CONFIGURABLE_ALGORITHM_2_CF.COMB OP	This calibration is used to define the COMB OP of the Configurable Algorithm 2		XDD, XDE/DISEL/FWDRV	2	COMB.OP = OR
			XDD, XDE/DISEL/RWDRV	0	COMB.OP = Condition 1 only
			XDD, XDE/ELECX	0	COMB.OP = Condition 1 only
CONFIGURABLE_ALGORITHM_2_CF.VAR2	This calibration is used to define the VAR2 of the Configurable Algorithm 2		XDD, XDE/DISEL/FWDRV	82	CAN_EXT_SOCBattery14V
			XDD, XDE/DISEL/RWDRV	0	No configuration
			XDD, XDE/ELECX	0	No configuration
CONFIGURABLE_ALGORITHM_2_CF.OP2	This calibration is used to define the OP2 of the Configurable Algorithm 2		XDD, XDE	2	>
CONFIGURABLE_ALGORITHM_2_CF.VALUE2	This calibration is used to define the VALUE 2 of the Configurable Algorithm 2		XDD, XDE	22	80% ==> 22 = [80-69] / 0,5
CONFIGURABLE_ALGORITHM_2_CF.SAFE_VAL	This calibration is used to define the SAFE_VAL of the Configurable Algorithm 2		XDD, XDE	0	Safe value = 0

Legenda

Parâmetro não utilizado na pasta de configuração (Nack 22 se utilizado)

RENAULT PLANT	RENAULT AFTER SALES
------------------	------------------------

PARAMETER	FUNCTIONALITY	Apenas ICE	SIZE	UNIT	RESOLUTION	OFFSET	VALUE	MEANING		
START: PARAMETERS AVAILABLE ONLY FROM SW311										
VH_TYPE	This calibration is used to configure the Vehicle Type		8 bits	decimal	1	0	0	No configuration		Yes
							1	XB2 ph2		
							2	XFK		
							3	XOD		
TRAILER_CF	This calibration is used to activate the Trailer feature		8 bits	boolean	1	0	0	Trailer feature not activated		Yes
							1	Trailer feature activated		
RALAC_CF	This calibration is used to activate the RALAC feature	X	8 bits	boolean	1	0	0	RALAC feature not activated		Yes
							1	RALAC feature activated		
RALAC_SW_TYPE_CF	This calibration is used to set button type for RALAC	X	8 bits	boolean	1	0	0	bistable button		Yes
							1	monostable button (impulse button)		
FRIDGE_DRIVE_CF	This calibration is used to activate the Fridge drive feature	X	8 bits	boolean	1	0	0	Fridge drive feature not activated		Yes
							1	Fridge drive feature activated		
FRIDGE_RPM_MIN_CF	This calibration is used to select the minimum engine speed for fridge drive activation	X	16 bits	rpm	0,125	0	(value x resolution) + offset = physical value	Minimum engine speed Valor baixo para permitir a transmissão do compressor de refrigeração em todos os casos de motor autônomo		Yes
FRIDGE_RPM_MAX_CF	This calibration is used to select the maximum engine speed for fridge drive activation	X	16 bits	rpm	0,125	0	(value x resolution) + offset = physical value	Maximum engine speed Valor elevado para permitir a transmissão do compressor de refrigeração em todos os casos de motor autônomo		Yes
BAT_STABILIZED_CF	This calibration is used to activate the Battery stabilized feature		8 bits	boolean	1	0	0	Battery stabilized feature not activated		Yes
							1	Battery stabilized feature activated		
BAT_STABILIZED_MIN_VOLTAGE_CF	This calibration is used to select the minimum voltage for the Battery Stabilized feature		3 bits	V	0,5	12	(value x resolution) + offset = physical value	Passar este valor para 13,5 V no caso de uma bateria de íons de lítio (não exceder 13,8 V, caso contrário a bateria de íons de lítio fica em sobretensão)		Yes
BAT_STABILIZED_VOLTAGE_RATE_CF	This calibration is used to select the voltage rate for the Battery Stabilized feature		8 bits	decimal	1	0	0	No Request		Yes
							1	Rate 1 (a correspondência entre o Rate e V/S é efetuada através da configuração do calculador USM)		
							2	Rate 2 (a correspondência entre o Rate e V/S é efetuada através da configuração do calculador USM)		
							3	Rate 3 (a correspondência entre o Rate e V/S é efetuada através da configuração do calculador USM)		
BAT_STABILIZED_SW_TYPE_CF	This calibration is used to set button type for Battery stabilized feature		8 bits	boolean	1	0	0	bistable button		Yes
							1	monostable button (impulse button)		
BATT_COUPLING_CF	This calibration is used to activate the Battery coupling feature		8 bits	boolean	1	0	0	Battery coupling feature not activated		Yes
							1	Battery coupling feature activated		
SEL_PWR_LIM_CUT_OFF	This calibration is used to activate to Output power cut off		8 bits	boolean	1	0	0	Output power cut off not activated		Yes
							1	Output power cut off activated		
O_PWM_X (X: 1 to 7) 7 parameters	This calibration is used to set the Output PWM X (1 to 7) signal		8 bits	decimal	1	0	0	No Configuration		Yes
							1	VehicleSpeed		
							2	EngineRPM		
							3	ExternalTemperature		
							4	EngineCoolantTemp		
							5	FuelLevelDisplayed		
							6	HVBatteryEnergyLevel		
							7	NightRheostatedLightMaxPercent		
O_LOG_X_power_limitation (X: 1 to 10) 10 parameters	This calibration is used to configure the power limitation for Output logical X pin (X: 1 to 10)		8 bits	boolean	1	0	0	Power limitation on Output logical X pin. Power limitation is following vehicle power limitation request		Yes
							1	NO power limitation on Output logical X pin		
O_LOGICAL_X_SWITCH_OFF_CONDITION (X: 1 to 10)	This calibration is used to configure the switch off conditions for the Output logical X pin (X: 1 to 10)		3 bits	decimal	1	0	0	No switch off		Yes
							1	Output switched off while engine stopped		
							2	Output switched off while engine starting		

10 parameters							3	Output switched off while engine stopped & starting				
END: PARAMETERS AVAILABLE ONLY FROM SW311												
START: PARAMETERS AVAILABLE ONLY FROM SW410												
FRIDGE_RPM_HYST_CF	This calibration is used to configure hysteresis in percentage to apply to min and max engine speed	X	8 bits	%	0.392 = 100/255	0	(value x resolution) + offset = physical value	Hysteresis value in % for Minimum & Maximum engine speed Example: 3700 - 10% 300-10%			Yes	Yes
ENG_RESTART_CF	This calibration is used to activate the engine restart feature	X	8 bits	boolean	1	0	0 1	Engine Restart feature not activated Engine Restart feature activated			Yes	Yes
MUTE_CF	This calibration is used to activate or deactivate the radio mute feature		8 bits	boolean	1	0	0 1	Mute feature not activated Mute feature activated			Yes	Yes
MUTE_SW_TYPE_CF	This calibration is used to set the button type for Radio Mute		8 bits	boolean	1	0	0 1	bistable button monostable button (impulse button)			Yes	Yes
DOOR_MUTE_DRIVER_CF	This calibration is used to enable driver door to mute Radio		1 bit	boolean	1	0	0 1	No mute radio when opening a door Mute radio when opening driver door			Yes	Yes
DOOR_MUTE_PASSENGER_CF	This calibration is used to enable passenger door to mute Radio		1 bit	boolean	1	0	0 1	No mute radio when opening a door Mute radio when opening passenger door			Yes	Yes
DOOR_MUTE_REAR_RIGHT_CF	This calibration is used to enable rear right door to mute Radio		1 bit	boolean	1	0	0 1	No mute radio when opening a door Mute radio when opening rear right door			Yes	Yes
DOOR_MUTE_REAR_LEFT_CF	This calibration is used to enable rear left door to mute Radio		1 bit	boolean	1	0	0 1	No mute radio when opening a door Mute radio when opening rear left door			Yes	Yes
DOOR_MUTE_TAILGATE_CF	This calibration is used to enable tailgate door to mute Radio		1 bit	boolean	1	0	0 1	No mute radio when opening a door Mute radio when opening tailgate door			Yes	Yes
PRODUCER_LOAD_LOW_CF	This calibration is used to configure the Low threshold for Producer load		8 bits	%	1	0	(value x resolution) + offset = physical value				Yes	Yes
PRODUCER_LOAD_HIGH_CF	This calibration is used to configure the High threshold for Producer load		8 bits	%	1	0	(value x resolution) + offset = physical value				Yes	Yes
PRODUCER_LOAD_HIGH_DELAY_CF	This calibration is used to configure the Producer_load delay for the High threshold		8 bits	s	0.02 s	0	(value x resolution) + offset = physical value				Yes	Yes
O_POWER_CF	This calibration is used to activate the O_POWER supply feature		8 bits	boolean	1	0	0 1	Output power supply not activated Output power supply activated			Yes	Yes
FOOTSTEP_VEH_SPEED_MIN_CF	This calibration is used to configure the threshold for footstep activation.		16 bits	km/h	0.01	0	(value x resolution) + offset = physical value	Do not choose a value < 3km/h because VDC can not deliver a value < 3 km/h			Yes	Yes
FOOTSTEP_VEH_SPEED_HYST_CF	This calibration is used to configure the hysteresis threshold for footstep activation.		16 bits	km/h	0.01	0	(value x resolution) + offset = physical value				Yes	Yes
CONFIGURABLE_ALGORITHM_CF.VAR1	This calibration is used to define the VAR1 of the Configurable Algorithm		8 bits	decimal	1	0	See Tab "Configurable Algorithm"	VAR 1 for Configurable Algorithm			Yes	Yes
CONFIGURABLE_ALGORITHM_CF.OP1	This calibration is used to define the OP1 of the Configurable Algorithm		8 bits	decimal	1	0	0 1 2 3 4 5 6	NOP (no operator OP1) = > >= < <= !=			Yes	Yes
CONFIGURABLE_ALGORITHM_CF.VALUE1	This calibration is used to define the VALUE1 of the Configurable Algorithm		32 bits	signed	1	0	VALUE 1 = [(physical value 1) - (offset)] / resolution	VALUE 1 for Configurable Algorithm			Yes	Yes
CONFIGURABLE_ALGORITHM_CF.COMB OP	This calibration is used to define the COMB OP of the Configurable Algorithm		8 bits	decimal	1	0	0 1 2 3 4 5 6	Condition 1 only Condition 1 AND Condition 2 Condition 1 OR Condition 2 Condition 1 XOR Condition 2 NOT (Condition 1 AND Condition 2) NOT (Condition 1 OR Condition 2) NOT (Condition 1 XOR Condition 2)			Yes	Yes
CONFIGURABLE_ALGORITHM_CF.VAR2	This calibration is used to define the VAR2 of the Configurable Algorithm		8 bits	decimal	1	0	See Tab "Configurable Algorithm"	VAR 2 for Configurable Algorithm			Yes	Yes

CONFIGURABLE_ALGORITHM_CF.OP2	This calibration is used to define the OP2 of the Configurable Algorithm		8 bits	decimal	1	0	0	NOP (no operator OP2)			Yes	Yes
							1	=				
							2	>				
							3	>=				
							4	<				
							5	<=				
							6	!=				
CONFIGURABLE_ALGORITHM_CF.VALUE2	This calibration is used to define the VALUE2 of the Configurable Algorithm		32 bits	signed	1	0	VALUE 2 = [(physical value 2) - (offset)] / resolution	VALUE 2 for Configurable Algorithm			Yes	Yes
CONFIGURABLE_ALGORITHM_CF.SAFE_VAL	This calibration is used to define the SAFE_VAL of the Configurable Algorithm		8 bits	boolean	1	0	0	Output logical X inactive (open circuit) when: - invalid value sent by ECUs - frame not received by AAM - init value sent by ECUs			Yes	Yes
							1	Output logical X active (ground) when: - invalid value sent by ECUs - frame not received by AAM - init value sent by ECUs				

								SW400 CAN_EXT PARAMETER	SW400 CAN_ADAPT_1 PARAMETER			
I,ANALOG_X_CF (X: 1 to 3) 3 parameters	This calibration is used to enable/disable the analog data sent on CAN_EXT and/or CAN_ADAPT_1		8 bits	decimal		0	0	data not sent on CAN-EXT and not sent on CAN_ADAPT_1	NA	NA	Yes	Yes
							1	data sent on CAN-EXT and not sent on CAN_ADAPT_1	AAM_AnalogInputMonitoringX (X: 1 to 3)	NA		
							2	data not sent on CAN_EXT and sent on CAN_ADAPT_1	NA	AnalogInputMonitoringX (X: 1 to 3)		
							3	data sent on CAN_EXT and sent on CAN_ADAPT_1	AAM_AnalogInputMonitoringX (X: 1 to 3)	AnalogInputMonitoringX (X: 1 to 3)		
I,LOG_X_CF (X: 1 to 5) 5 parameters	This calibration is used to enable/disable the logical data sent on CAN_EXT and/or CAN_ADAPT_1		8 bits	decimal		0	0	data not sent on CAN-EXT and not sent on CAN_ADAPT_1	NA	NA	Yes	Yes
							1	data sent on CAN-EXT and not sent on CAN_ADAPT_1	AAM_DigitalInputMonitoringX (X: 1 to 5)	NA		
							2	data not sent on CAN_EXT and sent on CAN_ADAPT_1	NA	DigitalInputMonitoringX (X: 1 to 5)		
X=6, X=7: doesn't exist, HW predisposal only							3	data sent on CAN_EXT and sent on CAN_ADAPT_1	AAM_DigitalInputMonitoringX (X: 1 to 5)	DigitalInputMonitoringX (X: 1 to 5)		

END: PARAMETERS AVAILABLE ONLY FROM SW410

START: PARAMETERS AVAILABLE ONLY FROM SW610												
CONFIGURABLE_ALGORITHM_2_CF.VAR1	This calibration is used to define the VAR1 of the Configurable Algorithm 2		8 bits	decimal	1	0	See Tab "Configurable Algorithm"	VAR 1 for Configurable Algorithm 2			Yes	Yes
CONFIGURABLE_ALGORITHM_2_CF.OP1	This calibration is used to define the OP1 of the Configurable Algorithm 2		8 bits	decimal	1	0	0 1 2 3 4 5 6	NOP (no operator OP1) = > >= < <= !=			Yes	Yes
CONFIGURABLE_ALGORITHM_2_CF.VALUE1	This calibration is used to define the VALUE1 of the Configurable Algorithm 2		32 bits	signed	1	0	VALUE 1 = [(physical value 1) - (offset)] / resolution	VALUE 1 for Configurable Algorithm 2			Yes	Yes
CONFIGURABLE_ALGORITHM_2_CF.COMB OP	This calibration is used to define the COMB OP of the Configurable Algorithm 2		8 bits	decimal	1	0	0 1 2 3 4 5 6	Condition 1 only Condition 1 AND Condition 2 Condition 1 OR Condition 2 Condition 1 XOR Condition 2 NOT (Condition 1 AND Condition 2) NOT (Condition 1 OR Condition 2) NOT (Condition 1 XOR Condition 2)			Yes	Yes
CONFIGURABLE_ALGORITHM_2_CF.VAR2	This calibration is used to define the VAR2 of the Configurable Algorithm 2		8 bits	decimal	1	0	See Tab "Configurable Algorithm"	VAR 2 for Configurable Algorithm 2			Yes	Yes
CONFIGURABLE_ALGORITHM_2_CF.OP2	This calibration is used to define the OP2 of the Configurable Algorithm 2		8 bits	decimal	1	0	0 1 2 3 4 5 6	NOP (no operator OP2) = > >= < <= !=			Yes	Yes

CONFIGURABLE_ALGORITHM_2_CF.VALUE2	This calibration is used to define the VALUE2 of the Configurable Algorithm 2		32 bits	signed	1	0	VALUE 2 = [(physical value 2) - (offset)] / resolution	VALUE 2 for Configurable Algorithm 2			Yes	Yes
CONFIGURABLE_ALGORITHM_2_CF.SAFE_VAL	This calibration is used to define the SAFE_VAL of the Configurable Algorithm 2		8 bits	boolean	1	0	0 Output logical X inactive (open circuit) when: - invalid value sent by ECUs - frame not received by AAM - init value sent by ECUs 1 Output logical X active (ground) when: - invalid value sent by ECUs - frame not received by AAM - init value sent by ECUs				Yes	Yes
CONFIGURABLE_ALGORITHM_3_CF.VAR1	This calibration is used to define the VAR1 of the Configurable Algorithm 3		8 bits	decimal	1	0	See Tab "Configurable Algorithm"	VAR 1 for Configurable Algorithm 3			Yes	Yes
CONFIGURABLE_ALGORITHM_3_CF.OP1	This calibration is used to define the OP1 of the Configurable Algorithm 3		8 bits	decimal	1	0	0 NOP (no operator OP1) 1 = 2 > 3 >= 4 < 5 <= 6 !=				Yes	Yes
CONFIGURABLE_ALGORITHM_3_CF.VALUE1	This calibration is used to define the VALUE1 of the Configurable Algorithm 3		32 bits	signed	1	0	VALUE 1 = [(physical value 1) - (offset)] / resolution	VALUE 1 for Configurable Algorithm 3			Yes	Yes
CONFIGURABLE_ALGORITHM_3_CF.COMB_OP	This calibration is used to define the COMB OP of the Configurable Algorithm 3		8 bits	decimal	1	0	0 Condition 1 only 1 Condition 1 AND Condition 2 2 Condition 1 OR Condition 2 3 Condition 1 XOR Condition 2 4 NOT (Condition 1 AND Condition 2) 5 NOT (Condition 1 OR Condition 2) 6 NOT (Condition 1 XOR Condition 2)				Yes	Yes
CONFIGURABLE_ALGORITHM_3_CF.VAR2	This calibration is used to define the VAR2 of the Configurable Algorithm 3		8 bits	decimal	1	0	See Tab "Configurable Algorithm"	VAR 2 for Configurable Algorithm 3			Yes	Yes
CONFIGURABLE_ALGORITHM_3_CF.OP2	This calibration is used to define the OP2 of the Configurable Algorithm 3		8 bits	decimal	1	0	0 NOP (no operator OP2) 1 = 2 > 3 >= 4 < 5 <= 6 !=				Yes	Yes
CONFIGURABLE_ALGORITHM_3_CF.VALUE2	This calibration is used to define the VALUE2 of the Configurable Algorithm 3		32 bits	signed	1	0	VALUE 2 = [(physical value 2) - (offset)] / resolution	VALUE 2 for Configurable Algorithm 3			Yes	Yes
CONFIGURABLE_ALGORITHM_3_CF.SAFE_VAL	This calibration is used to define the SAFE_VAL of the Configurable Algorithm 3		8 bits	boolean	1	0	0 Output logical X inactive (open circuit) when: - invalid value sent by ECUs - frame not received by AAM - init value sent by ECUs 1 Output logical X active (ground) when: - invalid value sent by ECUs - frame not received by AAM - init value sent by ECUs				Yes	Yes

END: PARAMETERS AVAILABLE ONLY FROM SW610

START: PARAMETERS AVAILABLE ON: SW311, or SW410, or SW610 (SEE COLUMN "AVAILABLE FROM SW")

								Output Logical X ACTIVE WHEN	SW311 CAN_EXT PARAMETER	SW311 CAN_ADAPT_1 PARAMETER		
0_LOQ_X (X: 1 to 10)	This calibration is used to set the Output logical X (1 to 10) signal		8 bits	decimal	1	0	0	No Configuration	NA	NA	Yes	Yes
10 parameters							1	001 Brake pedal not pressed 010 Brake pedal pressed 100 Brake pedal confirmed pressed 111 unavailable	BrakeInfoStatus	BrakeSwitchEngineControl		

							2	0 Compressor clutch off 1 Compressor clutch on	ACCompClutchStatus	ACCompressorAuthorized		
							3	00 Not used 01 Clutch pedal not pressed 10 Clutch pedal pressed at minimum 11 Unavailable	ClutchSwitchMinimumTravel			
								00 Not used 01 Clutch pedal not pressed at maximum 10 Clutch pedal pressed at maximum 11 Unavailable	ClutchSwitchMaximumTravel	ClutchSwitch		
								00 Unavailable Value 01 Driver door closed 10 Driver door open 11 Not Used	DriverDoorState	DriverDoorState		
								00 Unavailable Value 01 Passenger door closed 10 Passenger door open 11 Not Used	PassengerDoorState	PassengerDoorState		
							4	00 Unavailable Value 01 Rear Right door closed 10 Rear Right door open 11 Not Used	RearRightDoorState	RearRightDoorState		
								00 Unavailable Value 01 Tail Gate door closed 10 Tail gate door open 11 Not Used	TailGateStatus	TailGateStatus		
								00 Unavailable Value 01 Rear Left door closed 10 Rear Left door open 11 Not Used	RearLeftDoorState	RearLeftDoorState		
							5	0000 Sleeping 0001 Not used 0010 CutoffPending 0011 AutoACC - BatTempLevel 0100 Not used 0101 IgnitionLevel 0110 StartingInProgress (durante o arranque do motor) 0111 PowertrainRunning 1000 AutoStart 1001 EngineSystemStop 1010 Not used 1011 Not used 1100 Not used 1101 Not used 1110 Not used 1111 Unavailable	VehicleStates	IgnitionSwitch		
							6	0 Vehicle not locked from the outside by the customer 1 Vehicle Locked from the outside by the customer	VehicleOutsideLockedState	DoorsLocked		
							7	000 left and right flashing indicators OFF 001 left flashing indicator ON and right flashing indicator OFF 010 left flashing indicator OFF and right flashing indicator ON 011 left flashing indicator ON and right flashing indicator ON 111 Unavailable	FlashingIndicatorStatus	FlashingIndicators		
							8	000 left and right flashing indicators OFF 001 left flashing indicator ON and right flashing indicator OFF 010 left flashing indicator OFF and right flashing indicator ON 011 left flashing indicator ON and right flashing indicator ON 111 Unavailable	FlashingIndicatorStatus	HazardLight		
							9	0000 Sleeping 0001 Not used 0010 CutoffPending 0011 AutoACC - BatTempLevel 0100 Not used 0101 IgnitionLevel 0110 StartingInProgress 0111 PowertrainRunning 1000 AutoStart (arranque na saída da fase StopAuto) 1001 EngineSystemStop 1010 Not used 1011 Not used 1100 Not used 1101 Not used 1110 Not used 1111 Unavailable	VehicleStates	AutoStart		
							10	0 no AIRBAG system malfunction 1 AIRBAG system malfunction	AIRBAGMalfunction	AIRBAGMalfunction		
							11	00 not used 01 Rear Gear not Engaged 10 Rear Gear Engaged 11 unavailable	RearGearEngaged	RearGearEngaged		
							12	00 not used 01 neutral contact not reached 10 neutral contact reached 11 unavailable	NeutralContact	NeutralContact		

						X82P2: 00 Unavailable 01 No warning 10 AT major failure warning (Level 2) 11 Protection mode activated XFK: 00 Unavailable 01 No warning 10 AT major failure warning (Level 2) 11 Protection mode activated	AT_Level2FailureDisplayRequest	AT_Level2FailureDisplayRequest		
						0 position lights display not requested 1 position lights display requested	PositionLightsDisplay	PositionLightsDisplay		
						0 High beam display not requested 1 High beam display requested	HighBeamDisplay	HighBeamDisplay		
						0 low beam display not requested 1 low beam display requested	LowBeamDisplay	LowBeamDisplay		
						0 front fog lights display not requested 1 front fog lights display requested	FrontFogLightsDisplay	FrontFogLightsDisplay		
						000 Cruise Control (CC) and Speed Limit (SL) OFF 001 SL active 010 SL on and (awaiting or suspended) 011 SL requested and in failure 100 CC active 101 CC ON and (awaiting or suspended) 110 CC requested and in failure 111 Vehicle not equipped with CC/SL	CruiseControlStatus	CruiseControlStatus		
						0 no water detected in diesel 1 water detected in diesel	DieselFilterWaterDetection	DieselFilterWaterDetection		
						0 no Engine Control Failure Level 1 1 Engine Control Failure Level 1	EngineControlFailureLevel1	EngineControlFailureLevel1		
						0 no Engine Control Failure Level 2 create by stoping the engine 1 Engine Control Failure Level 2 create by stoping the engine	EngineControlFailureLevel2	EngineControlFailureLevel2		
						0 no water temperature warning 1 water temperature warning	WarningWaterTemp	WarningWaterTemp		
						No test of readiness codes status and Readiness Codes completed and MIL lamp off request No test of readiness codes status and Readiness Codes completed and MIL Lamp on request No test of readiness codes status and Readiness Codes completed and MIL lamp flash request No test of readiness codes status and Readiness Codes completed and MIL lamp auto-test	MILLamp	MILLamp		
						0 no ABS regulation 1 ABS in regulation	ABSinRegulation	ABSinRegulation		
						0 no ABS malfunction 1 ABS malfunction	ABSMalfunction	ABSMalfunction		
						0 no ASR regulation 1 ASR in regulation	ASRinRegulation	ASRinRegulation		
						0 no AYC in regulation 1 AYC in regulation	AYCinRegulation	AYCinRegulation		
						0 no MSR regulation 1 MSR in regulation	MSRinRegulation	MSRinRegulation		
						0 no AYC malfunction 1 AYC malfunction	AYCMalfunction	AYCMalfunction		
						0000 declutched at rest 0001 1st range 0010 2nd range 0011 3rd range 0100 4th range 0101 5th range 0110 6th range 0111 7th range 1000 8th range 1001 reverse 1010 neutral or parking 1011 CVT in continuous mode 1100 9th range 1101 10th range 1110 Not used 1111 AT in limphone	TransmRangeEngaged_Current	TransmRangeEngaged_Current		
						0000 warning 0001 1 bargraph element displayed 0010 2 bargraph element displayed 0011 3 bargraph element displayed 0100 4 bargraph element displayed 0101 5 bargraph element displayed 0110 6 bargraph element displayed 0111 7 bargraph element displayed 1000 8 bargraph element displayed 1001 Not used 1010 Not used 1011 Not used 1100 Not used 1101 Not used 1110 Not used 1111 not available	DisplayedOilLevel	DisplayedOilLevel		
						0 Not Locked 1 Locked	CockpitLocked_State	CockpitLocked_State		

						40	0 No VDC (ESC) malfunction 1 VDC (ESC) malfunction	ESCMalfunction	ESCMalfunction		
						42	000 No Request 001 Life on Boost Low SOC power limitation 010 Delivery Mode power limitation 011 Battery Disconnection power limitation 100 Producer failure power limitation 101 Not used 110 Not used 111 Not used	EEM_StaticPowerLimitationRequest	EEM_StaticPowerLimitationRequest		
						43	0 Brake Lamp Off 1 Brake Lamp On	BrakeLampStatus	BrakeLampStatus		
						44	00 Not used 01 Input logical 1 = ON (ground) 10 Input logical 1 = OFF (open circuit) 11 Unavailable	AAM_DigitalInputMonitoring1	DigitalInputMonitoring1		
						45	00 Not used 01 Input logical 2 = ON (ground) 10 Input logical 2 = OFF (open circuit) 11 Unavailable	AAM_DigitalInputMonitoring2	DigitalInputMonitoring2		
						46	00 Not used 01 Input logical 3 = ON (ground) 10 Input logical 3 = OFF (open circuit) 11 Unavailable	AAM_DigitalInputMonitoring3	DigitalInputMonitoring3		
						47	00 Not used 01 Input logical 4 = ON (ground) 10 Input logical 4 = OFF (open circuit) 11 Unavailable	AAM_DigitalInputMonitoring4	DigitalInputMonitoring4		
						48	00 Not used 01 Input logical 5 = ON (ground) 10 Input logical 5 = OFF (open circuit) 11 Unavailable	AAM_DigitalInputMonitoring5	DigitalInputMonitoring5		
						49	0 no Idle Speed Increase activation 1 Idle Speed Increase activation	EngIdleSpeedIncreaseStatus	EngIdleSpeedIncreaseStatus		
						50	0 Stop lamps flashing no requested 1 Stop lamps flashing requested	StopLampFlashingRequest	StopLampFlashingRequest		
						64	0-VDC-available 1-VDC-disabled	VDC_Deactivated	VDC_Deactivated		
						52	0000 Not initialized 0001 Starting sequence 0010 Nominal Mode 0011 Producer power limitation 0100 Producer communication fault is detected 0101 Producer communication fault is confirmed 0110 Producer fault is detected 0111 Producer fault is confirmed 1000 Undervoltage is detected 1001 Undervoltage is confirmed 1010 Overvoltage is detected 1011 Overvoltage is confirmed 1100 CAN fault is detected 1101 CAN fault is confirmed 1110 Not used 1111 Unavailable	VoltageRegulationStatus_V2	VoltageRegulationStatus_V2		
						53	0000 Sleeping 0001 Not used 0010 CutoffPending 0011 AutoACC - BatTempoLevel 0100 Not used 0101 IgnitionLevel 0110 StartingInProgress 0111 PowertrainRunning 1000 AutoStart 1001 EngineSystemStop 1010 Not used 1011 Not used 1100 Not used 1101 Not used 1110 Not used 1111 Unavailable	VehicleStates	VehicleStates (available from SW610, rom CAN_ADAPT_1 message set V3.3)		
						54	0000 Sleeping 0001 Not used 0010 CutoffPending 0011 AutoACC - BatTempoLevel 0100 Not used 0101 IgnitionLevel 0110 StartingInProgress 0111 PowertrainRunning 1000 AutoStart 1001 EngineSystemStop 1010 Not used 1011 Not used 1100 Not used 1101 Not used 1110 Not used 1111 Unavailable	VehicleStates	VehicleStates (available from SW610, rom CAN_ADAPT_1 message set V3.3)		

							55	0000 Sleeping 0001 Not used 0010 CutoffPending 0011 AutoACC - BatTempoLevel 0100 Not used 0101 IgnitionLevel 0110 StartingInProgress 0111 PowertrainRunning 1000 AutoStart 1001 EngineSystemStop 1010 Not used 1011 Not used 1100 Not used 1101 Not used 1110 Not used 1111 Unavailable	VehicleStates	VehicleStates (available from SW610, rom CAN_ADAPT_1 message set V3.3)		
							56	FridgeDrive activated	NA (not on CAN_EXT)	NA (not on CAN_ADAPT_1)		
							57	Battery coupling activated	NA (not on CAN_EXT)	NA (not on CAN_ADAPT_1)		
							58	Footstep activated	NA (not on CAN_EXT)	NA (not on CAN_EXT)	Yes	Yes
							59	Configurable algorithm 1 activated	NA (not on CAN_EXT)	NA (not on CAN_EXT)	Yes	Yes
							66	Configurable algorithm 2 activated	NA (not on CAN_EXT)	NA (not on CAN_EXT)	Yes	Yes
							67	Configurable algorithm 3 activated	NA (not on CAN_EXT)	NA (not on CAN_EXT)	Yes	Yes
							255	Invalid value saída não utilizada, nenhuma atribuição	NA	NA	Yes	Yes

STOP: PARAMETERS AVAILABLE ON: SW311, SW410 or SW610 (SEE COLUMN "AVAILABLE FROM SW")

PARAMETER										RENAULT PLANT	RENAULT AFTER SALES
START: PARAMETERS AVAILABLE ONLY FROM SW311											
SEL_TYPE	This calibration is used to configure the battery Type	01da	decimal	1	0	0	No configuration			Yes	Yes
						1	SEL and				
						2	AKB				
						3	EV2				
TRALER_CF	This calibration is used to activate the trailer feature	01da	boolean	1	0	0	Trailer feature not activated			Yes	Yes
						1	Trailer feature activated				
RALAC_CF	This calibration is used to activate the RALAC feature	01da	boolean	1	0	0	RALAC feature not activated			Yes	Yes
						1	RALAC feature activated				
RALAC_SW_TYPE_CF	This calibration is used to set button type for RALAC	01da	boolean	1	0	0	storable button			Yes	Yes
						1	reconfigurable button (impulse button)				
FRIDGE_WPRN_CF	This calibration is used to activate the Fridge drive feature	01da	boolean	1	0	0	Fridge drive feature not activated			Yes	Yes
						1	Fridge drive feature activated				
FRIDGE_RPM_MIN_CF	This calibration is used to select the minimum engine speed for fridge drive activation	10 rpm	rpm	0,125	0	value * resolution + offset = physical value	Minimum engine speed Valeur basse pour permettre le fonctionnement du compresseur de réfrigération en toute les cases de motor automobiles			Yes	Yes
FRIDGE_RPM_MAX_CF	This calibration is used to select the maximum engine speed for fridge drive activation	10 rpm	rpm	0,125	0	value * resolution + offset = physical value	Maximum engine speed Valeur élevée pour permettre le fonctionnement du compresseur de réfrigération en toute les cases de motor automobiles			Yes	Yes
BAT_STABILIZED_CF	This calibration is used to activate the battery stabilized feature	01da	boolean	1	0	0	Battery stabilized feature not activated			Yes	Yes
						1	Battery stabilized feature activated				
BAT_STABILIZED_MIN_VOLTAGE_CF	This calibration is used to select the minimum voltage for the Battery Stabilized feature	01da	V	0,5	02	value * resolution + offset = physical value	Power set value pour 12,5 V en cas de une batterie de type de fil (fil standard 13,8 V, sans contrôle à batterie de type de fil fixe en automatique)			Yes	Yes
BAT_STABILIZED_VOLTAGE_RATE_CF	This calibration is used to select the voltage rate for the Battery Stabilized feature	01da	decimal	1	0	0	No Request			Yes	Yes
						1	Rate 1 (la correspondance entre le Rate n V/S a été mise à jour de la dernière mise à jour de la batterie)				
						2	Rate 2 (la correspondance entre le Rate n V/S a été mise à jour de la dernière mise à jour de la batterie)				
						3	Rate 3 (la correspondance entre le Rate n V/S a été mise à jour de la dernière mise à jour de la batterie)				
BAT_STABILIZED_SW_TYPE_CF	This calibration is used to set button type for Battery stabilized feature	01da	boolean	1	0	0	storable button			Yes	Yes
						1	reconfigurable button (impulse button)				
BATT_COUPLING_CF	This calibration is used to activate the battery coupling feature	01da	boolean	1	0	0	Battery coupling feature not activated			Yes	Yes
						1	Battery coupling feature activated				
SEL_PWR_LIM_OUT_OFF	This calibration is used to activate to Output power cut off	01da	boolean	1	0	0	Output power cut off not activated			Yes	Yes
						1	Output power cut off activated				
O_PWM_X (X: 1 to 7) 7 parameters	This calibration is used to set the Output PWM X of the P-gate	01da	decimal	1	0	0	No Configuration			Yes	Yes
						1	Unidirectional				
						2	Bidirectional				
						3	Current Compensation				
						4	Current Compensation				
						5	Current Compensation				
						6	Current Compensation				
						7	Current Compensation				
O_LOS_A_power limitation (X: 1 to 10) 10 parameters	This calibration is used to configure the power limitation for Output logical X pin (X: 1 to 10)	01da	boolean	1	0	0	Power limitation on Output logical X pin Power limitation following vehicle power limitation request			Yes	Yes
						1	NO power limitation on Output logical X pin				
O_LOGICAL_X_SWITCH_CONDITION (X: 1 to 10) 10 parameters	This calibration is used to configure the switch condition for the Output logical X pin (X: 1 to 10)	01da	decimal	1	0	0	No switch off			Yes	Yes
						1	Output switched off while engine stopped				
						2	Output switched off while engine starting				
						3	Output switched off while engine stopped & starting				
END: PARAMETERS AVAILABLE ONLY FROM SW311											
START: PARAMETERS AVAILABLE ONLY FROM SW410											
FRIDGE_RPM_HYST_CF	This calibration is used to configure the engine speed hysteresis for fridge drive	01da	%	0,302 = 1000/330	0	value * resolution + offset = physical value	Hysteresis value in % for Minimum & Maximum engine speed Exemple: 300% - 100% 200-100%			Yes	Yes
ENG_RESTART_CF	This calibration is used to activate the engine restart feature	01da	boolean	1	0	0	Engine Restart feature not activated			Yes	Yes
						1	Engine Restart feature activated				
MUTE_CF	This calibration is used to activate or deactivate the radio mute feature	01da	boolean	1	0	0	Mute feature not activated			Yes	Yes
						1	Mute feature activated				
MUTE_SW_TYPE_CF	This calibration is used to set the button type for Radio Mute	01da	boolean	1	0	0	storable button			Yes	Yes
						1	reconfigurable button (impulse button)				
DOOR_MUTE_DRIVER_CF	This calibration is used to enable driver door to mute Radio	11da	boolean	1	0	0	No mute radio when opening a door			Yes	Yes
						1	Mute radio when opening driver door				
DOOR_MUTE_PASSENGER_CF	This calibration is used to enable passenger door to mute Radio	11da	boolean	1	0	0	No mute radio when opening a door			Yes	Yes
						1	Mute radio when opening passenger door				
DOOR_MUTE_REAR_RIGHT_CF	This calibration is used to enable rear right door to mute Radio	11da	boolean	1	0	0	No mute radio when opening a door			Yes	Yes
						1	Mute radio when opening rear right door				
DOOR_MUTE_REAR_LEFT_CF	This calibration is used to enable rear left door to mute Radio	11da	boolean	1	0	0	No mute radio when opening a door			Yes	Yes
						1	Mute radio when opening rear left door				
DOOR_MUTE_TAILGATE_CF	This calibration is used to enable tailgate door to mute Radio	11da	boolean	1	0	0	No mute radio when opening a door			Yes	Yes
						1	Mute radio when opening tailgate door				
PRODUCER_LOAD_LOW_CF	This calibration is used to configure the Low threshold for Producer Load	01da	%	1	0	value * resolution + offset = physical value				Yes	Yes
PRODUCER_LOAD_HIGH_CF	This calibration is used to configure the High threshold for Producer Load	01da	%	1	0	value * resolution + offset = physical value				Yes	Yes
PRODUCER_LOAD_HIGH_DELAY_CF	This calibration is used to configure the Producer Load delay for the High threshold	01da	s	0,02 s	0	value * resolution + offset = physical value				Yes	Yes
O_POWER_CF	This calibration is used to activate the O_POWER output feature	01da	boolean	1	0	0	Output power enable not activated			Yes	Yes
						1	Output power enable activated				
FOOTSTEP_VEH_SPEED_MIN_CF	This calibration is used to configure the minimum speed for footstep activation	10 km/h	km/h	0,01	0	value * resolution + offset = physical value	Do not choose a value = 0 km/h because VSC can not deliver a value = 0 km/h			Yes	Yes
FOOTSTEP_VEH_SPEED_HYST_CF	This calibration is used to configure the hysteresis for footstep activation	10 km/h	km/h	0,01	0	value * resolution + offset = physical value				Yes	Yes
CONFIGURABLE_ALGORITHM_CF VWR1	This calibration is used to define the VWR1 of the Configurable Algorithm	01da	decimal	1	0	See Tab "Configurable Algorithm"	VWR 1 for Configurable Algorithm			Yes	Yes
CONFIGURABLE_ALGORITHM_CF OP1	This calibration is used to define the OP1 of the Configurable Algorithm	01da	decimal	1	0	0	NOOP (no operator OP1)			Yes	Yes
						1	OP1				
						2	OP2				
						3	OP3				
						4	OP4				
						5	OP5				
CONFIGURABLE_ALGORITHM_CF COMB OP	This calibration is used to define the COMB OP of the Configurable Algorithm	01da	decimal	1	0	0	COMBOP 1 AND Condition 1			Yes	Yes
						1	COMBOP 1 AND Condition 2				
						2	COMBOP 1 OR Condition 1				
						3	COMBOP 1 AND Condition 3				
						4	NOT Condition 1 AND Condition 2				
						5	NOT Condition 1 OR Condition 2				
						6	NOT Condition 1 AND Condition 3				
CONFIGURABLE_ALGORITHM_CF VWR2	This calibration is used to define the VWR2 of the Configurable Algorithm	01da	decimal	1	0	See Tab "Configurable Algorithm"	VWR 2 for Configurable Algorithm			Yes	Yes
CONFIGURABLE_ALGORITHM_CF OP2	This calibration is used to define the OP2 of the Configurable Algorithm	01da	decimal	1	0	0	NOOP (no operator OP2)			Yes	Yes
						1	OP1				
						2	OP2				
						3	OP3				
						4	OP4				
						5	OP5				
						6	OP6				
CONFIGURABLE_ALGORITHM_CF VALUE2	This calibration is used to define the VALUE2 of the Configurable Algorithm	32 bits	signed	1	0	VALUE 2 = (logical value 2) * (offset) / resolution	VALUE 2 for Configurable Algorithm			Yes	Yes
CONFIGURABLE_ALGORITHM_CF SAFE_VL	This calibration is used to define the SAFE_VL of the Configurable	01da	boolean	1	0	0	Output logical 1 inactive (open circuit) when powered down and by VSC1 Output not required by VSC1 Use value 0 when not used			Yes	Yes

commentaire 1: MANDON sobre necessidades dos chapéus

	Algorithm					1	Output logical X active (ignores) when: - Request value sent by ECU's - Items not received by ABS - Not calibrated by SW											
													SW400 CAN_EXT PARAMETER	SW400 CAN_ADAPT_1 PARAMETER				
1. ANALOG_X_OP (X: 1 to 3) 3 parameters	This calibration is used to enable/disable the analog data sent on CAN_EXT and/or CAN_ADAPT_1	8 bits	decimal		0	1	data not sent on CAN_EXT and not sent on CAN_ADAPT_1	NA	NA	Yes	Yes							
						1	data sent on CAN_EXT and not sent on CAN_ADAPT_1	ANM_Analogpilotbrake (X: 1 to 3)	NA	AnalogpilotbrakeK (X: 1 to 3)								
						2	data not sent on CAN_EXT and sent on CAN_ADAPT_1	NA	ANM_Analogpilotbrake (X: 1 to 3)									
						3	data sent on CAN_EXT and sent on CAN_ADAPT_1	ANM_Analogpilotbrake (X: 1 to 3)	ANM_Analogpilotbrake (X: 1 to 3)									
1. LOGIC_X_OP (X: 1 to 3) 3 parameters	This calibration is used to enable/disable the logical data sent on CAN_EXT and/or CAN_ADAPT_1	8 bits	decimal		0	1	data not sent on CAN_EXT and not sent on CAN_ADAPT_1	NA	NA	Yes	Yes							
SW400 doesn't exist, HW preinstall only						1	data sent on CAN_EXT and not sent on CAN_ADAPT_1	ANM_Digitalpilotbrake (X: 1 to 3)	NA	DigitalpilotbrakeK (X: 1 to 3)								
						2	data not sent on CAN_EXT and sent on CAN_ADAPT_1	NA	DigitalpilotbrakeK (X: 1 to 3)									
						3	data sent on CAN_EXT and sent on CAN_ADAPT_1	ANM_Digitalpilotbrake (X: 1 to 3)	DigitalpilotbrakeK (X: 1 to 3)									

END: PARAMETERS AVAILABLE ONLY FROM SW410

END: PARAMETERS AVAILABLE ONLY FROM SW410

START: PARAMETERS AVAILABLE ONLY FROM SW610

CONFIGURABLE_ALGORITHM_2_OF_VARI	This calibration is used to define the VARI of the Configurable Algorithm 2	bits	decimal	1	0	See Tab "Configurable Algorithm"	VARI 1 for Configurable Algorithm 2					Yes	Yes
CONFIGURABLE_ALGORITHM_2_OF_OPI	This calibration is used to define the OPI of the Configurable Algorithm 2	bits	decimal	1	0	1	MSP (no operator OPI)					Yes	Yes
						2	"						
						3	"						
						4	"						
						5	"						
						6	"						
CONFIGURABLE_ALGORITHM_2_OF_VALUE1	This calibration is used to define the VALUE1 of the Configurable Algorithm 2	32 bits	signed	1	0	VALUE 1 = (physical value 1 - (offset) / resolution)	VALUE 1 for Configurable Algorithm 2					Yes	Yes
CONFIGURABLE_ALGORITHM_2_OF_COMB_OP	This calibration is used to define the COMB_OP of the Configurable Algorithm 2	bits	decimal	1	0	0	Condition 1 only					Yes	Yes
						1	Condition 1 AND Condition 2						
						2	Condition 1 OR Condition 2						
						3	Condition 1 XOR Condition 2						
						4	NOT Condition 1 AND Condition 2						
						5	NOT Condition 1 OR Condition 2						
CONFIGURABLE_ALGORITHM_2_OF_VARI2	This calibration is used to define the VARI2 of the Configurable Algorithm 2	bits	decimal	1	0	See Tab "Configurable Algorithm"	VARI 2 for Configurable Algorithm 2					Yes	Yes
CONFIGURABLE_ALGORITHM_2_OF_OPI2	This calibration is used to define the OPI2 of the Configurable Algorithm 2	bits	decimal	1	0	1	MSP (no operator OPI2)					Yes	Yes
						2	"						
						3	"						
						4	"						
						5	"						
						6	"						
CONFIGURABLE_ALGORITHM_2_OF_VALUE2	This calibration is used to define the VALUE2 of the Configurable Algorithm 2	32 bits	signed	1	0	VALUE 2 = (physical value 2 - (offset) / resolution)	VALUE 2 for Configurable Algorithm 2					Yes	Yes
CONFIGURABLE_ALGORITHM_2_OF_SAFE_VAL	This calibration is used to define the SAFE_VAL of the Configurable Algorithm 2	bits	boolean	1	0	0	Output logical X inactive (open circuit) when: - Request value sent by ECU's - Items not received by ABS - Not calibrated by SW					Yes	Yes
						1	Output logical X active (ignores) when: - Request value sent by ECU's - Items not received by ABS - Not calibrated by SW						
CONFIGURABLE_ALGORITHM_3_OF_VARI1	This calibration is used to define the VARI1 of the Configurable Algorithm 3	bits	decimal	1	0	See Tab "Configurable Algorithm"	VARI 1 for Configurable Algorithm 3					Yes	Yes
CONFIGURABLE_ALGORITHM_3_OF_OPI1	This calibration is used to define the OPI1 of the Configurable Algorithm 3	bits	decimal	1	0	1	MSP (no operator OPI1)					Yes	Yes
						2	"						
						3	"						
						4	"						
						5	"						
						6	"						
CONFIGURABLE_ALGORITHM_3_OF_VALUE1	This calibration is used to define the VALUE1 of the Configurable Algorithm 3	32 bits	signed	1	0	VALUE 1 = (physical value 1 - (offset) / resolution)	VALUE 1 for Configurable Algorithm 3					Yes	Yes
CONFIGURABLE_ALGORITHM_3_OF_COMB_OP	This calibration is used to define the COMB_OP of the Configurable Algorithm 3	bits	decimal	1	0	0	Condition 1 only					Yes	Yes
						1	Condition 1 AND Condition 2						
						2	Condition 1 OR Condition 2						
						3	Condition 1 XOR Condition 2						
						4	NOT Condition 1 AND Condition 2						
						5	NOT Condition 1 OR Condition 2						
CONFIGURABLE_ALGORITHM_3_OF_VARI2	This calibration is used to define the VARI2 of the Configurable Algorithm 3	bits	decimal	1	0	See Tab "Configurable Algorithm"	VARI 2 for Configurable Algorithm 3					Yes	Yes
CONFIGURABLE_ALGORITHM_3_OF_OPI2	This calibration is used to define the OPI2 of the Configurable Algorithm 3	bits	decimal	1	0	1	MSP (no operator OPI2)					Yes	Yes
						2	"						
						3	"						
						4	"						
						5	"						
						6	"						
CONFIGURABLE_ALGORITHM_3_OF_VALUE2	This calibration is used to define the VALUE2 of the Configurable Algorithm 3	32 bits	signed	1	0	VALUE 2 = (physical value 2 - (offset) / resolution)	VALUE 2 for Configurable Algorithm 3					Yes	Yes
CONFIGURABLE_ALGORITHM_3_OF_SAFE_VAL	This calibration is used to define the SAFE_VAL of the Configurable Algorithm 3	bits	boolean	1	0	0	Output logical X inactive (open circuit) when: - Request value sent by ECU's - Items not received by ABS - Not calibrated by SW					Yes	Yes
						1	Output logical X active (ignores) when: - Request value sent by ECU's - Items not received by ABS - Not calibrated by SW						

END: PARAMETERS AVAILABLE ONLY FROM SW610

START: PARAMETERS AVAILABLE ON: SW311, or SW410, or SW610 (SEE COLUMN "AVAILABLE FROM SW")

						Output Logical X ACTIVE WHEN		SW311 CAN_EXT PARAMETER	SW311 CAN_ADAPT_1 PARAMETER			
0 LOGIC_X (X: 1 to 16) 10 parameters	This calibration is used to set the Output logical X (X is 16) signal	8 bits	decimal	1		0	0 No Configuration	NA	NA	Yes	Yes	
							1	001 Brake pedal not pressed 002 Brake pedal pressed 003 Brake pedal confirmed pressed 004 Unavailable	BrakeVehStatus	BrakeSwitchEngineControl		
							2	0 Compressor clutch off 1 Compressor clutch on	ACCompClutchStatus	ACCompressorAuthorized		
							3	00 Not used 01 Clutch pedal not pressed 02 Clutch pedal pressed at minimum 03 Unavailable	ClutchSwitchMinimumTravel	ClutchSwitch		
								00 Not used 01 Clutch pedal not pressed at maximum 02 Clutch pedal pressed at maximum 03 Unavailable	ClutchSwitchMaximumTravel			
							4	00 Unavailable Value 01 Driver door closed 02 Driver door open 03 Unavailable Value 04 Unavailable Value 05 Passenger door closed 06 Passenger door open 07 Unavailable 08 Not Used	DriverDoorState	DriverDoorState		
								00 Unavailable Value 01 Rear Right door closed 02 Rear Right door open 03 Unavailable Value 04 Unavailable Value 05 Tail Gate door closed 06 Tail Gate door open 07 Unavailable 08 Unavailable Value 09 Rear Left door closed 10 Rear Left door open 11 Not Used	PassengerDoorState	PassengerDoorState		
							4	00 Unavailable Value 01 Rear Right door closed 02 Rear Right door open 03 Unavailable Value 04 Unavailable Value 05 Tail Gate door closed 06 Tail Gate door open 07 Unavailable 08 Unavailable Value 09 Rear Left door closed 10 Rear Left door open 11 Not Used	RearRightDoorState	RearRightDoorState		
								00 Unavailable Value 01 Tail Gate door closed 02 Tail Gate door open 03 Unavailable 04 Unavailable Value 05 Rear Left door closed 06 Rear Left door open 07 Not Used	TailGateStatus	TailGateStatus		
								00 Unavailable Value 01 Rear Left door closed 02 Rear Left door open 03 Not Used	RearLeftDoorState	RearLeftDoorState		
								00 Unavailable Value 01 Not Used				

detecção da iniciativa do condutor de pressionar o travão (contacto de pedal)

Travão e estado ligado do compressor de ar condicionado para os EC

No caso dos EC, permite

Abrir os elementos de ar condicionado adicional apenas se circular fclon

Evitar a abertura de um elemento adicional activado pelo motor se o compressor de ar condicionado do veículo estiver ativado de modo a não consumir demasiado bruto no arranque.

A necessidade de base é poder detectar a atuação do compressor de ar condicionado do veículo de base em EC e EV e não apenas o estado do embraiagem (em EV não existe embraiagem de acionamento, mas sim um motor elétrico)

=> validado em SW300 para o estado ativo ou inativo do ar condicionado (DPC 1.1)

detecção da iniciativa do condutor no início ou no fim da pressão (isto permite traduzir o estado da cabine climatizada)

Para obter um estado desengatado da cabine climatizada, é necessário utilizar um algoritmo conf. (verve máxima = 2)

estado de abertura/fecho e localização de pelo menos 1 porta

Para poder localizar a porta aberta, utilizar um algoritmo conf. (estado da porta considerada = 2)

STOP: PARAMETERS AVAILABLE ON: SW311, SW410 or SW610 (SEE COLUMN "AVAILABLE FROM SW")

Fundamental

Viveiro
vehicule speed sign
PRND em EV?
informações ADAS dissonâncias
Ennece Restart também inicia Stop Auto
XDD Grio Control implica deslizar o controlo da trajectória?
Criar páginas explicativas com diagramas para funções importantes (por exemplo, Battery Coupling, etc.) e transformações do tipo corta-traseira elevatória
Em Res. Eval. avaliar a sustentabilidade das informações do conector e das informações AAM

		ATCU_A0	ATCU_A10	CAN_EXT_TransferRangeRequest_Current	R						0000	Detached at rest
											0001	1st range
											0010	2nd range
											0011	3rd range
											0100	4th range
											0101	5th range
											0110	6th range
											0111	7th range
											1000	8th range
											1001	Reverse
											1010	Neutral or parking
											1011	CVT in cruise mode
											1100	8th range
											1101	9th range
											1110	Not used
											1111	AT in longhorn
XDDP/KNO2PH2	61											
XDDP/KNO2PH2	62	ATCU_A4	ATCU_A10	CAN_EXT_AT_LandStatusDisplayRequest	R						00	Unavailable
XDDP/KNO2PH2	63	ACU_A1	ACU_A101	CAN_EXT_AIRBAGMalfunction	R						01	No warning
											10	AT major failure warning (Level 2)
XDDP/KNO2PH2	64	ACU_A1	ACU_A101	CAN_EXT_PassengerAIRBAG_InhibitionG	R						00	Driver's side airbag
XDDP/KNO2PH2	65	ARM_R2	ARM_R102	I_ANALOG_1_SW	I	ADC	0		1		0	No AIRBAG system malfunction
XDDP/KNO2PH2	66	ARM_R2	ARM_R102	I_ANALOG_2_SW	I	ADC	0		1		0	Passenger AIRBAG not inhibited
XDDP/KNO2PH2	67	ARM_R2	ARM_R102	I_ANALOG_3_SW	I	ADC	0		1		0	Passenger AIRBAG inhibited
XDDP/KNO2PH2	68	ARM_R2	ARM_R102	I_LOGS_1_SW post CAN_1 LOGS_1 SW	Internal						1	correct code x 0.004338851 V
XDDP/KNO2PH2	69	ARM_R2	ARM_R102	I_LOGS_2_SW post CAN_1 LOGS_2 SW	Internal						0	OFF
XDDP/KNO2PH2	70	ARM_R2	ARM_R102	I_LOGS_3_SW post CAN_1 LOGS_3 SW	Internal						1	ON
XDDP/KNO2PH2	71	ARM_R2	ARM_R102	I_LOGS_4_SW post CAN_1 LOGS_4 SW	Internal						0	OFF
XDDP/KNO2PH2	72	ARM_R2	ARM_R102	I_LOGS_5_SW post CAN_1 LOGS_5 SW	Internal						1	ON
XDDP/KNO2PH2	73	ARM_R2	ARM_R102	I_LOGS_6_SW post CAN_1 LOGS_6 SW	Internal						0	OFF
XDDP/KNO2PH2	74	ARM_R2	ARM_R102	I_LOGS_7_SW post CAN_1 LOGS_7 SW	Internal						1	ON
XDDP/KNO2PH2	75	HEVC_R15	HEVC_A103	CAN_EXT_StatusOfConsumer2R_Voltage_v5	R	800			1			
XDDP/KNO2PH2	76	HEVC_R15	HEVC_A104	CAN_EXT_AuxiliaryConsumer2R_V_LatDev	R				0.1			
XDDP/KNO2PH2	77	HEVC_A1	HEVC_A108	CAN_EXT_PChargeStatus	R							
XDDP/KNO2PH2	78	HEVC_A1	HEVC_A113	CAN_EXT_ChargePlugStatus	R							
XDDP/KNO2PH2	79											
XDDP/KNO2PH2	80											
XDDP/KNO2PH2	81	USM_A2	USM_A101	CAN_EXT_BatterVoltage	R	12			0.05	12.5	30	
XDDP/KNO2PH2	82	USM_A2	USM_A103	CAN_EXT_RestartChargeResistance	R	Ohm			1			
XDDP/KNO2PH2	83	USM_A2	USM_A105	CAN_EXT_Bat/Battery	R	%			0.5	80	22	

O_LOGICAL_X_SWITCH_OFF_CONDITION	Output Logical X ATIVO QUANDO estados a azul
0 No switch off	0000 Sleeping 0001 Not used 0010 CutoffPending 0011 AutoACC - BatTempoLevel 0100 Not used 0101 IgnitionLevel 0110 StartingInProgress (durante o arranque do motor) 0111 PowertrainRunning 1000 AutoStart (apenas ICE) 1001 EngineSystemStop (apenas ICE) 1010 Not used 1011 Not used 1100 Not used 1101 Not used 1110 Not used 1111 Unavailable
1 Output switched off while engine stopped	0000 Sleeping 0001 Not used 0010 CutoffPending 0011 AutoACC - BatTempoLevel 0100 Not used 0101 IgnitionLevel 0110 StartingInProgress (durante o arranque do motor) 0111 PowertrainRunning 1000 AutoStart (apenas ICE) 1001 EngineSystemStop (apenas ICE) 1010 Not used 1011 Not used 1100 Not used 1101 Not used 1110 Not used 1111 Unavailable
2 Output switched off while engine starting	0000 Sleeping 0001 Not used 0010 CutoffPending 0011 AutoACC - BatTempoLevel 0100 Not used 0101 IgnitionLevel 0110 StartingInProgress (durante o arranque do motor) 0111 PowertrainRunning 1000 AutoStart (apenas ICE) 1001 EngineSystemStop (apenas ICE) 1010 Not used 1011 Not used 1100 Not used 1101 Not used 1110 Not used 1111 Unavailable

3 Output switched off while engine stopped & starting	0000 Sleeping 0001 Not used 0010 CutoffPending 0011 AutoACC - BatTempoLevel 0100 Not used 0101 IgnitionLevel 0110 StartingInProgress (durante o arranque do motor) 0111 PowertrainRunning 1000 AutoStart (apenas ICE) 1001 EngineSystemStop (apenas ICE) 1010 Not used 1011 Not used 1100 Not used 1101 Not used 1110 Not used 1111 Unavailable
--	--

SW 311	
O_LOG_X_power_limitation	Output Logical X ATIVO QUANDO estados a azul de EEM_StaticPowerLimitationRequest
0 Power limitation on Output logical X pin. Power limitation is following vehicle power limitation request	0 No Request 1 Life on Board Low SOC power limitation 2 Delivery Mode power limitation 3 Battery Disconnection power limitation 4 Producer failure power limitation
1 NO power limitation on Output logical X pin	0 No Request 1 Life on Board Low SOC power limitation 2 Delivery Mode power limitation 3 Battery Disconnection power limitation 4 Producer failure power limitation

SW 400	
O_LOG_X_power_limitation	Output Logical X ATIVO QUANDO estados a azul de EEM_StaticPowerLimitationRequest
0 Power limitation on Output logical X pin. Power limitation is following vehicle power limitation request	0 No Request 1 Life on Board Low SOC power limitation 2 Delivery Mode power limitation 3 Battery Disconnection power limitation 4 Producer failure power limitation
1 NO power limitation on Output logical X pin	0 No Request 1 Life on Board Low SOC power limitation 2 Delivery Mode power limitation 3 Battery Disconnection power limitation 4 Producer failure power limitation

O_LOG_X (X: 1 to 10)

NOME DO ALGORITMO	Apenas ICE	VALOR	Output Logical X ATIVO QUANDO
NoConfiguration		0	Sem configuração
BrakeInfoStatus		1	Pressão no pedal do travão
ACCompClutchStatus		2	Compressor do ar condicionado ligado
ClutchSwitch	X	3	Pedal da embraiagem pressionado ao mínimo ou Pedal da embraiagem pressionado ao máximo
DoorSwitches		4	Porta do Condutor aberta ou Porta do Passageiro aberta ou Porta Traseira Direita aberta ou Porta Traseira Esquerda aberta ou Porta da Bagageira aberta
ElectricalIgnitionState		5	Estados: Ignition ou StartingInProgress ou PowertrainRunning ou AutoStart ou EngineSystemStop
VehicleOutsideLockedState		6	Veículo trancado pelo condutor a partir do exterior
FlashingIndicator_LorR		7	Luz de Direção Direita ou Luz de Direção Esquerda acesa
FlashingIndicator_Warning		8	Luz de Direção Direita e Luz de Direção Esquerda acesas
AutoStart	X	9	Rearranque do motor na saída da fase StopAuto
AIRBAGMalfunction		10	Falha do airbag
RearGearEngaged		11	Marcha-atrás engatada
NeutralContact		12	Posição neutra na alavanca da caixa de velocidades
AT_Level2FailureDisplayRequest		13	Falha da caixa de velocidades automática ou modo de proteção ativado
PositionLightsDisplay		14	Mínimos acesos
HighBeamDisplay		15	Máximos acesos
LowBeamDisplay		16	Médios acesos
FrontFogLightsDisplay		17	Luzes de nevoeiro dianteiras acesas
CruiseControlStatus		18	Limitador ou regulador de velocidade ativo ou em espera
DieselFilterWaterDetection	X	19	Deteção de água no diesel
EngineControlFailureLevel1	X	20	Falha de nível 1 Controlo do motor
EngineControlFailureLevel2	X	21	Falha de nível 2 Controlo do motor
WarningWaterTemp		22	Alerta de temperatura da água
MILLamp		23	Pedido de acendimento MIL lâmpada
ABSinRegulation		24	ABS em regulação
ABSMalfunction		25	Falha do ABS
ASRinRegulation		26	ASR (antipatinagem) em regulação
AYCinRegulation		27	AYC (correção da trajetória) em regulação
MSRinRegulation		28	MSR (correção do binário do motor) em regulação
AYCMalfunction		29	Falha do AYC (correção da trajetória)
TransmRangeEngaged_Current		30	Caixa automática com velocidade (avanço 1 a 10 ou marcha-atrás)
DisplayedOilLevel	X	31	Visualização do nível de combustível (1 a 8 barras)
CockpitLocked_State		32	Veículo trancado
LoadingAreaLocked_State		33	Zona de carga trancada
PowerTrainRunning		34	Motor ligado (não na fase de arranque)
StartingInProgress		35	Motor sob motor de arranque (após arranque do condutor ou saída da fase StopAuto)
IgnitionLevel		36	Veículo no estado IgnitionLevel
AutoACC		37	Veículo no estado Auto ACC
TrailerPresence		38	Atrélado detetado
DriverSafetyBeltFastened		39	Cinto do condutor apertado
ESCMalfunction		40	Falha do VDC (ESC)
StaticPowerLimitationRequest		42	Pedido de limitação de potência da Gestão de Energia
BrakeLampStatus		43	Lâmpada das luzes de stop acesa
DigitalInputMonitoring1		44	Entrada Input logical 1 ativa
DigitalInputMonitoring2		45	Entrada Input logical 2 ativa
DigitalInputMonitoring3		46	Entrada Input logical 3 ativa
DigitalInputMonitoring4		47	Entrada Input logical 4 ativa

DigitalInputMonitoring5		48	Entrada Input logical 5 ativa
EngIdleSpeedIncreaseStatus	X	49	Função Idle Speed Increase ativada
StopLampFlashingRequest		50	Lâmpada das luzes de stop intermitente
VDC_Deactivated		51	VDC (ESP) desativado
VoltageRegulationStatus_V2		52	Produtor de energia em modo nominal
EngineStopped		53	Motor desligado, mas saída desligada de acordo com o pedido de Power Limitation do veículo
EngineStarting		54	Motor sob motor de arranque (após arranque do condutor ou saída da fase StopAuto), mas saída desligada de acordo com o pedido de Power Limitation do veículo
EngineStopped Or Starting		55	Motor desligado ou sob motor de arranque, mas saída desligada de acordo com o pedido de Power Limitation do veículo
FridgeDrive	X	56	Função Fridge Drive ativada
BatteryCoupling		57	Função Battery Coupling ativada
Footstep activated		58	Função Foot Step ativada
Configurable algorithm 1 activated		59	Função Configurable algorithm 1 ativada
Configurable algorithm 2 activated		66	Função Configurable algorithm 2 ativada
Configurable algorithm 3 activated		67	Função Configurable algorithm 3 ativada
INVALID VALUE		255	Saída Output logical X (X: 1 a 10) não utilizada, nenhuma atribuição

PARÂMETRO	SW MIN.	FUNCIONALIDADE	Apenas ICE	NÚMERO DA FUNÇÃO	FUNÇÃO
VH_TYPE	SW 311	Configuração do tipo de veículo (X82 P2, XFK, XDD)		1	Gateway
TRAILER_CF	SW 311	Ativação (sim/não) da função Trailer Lighting		17	Trailer Lighting
RALAC_CF	SW 311	Ativação (sim/não) da função Idle Speed Increase	X	8	Idle Speed Increase
RALAC_SW_TYPE_CF	SW 311	Configuração do tipo de botão (biestável/impulsional) da entrada Idle Speed Increase (Input logical 1)	X	8	Idle Speed Increase
FRIDGE_DRIVE_CF	SW 311	Ativação (sim/não) da função Fridge Drive	X	15	Fridge Drive
FRIDGE_RPM_MIN_CF	SW 311	Configuração do valor do limiar FRIDGE_RPM_MIN da função Fridge Drive	X	15	Fridge Drive
FRIDGE_RPM_MAX_CF	SW 311	Configuração do valor do limiar FRIDGE_RPM_MAX da função Fridge Drive	X	15	Fridge Drive
BAT_STABILIZED_CF	SW 311	Ativação (sim/não) da função Stabilized Battery		10	Stabilized Battery
BAT_STABILIZED_MIN_VOLTAGE_CF	SW 311	Configuração do valor de BAT_STABILIZED_MIN_VOLTAGE da função Stabilized Battery		10	Stabilized Battery
BAT_STABILIZED_VOLTAGE_RATE_CF	SW 311	Configuração do valor de BAT_STABILIZED_VOLTAGE_RATE da função Stabilized Battery		10	Stabilized Battery
BAT_STABILIZED_SW_TYPE_CF	SW 311	Configuração do tipo de botão (biestável/impulsional) da entrada Stabilized Battery (Input logical 4)		10	Stabilized Battery
BATT_COUPLING_CF	SW 311	Ativação (sim/não) da função Battery Coupling		12	Battery Coupling
SEL_PWR_LIM_CUT_OFF	SW 311	Ativação (sim/não) da função Output power cut off		13	Output power cut off
O_PWM_X (X: 1 to 7) 7 parameters	SW 311	Seleção do parâmetro CAN_EXT de saída em Output PWM X (X: 1 a 7)		6	Output PWM
O_LOG_X_power_limitation (X: 1 to 10) 10 parameters	SW 311	Configuração da prioridade (sim/não) da saída Output logical X (X: 1 a 10)		5	Output logical power limitation
O_LOGICAL_X_SWITCH_OFF_CONDITION (X: 1 to 10) 10 parameters	SW 311	Configuração das condições de corte (motor parado, motor sob motor de arranque) da saída Output logical X (X: 1 a 10)		5	Output logical power limitation
O_LOG_X (X: 1 to 10) 10 parameters	SW 311	Configuração do algoritmo utilizado na saída Output logical X		4	Output logical
FRIDGE_RPM_HYST_CF	SW400	Configuração do valor de FRIDGE_RPM_HYST da função Fridge Drive	X	15	Fridge Drive
ENG_RESTART_CF	SW400	Ativação (sim/não) da função Engine Restart	X	9	Engine Restart
MUTE_CF	SW400	Ativação (sim/não) da função Radio Mute		11	Radio Mute
MUTE_SW_TYPE_CF	SW400	Configuração do tipo de botão (biestável/impulsional) da entrada Radio Mute (Input logical 3)		11	Radio Mute
DOOR_MUTE_DRIVER_CF	SW400	Configuração de Radio Mute na abertura da porta do condutor		11	Radio Mute
DOOR_MUTE_PASSENGER_CF	SW400	Configuração de Radio Mute na abertura da porta do passageiro		11	Radio Mute
DOOR_MUTE_REAR_RIGHT_CF	SW400	Configuração de Radio Mute na abertura da porta traseira direita		11	Radio Mute
DOOR_MUTE_REAR_LEFT_CF	SW400	Configuração de Radio Mute na abertura da porta traseira esquerda		11	Radio Mute
DOOR_MUTE_TAILGATE_CF	SW400	Configuração de Radio Mute na abertura da porta da bagageira		11	Radio Mute
PRODUCER_LOAD_LOW_CF	SW400	Configuração do valor de PRODUCER_LOAD_LOW da função Output power cut off		13	Output power cut off
PRODUCER_LOAD_HIGH_CF	SW400	Configuração do valor de PRODUCER_LOAD_HIGH da função Output power cut off		13	Output power cut off
PRODUCER_LOAD_HIGH_DELAY_CF	SW400	Configuração do valor de PRODUCER_LOAD_HIGH_DELAY da função Output power cut off		13	Output power cut off
O_POWER_CF	SW400	Ativação (sim/não) da função Output power		19	Output power
FOOTSTEP_VEH_SPEED_MIN_CF	SW400	Configuração do valor de FOOTSTEP_VEH_SPEED_MIN da função Foot Step		20	Footstep
FOOTSTEP_VEH_SPEED_HYST_CF	SW400	Configuração do valor de FOOTSTEP_VEH_SPEED_HYST da função Foot Step		20	Footstep
CONFIGURABLE_ALGORITHM_CF.VAR1	SW400	Configuração do valor de VAR1 da função Configurable Algorithm		21	Configurable Algorithm

CONFIGURABLE_ALGORITHM_CF.OP1	SW400	Configuração do valor de OP1 da função Configurable Algorithm	21	Configurable Algorithm
CONFIGURABLE_ALGORITHM_CF.VALUE1	SW400	Configuração do valor de VALUE1 da função Configurable Algorithm	21	Configurable Algorithm
CONFIGURABLE_ALGORITHM_CF.COMB OP	SW400	Configuração do valor de COMB OP da função Configurable Algorithm	21	Configurable Algorithm
CONFIGURABLE_ALGORITHM_CF.VAR2	SW400	Configuração do valor de VAR2 da função Configurable Algorithm	21	Configurable Algorithm
CONFIGURABLE_ALGORITHM_CF.OP2	SW400	Configuração do valor de OP2 da função Configurable Algorithm	21	Configurable Algorithm
CONFIGURABLE_ALGORITHM_CF.VALUE2	SW400	Configuração do valor de VALUE2 da função Configurable Algorithm	21	Configurable Algorithm
CONFIGURABLE_ALGORITHM_CF.SAFE_VAL	SW400	Configuração do valor de SAFE VAL da função Configurable Algorithm	21	Configurable Algorithm
I_ANALOG_X_CF (X: 1 to 3), 3 parameters	SW400	Configuração do envio de Input analog X (X: 1 a 3) em CAN_EXT e/ou CAN_ADAPT_1	2	Input analog
I_LOG_X_CF (X: 1 to 5), 5 parameters. X=6, X=7: doesn't exist, HW predisposal only	SW400	Configuração do envio de Input logical X (X: 1 a 5) em CAN_EXT e/ou CAN_ADAPT_1	3	Input logical
CONFIGURABLE_ALGORITHM_2_CF.VAR1	SW610	Configuração do valor de VAR1 da função Configurable Algorithm 2	22	Configurable Algorithm 2
CONFIGURABLE_ALGORITHM_2_CF.OP1	SW610	Configuração do valor de OP1 da função Configurable Algorithm 2	22	Configurable Algorithm 2
CONFIGURABLE_ALGORITHM_2_CF.VALUE1	SW610	Configuração do valor de VALUE1 da função Configurable Algorithm 2	22	Configurable Algorithm 2
CONFIGURABLE_ALGORITHM_2_CF.COMB OP	SW610	Configuração do valor de COMB OP da função Configurable Algorithm 2	22	Configurable Algorithm 2
CONFIGURABLE_ALGORITHM_2_CF.VAR2	SW610	Configuração do valor de VAR2 da função Configurable Algorithm 2	22	Configurable Algorithm 2
CONFIGURABLE_ALGORITHM_2_CF.OP2	SW610	Configuração do valor de OP2 da função Configurable Algorithm 2	22	Configurable Algorithm 2
CONFIGURABLE_ALGORITHM_2_CF.VALUE2	SW610	Configuração do valor de VALUE2 da função Configurable Algorithm 2	22	Configurable Algorithm 2
CONFIGURABLE_ALGORITHM_2_CF.SAFE_VAL	SW610	Configuração do valor de SAFE VAL da função Configurable Algorithm 2	22	Configurable Algorithm 2
CONFIGURABLE_ALGORITHM_3_CF.VAR1	SW610	Configuração do valor de VAR1 da função Configurable Algorithm 3	23	Configurable Algorithm 3
CONFIGURABLE_ALGORITHM_3_CF.OP1	SW610	Configuração do valor de OP1 da função Configurable Algorithm 3	23	Configurable Algorithm 3
CONFIGURABLE_ALGORITHM_3_CF.VALUE1	SW610	Configuração do valor de VALUE1 da função Configurable Algorithm 3	23	Configurable Algorithm 3
CONFIGURABLE_ALGORITHM_3_CF.COMB OP	SW610	Configuração do valor de COMB OP da função Configurable Algorithm 3	23	Configurable Algorithm 3
CONFIGURABLE_ALGORITHM_3_CF.VAR2	SW610	Configuração do valor de VAR2 da função Configurable Algorithm 3	23	Configurable Algorithm 3
CONFIGURABLE_ALGORITHM_3_CF.OP2	SW610	Configuração do valor de OP2 da função Configurable Algorithm 3	23	Configurable Algorithm 3
CONFIGURABLE_ALGORITHM_3_CF.VALUE2	SW610	Configuração do valor de VALUE2 da função Configurable Algorithm 3	23	Configurable Algorithm 3
CONFIGURABLE_ALGORITHM_3_CF.SAFE_VAL	SW610	Configuração do valor de SAFE VAL da função Configurable Algorithm 3	23	Configurable Algorithm 3