

OVEN SPEED REFERENCE

Daily checks and settings to review when changing oven belt and hopper speeds

DAILY CHECKS
Read before speed changes

DAILY CHECKS TO REMEMBER

- Pre-heat the oven before production setup begins.
- Start Transport, Cooling, and Heating.
- Wait until B3 / Burner 3 Actual Power is under 50% before starting production.
- Confirm the tunnel belt speed matches the current phase below.
- Confirm both hopper spreaders are set to the correct matching speed.
- Do not allow the oven temperature to exceed 150 C at any time.

BELT AND HOPPER SPEED SETTINGS

PHASE	WHEN TO USE	TUNNEL BELT SPEED	HOPPER SPREADER SPEED
Granola transition phase Conveyor integration	Use when moving into production or after a tunnel belt delay.	14.5 Hz	5.3 Hz / 5.3 Hz
10-minute refinement settings	Use after the 10-minute point.	16 Hz	6.5 Hz / 6.5 Hz
Advanced 20-minute settings	Use after the 20-minute point.	17.2 Hz	7.7 Hz / 7.7 Hz

TUNNEL BELT DELAY

If any interval on the tunnel belt exceeds 5 minutes, revert to the Granola Transition Phase settings:

Tunnel belt speed **14.5 Hz**
Hopper spreader speed **5.3 Hz / 5.3 Hz**

TEMPERATURE LIMIT

Maximum oven temperature at any time:

150 C