

Oven Belt and Hopper Speed Guide

Quick daily reference for changing tunnel belt and hopper spreader speeds.

SPEED SETTINGS

PHASE	WHEN TO USE	TUNNEL BELT	HOPPER SPREADER
Granola Transition Phase Conveyor integration	Use when moving into production or after a tunnel belt delay.	14.5 Hz	5.3 Hz / 5.3 Hz
10-Minute Refinement	Use after the 10-minute point.	16 Hz	6.5 Hz / 6.5 Hz
Advanced 20-Minute Settings	Use after the 20-minute point.	17.2 Hz	7.7 Hz / 7.7 Hz

Hopper spreader values show left and right side settings.

TUNNEL BELT DELAY

If any interval on the tunnel belt exceeds 5 minutes, revert to the Granola Transition Phase settings.

Tunnel belt: 14.5 Hz

Hopper spreader: 5.3 Hz / 5.3 Hz

Maximum oven temperature at any time:

150 C

DAILY CHECKS TO REMEMBER

- ☐ Pre-heat the oven before production setup begins.
- ☐ Start Transport, Cooling, and Heating.
- ☐ Wait until B3 / Burner 3 Actual Power is under 50% before starting production.
- ☐ Confirm the tunnel belt speed matches the current phase.
- ☐ Confirm both hopper spreaders are set to the matching speed.
- ☐ Keep the oven temperature at or below 150 C.

Oven speed reference - read before changing tunnel belt or hopper spreader speeds.