

utfcode
utf8.sty 3.10 UTF-8 input encoding 13.06.2000
scanner for code UTF-8 installed.

OmniTech Retail Solutions

Flagship Laptop Pro X15 System Specifications & Hardware Guide

Version 1.2 — Effective Date: January 10, 2026 — Document Reference: DOC-07-PX15

1 1. Technical Specifications and Hardware Architecture

The Flagship Laptop Pro X15 is an enterprise-grade high-performance notebook engineered for intensive computing, deep learning inference, and digital media production.

1.1 1.1 Core Hardware Component Matrix

- Central Processing Unit (CPU):** Intel Core i7-13700H (14 Cores, 20 Threads, up to 5.0 GHz Turbo).
- Graphics Processing Unit (GPU):** NVIDIA GeForce RTX 4060 Laptop GPU with 8GB GDDR6 VRAM (120W Max TGP).
- System Memory & Storage:** 32GB DDR5 5200MHz RAM (Dual-channel, expandable to 64GB); 1TB PCIe 4.0 NVMe M.2 SSD.
- Display Panel:** 15.6-inch OLED QHD+ (2560x1600), 120Hz refresh rate, 100% DCI-P3 color gamut, 500 nits peak brightness.

1.2 1.2 Input/Output (I/O) Port Layout

- Left Side:** 1x Thunderbolt 4 (USB Type-C with Power Delivery 3.0), 1x USB 3.2 Gen 2 Type-A, 3.5mm Combo Audio Jack.
- Right Side:** 1x Thunderbolt 4, 1x Full-size SD Express Card Reader, Hardware Factory Reset Pinhole.
- Rear Side:** 1x HDMI 2.1 (supports 4K@120Hz / 8K@60Hz), Dedicated DC-in Power Connector.

Table 7.1: Power Profiles and Thermal Budgets

Thermal Profile	CPU Target Power	GPU Target Power	Fan Noise Level
Silent Mode (Fn+Q)	25W	35W	< 30 dB (Whisper Quiet)
Balanced Mode (Fn+Q)	45W	80W	38–42 dB (Dynamic)
Performance Mode (Fn+Q)	75W	120W Max	Up to 52 dB (Maximum Boost)

2 2. Operation, Maintenance, and Hard Reset Procedures

2.1 2.1 Thermal Profile Switching

Users can dynamically adjust system thermal thresholds and power delivery limits using the hotkey shortcut **Fn + Q**:

1. **Silent Mode:** Limits total system acoustic output; optimizes battery longevity during productivity tasks.
2. **Balanced Mode:** Factory default setting; uses AI algorithms to balance frame rates and surface temperatures.
3. **Performance Mode:** Requires the 230W AC adapter to be connected. Unlocks full GPU Dynamic Boost.

2.2 2.2 Hardware Factory Reset and Recovery Protocol

If the device experiences system instability, boot loops, or corrupted firmware profiles, execute the following physical reset procedure:

- Power down the laptop completely and disconnect all external peripherals and the AC power cable.
- Locate the small **Hardware Factory Reset Pinhole** situated on the right flank adjacent to the SD card slot.
- Insert a paperclip or SIM ejector pin into the pinhole button and depress firmly for **10 consecutive seconds**.
- Release the button, reattach the AC adapter, and power on the system to launch the BIOS recovery menu.

— End of Document DOC-07-PX15 —