

utfcode
utf8.sty 3.10 UTF-8 input encoding 13.06.2000
scanner for code UTF-8 installed.

OmniTech Retail Solutions

UltraSound Wireless ANC Headphones Setup & Diagnostic Guide

Version 2.0 — Effective Date: February 1, 2026 — Document Reference: DOC-08-ANC

11. Wireless Pairing and Multi-Device Connectivity

The UltraSound Wireless Active Noise Canceling (ANC) Headphones feature Bluetooth 5.3 architecture with multipoint capability.

1.11.1 Bluetooth 5.3 Multipoint Pairing Sequence

- **Initial Power On:** Press and hold the primary Power button for 3 seconds. The LED indicator will flash blue, entering discovery mode.
- **Multipoint Setup:** To connect a secondary device (e.g., laptop while connected to smart-phone), press and hold the Power button for **5 seconds** until the LED flashes red and blue alternately.
- **Supported Audio Codecs:** Sony LDAC (High-Resolution 990kbps), AAC (Apple iOS native), and SBC baseline.

1.21.2 Active Noise Cancellation Modes

Toggle through acoustic profiles using the dedicated ANC button on the left ear cup:

1. **ANC Max Mode:** Hybrid feedforward + feedback microphones active for isolation up to -38dB.
2. **Transparency Mode:** External voice pass-through using ambient microphone arrays.
3. **Off Mode:** Standard passive physical isolation.

Table 8.1: LED Diagnostics and Battery Status

LED Flash Pattern	Battery Level	System State
Solid Green	80% – 100%	Fully charged / Normal operation.
Flashing Amber	20% – 79%	Moderate battery balance remaining.
Flashing Red	< 10%	Low battery threshold; recharge required.
Alternating Red / Blue	N/A	Active Bluetooth pairing discovery mode.

2 2. Battery Diagnostics and Factory Reset Protocol

2.1 2.1 Battery Maintenance and Fast-Charging Specs

The device includes a 750mAh lithium-polymer battery unit offering up to 40 hours of continuous playback (ANC Off):

- **Fast Charge Feature:** A 10-minute USB-C charge provides up to 4 hours of playback time.
- **Power Adapter Specs:** Requires standard 5V, 1A USB charger (avoid high-voltage laptop chargers above 45W to prevent thermal throttling).

2.2 2.2 Hardware Factory Reset Sequence

If the headphones exhibit audio latency, unresponsiveness, or fail to connect to paired devices:

- Disconnect the USB-C charging cable from the headset.
- Press and hold both the **ANC Button** and **Volume Up (+) Button** simultaneously for **8 seconds**.
- The LED indicator will flash red three times rapidly, signaling that all paired device memories have been cleared and factory settings restored.

— End of Document DOC-08-ANC —