Korg Volca Keys MIDI channel...

Marketing (

Misc

Music

/ News / Music /



Korg Volca Keys MIDI channel and global settings

Published: Mon 24 January 2022

<u>Updated: Mon 24 January 2022 by Ludo In Music</u>

tags: volca keys korg synthesizer

Change the MIDI channel of your Volca Keys, this great little analog synth? You did it a few months ago, but you don't remember where it is, and the manual is not really clear. Well, you're in luck, here you'll quickly find the main parameters hidden in your Volca Keys:)

How to set the MIDI channel?

By default it listens on MIDI channel 1, so you really need **change the MIDI channel of your Volca Keys** if you have more than one synth in your synth setup. Note that this trick works with Volca Bass, Volca Drum, Volca Samples etc.

Let's go:

- 1. While holding down the **MEMORY button**, turn your Volca on
- 2. Keyboard keys 1 to 16 correspond to the **MIDI channels 1 to 16**. Press the **one of keys** to set the desired channel, and the LED below the keyboard will light up.



How to change global parameters of your Volca Keys?

In the global Volca keys parameters, you'll find a few useful settings related to MIDI clock sync, tempo range,



Share me!



Last articles:

- FREE MIDI Chords packs!
- My ultimate custom MIDI filter and USB host controller
- <u>Arturia Minifreak presets</u> and samples
- MIDI Sysex information for the Verselab MV-1
- Ableton Live and Launchpad Visual
 Metronome

RSS 2.0 Feed

1 of 3 01/09/2023, 14:15

and MIDI ShortMessage, which allow you to tweak the sound engine via MIDI CC messages.

To access global settings:

- 1. Turn On your Volca Keys, while holding down FUNC button,
- 2. Use the keyboard keys 1 to 7, to set your preferences for any or all of the global parameters. (Refer to the table below)
- 3. When you have finished, press the \bigcirc (REC) button. Your settings will be saved, and the volca keys will restart. To cancel any changes, press the ▶(PLAY) button.

Button	Parameter	LED lit up	LED unlit
1	Auto power-off function	*Enabled	Disabled
2	Battery type selection	Nickel-metal	*Alkaline
3	Sync Out polarity	Fall SyncOut Lo	*Rise SyncOut HI
4	Sync In polarity	Fall SyncIn Lo	*Rise SyncIn HI
5	Tempo range	Full (10-600)	*Narrow (56-240)
6	MIDI Clock Source	*Auto	Internal clock
7	MIDI RX ShortMessage	*0n	Off

^{*:} Factory default setting

How to check the firmware version on your Volca Keys?

If you want to **check the firmware version**, turn the Power ON while pressing the **REC button**.

How to reset your Volca Keys?

To restore all Volca Keys sound programs and sequence data:

- 1. While holding down the **FUNC and MEMORY buttons**, turn the VolcaKeys on
- 2. The (REC) and (PLAY) buttons will blink
- 3. Press the (REC) button to restore the factory defaults
- 4. Or Press the (PLAY) button to cancel the reset operation and simply start Volca Keys

If you've found more MIDI tricks for your Korg Volca Keys, please comment below 🤨




LD. --

Similar posts for you:

- Korg Volca FM global settings and MIDI channel
- Korg Volca FM firmware upgrade in 5 minutes
- Convert your Korg Prologue patches to the Minilogue XD
- Minilogue XD presets and samples

2 of 3 01/09/2023, 14:15



All pages and graphics are copyrighted. copyright © 1998-2022 <u>Ludovic Drolez</u> | Design based on: <u>HTML5 UP</u>

3 of 3 01/09/2023, 14:15