X16 (Yellow) 26-pin X16 Connector – Rear of A2w instrument cluster 20–1 01 –1

Pin	Туре	Description	Connection	Signal Type	Pin (High)
Pin 1	Α	TxD Diagnostic Line	Diagnostic Connector, Diagnostic Module	Square-Wave Analog	X17/14
Pin 2	Е	ABS Indicator Lamp	ABS Control Unit B-		X16/20
Pin 3	А	Brake Fluid Level	Brake Fluid Level Switch B-		X16/15
Pin 4	Е	Coolant Temperature Sensor	Remote Thermometer Sensor	B-	X16/26
Pin 5	А	Oil Pressure Signal	Oil Pressure Switch	B-	X16/6
Pin 6		NOT_USED	NOT_USED		
Pin 7	Е	Preheating, Diesel	DDE Control Unit		X16/8
Pin 8		SIA (Service Light) Reset	Diagnostic Connector, Diag Socket Pin 7	B-	X16/16
Pin 9		Charge Indicator Lamp, Terminal 61	Unloader Relay		X16/5
Pin 10	Е	Start Clear Diesel	DDE Control Unit		
Pin 11		NOT_USED	NOT_USED		
Pin 12	Е	RxD Diagnosis Line	Diagnostic Connector, Diag Socket Pin 15	Square-Wave Analog	X17/2
Pin 13	Е	NOT_USED	NOT_USED		
Pin 14	А	Airbag Lamp Indicator	Airbag Diagnostic Module	B-	X16/1
Pin 15	Α	Ignition Lock	Ignition Switch		N/A
Pin 16	Α	Fuse, Terminal 15, Ignition	Fuse B+		X16/7
Pin 17	Α	Terminal R for Airbag Indicator Lamp	Ignition Switch	B+	X16/21
Pin 18	Α	Ground Connection	Ground Connection B-		X17/1 X17/13
Pin 19		NOT_USED	NOT_USED		
Pin 20	Α	TI (DME Control Unit) Signal	DME/DDE Control Unit	Square-Wave Analog	X16/17
Pin 21	Е	Fuse, Terminal 30	Fuse	B+	X16/12 X16/13
Pin 22	Е	Fuse, Terminal R, Accessories Wire (ACC)	Fuse	B+	X17/3 X17/15
Pin 23	Α	Main Beam Indicator Lamp	Direction Switch	B+	X16/22
Pin 24	Α	Turn Signal Indicator Lamp	Hazard Warning Relay	B+	X16/11
Pin 25	Α	Fuse, Terminal 15, Ignition	Fuse	B+	
Pin 26	Е	TD Signal	DME/DDE Control Unit	Square-Wave Analog	X16/18

Pin Types

TYPE DESCRIPTION E Input A Output M Ground

Abbreviation

Symbol	Description		
ABS	Assisted Breaking System		
SIA	Service Lights Indicator		
TI	Injection Signal		
TD	Engine Speed Signal		
cc	Check-Control		
ССМ	Check-Control Module		
LKM	Lamp Control Module		
АНМ	Trailer Module		
ASC	Automatic Stability Control		
EGS	Electronic Transmission Control		
К	Instrument Cluster		
KVA	Fuel Consumption Indicator		
TQ	Injection Quantity Diesel		

Author / Creator

Nickname	0xduraki
Blog	https://duraki.github.io
Notes	https://notes.durakiconsulting.com
Email	hello[at] <u>durakiconsulting.com</u>
Instagram	<u>@e34.brt</u>

X13060 (Blue) 26-pin

	X13060 Connector - Rear of HZw instrument cluster 20-1 10-4										
Pin		Description	Connection	Signal Type	Color	Pin (High)					
Pin 1	E	Instrument Cluster Lights	Light Switch, Dimmer	Pulses		X502/14					
Pin 2	E	Engie/Vehicle Speed Input (-), Position Pulse	Rear Axle reed contact, Speed Sensor	B-	Brown	X271/10					
Pin 3	E	Fuel Level Warning Light	Fuel Level Sending Unit, Fuel Sensor	B-		X271/2					
Pin 4		NOT_USED	NOT_USED		NOT_USED						
Pin 5	Α	Position Pulse DWA	DWA Module								
Pin 6		NOT_USED	NOT_USED		NOT_USED						
Pin 7	E	Indicator Lamp, Rear Fog Lights	Fog Light Switch	B+		X502/15					
Pin 8	E	Indicator Lamp, Front Fog Lights	Fog Light Switch	B+		X502/1					
Pin 9	E	Brake Pad Sensor Input	Front Break-pad Sensor	Approx. 12V		X16/25	Front and Rear sensors are interconnected				
Pin 10	Α	Ground Break Pad Sensor	Rear Break-pad Sensor	Ground		X16/10	Front and Rear sensors are interconnected				
Pin 11	М	Ground	Ground Connection	B-		X16/24					
Pin 12	Α	Speedometer (Speed Signal), Tacho A Signal, Output	Control Units, Control Module	Square-Wave Analog	Black/White	X502/18	Attach Device here to get Speed Value				
Pin 13	Α	Engine/Vehicle Speed Input (+), Position Pulse	Read Axle reed contact, Speed Sensor	Square-Wave 0-12V	Brown/Red	X271/8	Vehicle Speed				
Pin 14	E	Fuel Level Signal	Fuel level Sending Unit, Fuel Sensor	B-		X271/4	Lamp Light is controlled via electronics.				
Pin 15	E	Connecting Line	Instrument Cluster								
Pin 16		NOT_USED	NOT_USED		NOT_USED						
Pin 17		NOT_USED	NOT_USED		NOT_USED						
Pin 18		NOT_USED	NOT_USED		NOT_USED						
Pin 19	E	Right Turn Signal Indicator	Hazard Warning Relay	B+		X502/26					
Pin 20	E	Left Turn Signal Indicator	Hazard Warning Relay	B+		X502/25					
Pin 21		NOT_USED	NOT_USED		NOT_USED						
Pin 22		NOT_USED	NOT_USED		NOT_USED						
Pin 23		NOT_USED	NOT_USED		NOT_USED						
Pin 24	E	Handbrake Indicator Lamp	Handbrake Switch, Parking Brake Sensor	B-		X271/7					
Pin 25		NOT_USED	NOT_USED		NOT_USED						
Pin 26	Α	Gong Signal, Sound Tone Signal, Output	Gong, Acoustic Generator	B-		X502/2					