

WASM

Assembler/Disassembler
For Wang Programmable Calculators
October 20, 2023

Table of Contents

INTRODUCTION.....	1
ASSEMBLER.....	1
DISASSEMBLER.....	2
COMMAND LINE.....	2
OPERAND FORMATS.....	3
ALPHA.....	3
REGISTER DIRECT.....	3
PRINT / WRITE.....	3
MARK / SEARCH.....	4
ASSEMBLER ERRORS.....	4
EXAMPLES.....	4

INTRODUCTION

‘wasm’ is an Assembler and Disassembler for Wang 600/700 Programmable Calculators. It recognizes, but does not require, certain file type suffixes. Any suffix of the form “.w6x” (where ‘x’ is any letter) indicates Wang 600 code. Similarly, any suffix like “.w7x” indicates Wang 700 code. A suffix with the last letter ‘t’ is recognized as a tape image, which has additional codes to handle the end of the image.

ASSEMBLER

The assembler converts opcodes (and operands where appropriate) into instruction codes. Comments begin with a semicolon character and extend for the rest of the current line.

The special pseudo-op “ENTER” is used to make entering numbers easier. The operand for “ENTER” is a string of decimal digits with optional ‘E’, ‘-’, and ‘.’ characters. This string represents the sequence of keystrokes to enter the number, and NOT a standard number. In many cases the string representation will be the same as the number, but it need not be. For example, “1.1-”, “-1.1”, “1.-1” all represent the number -1.1.

The pseudo-op “.REG” may be used to insert register data into a program, as well as assign a symbolic name for that register to be used in direct register instructions. If no data is provided, 0’s are inserted. A label may be referenced in direct register instructions by prefixing with a ‘&’. Data may be specified as a hexadecimal string in double-quotes, in which case each digit of the register is populated with the value of the corresponding hex digit, with the left-most digit representing the mantissa sign nibble of the register. Otherwise, a floating-point number may be given, using scientific notation if desired. If the machine stores two registers per block of program steps (Wang 700), then two labels and two data

fields may be specified, separated by a comma. The first applies to the lowest (even) numbered register of the pair. Labels and data are not case-sensitive.

The pseudo-op “.OUT” may be used to define the output device for ALPHA text. Values are the model number of the output device, prefixed with a ‘W’. For example, “W612” is the flatbed plotter for the Wang 600. The default is the 701/601 Output Writer. All ALPHA text sequences that follow (until the next “.OUT”) are interpreted using the character set for the specified device.

Errors in assembly are noted by a letter in the first column of the listing output. The lines containing errors are also sent to stderr in the case that no listing is being printed to stdout. The error letters and their meanings are in the “ASSEMBLER ERRORS” section.

DISASSEMBLER

The disassembler may be used to convert program or tape images into source code, allowing existing programs saved from a Wang Programmable Calculator Simulator to be turned into source code, or simply viewed (listed) in a symbolic form.

The disassembler looks for sequences of number entry commands and combines those into a single “ENTER” pseudo-op. It also converts ALPHA text sequences into more-natural strings.

COMMAND LINE

The following command line options are used to control the behavior of ‘wasm’:

600

Use Wang 600 instruction codes and mnemonics. Also allows 601, 602, 611, 612, 607, or 606 to specify the default output device.

700

Use Wang 700 instruction codes and mnemonics. Also allows 701, 702, 711, 712, 707, or 706 to specify the default output device.

docs

Do not assemble/disassemble, only print a list of codes and mnemonics for the specified machine type.

tape

Treat image file (input or output) as a cassette tape image, adding extra codes to mark the end of the image. Each End Program (END) code will appear as two successive END codes, and the end of a data image will have END followed by 15-15.

asm=*file*

Assemble *file* using the (implied or specified) machine type mnemonics and syntax. By default, a listing is produced on stdout and the object code is written to a file named “a.out”.

nolst

Do not produce any assembly listing.

list=file

Produce an assembly listing written to *file*, instead of sending to stdout.

out=file

Write assembled object code (or tape image) to *file*, instead of “a.out”. Or write disassembly output to *file* instead of stdout.

dis=file

Disassemble the program image *file* and send to stdout. By default, this produces a listing-style output (containing step numbers and object code).

raw

The disassembly output is source code, not listing. This code should be ready for re-assembly.

Note that it does not make sense to specify both “dis=” and “asm=” in the same command. If both are specified, “asm=” will be ignored.

OPERAND FORMATS

ALPHA

The “ALPHA” mnemonic, which represents the “α” key on the Wang 600 or the “WRITE ALPHA” key on the Wang 700, takes an operand that may be a single specific key (mnemonic) or a numeric code (e.g. 00-00), or a string enclosed in double quotes. In the case of a string, the ALPHA command is coded as a variable-length command that is automatically terminated by the appropriate code based on machine type. Within the string, shift codes are handled automatically. The following special codes (escapes) are used to represent special characters:

“\r”	RETURN-INDEX (carriage-return line-feed)
“\b”	BACKSPACE
“\t”	TAB
“\i”	INDEX (line-feed)
“\v”	REVERSE INDEX
“\h”	“½”
“\q”	“¼”
“\c”	“¢”
“\n”	DC2 a.k.a. PUNCH-ON
“\f”	DC4 a.k.a. PUNCH-OFF

Not all output devices support all these characters.

REGISTER DIRECT

Register direct instructions use the decimal value of the register index, the same number that would be used for indirect register access (not the coded value placed in the program step). For the Wang 700, this includes automatic handling of the “register + 100” cases.

PRINT / WRITE

The PRINT (Wang 600) or WRITE (Wang 700) instruction is followed by a code that indicates the format used to print the number. The Wang 600 uses a format that specifies a letter “tag” and the number of decimal places separated by a slash, for example “X/02”. The Wang 700 uses a format that specifies the number of places to blank-pad in the whole-number portion and the number of decimal places, represented as a standard program code, for example “05-02”.

MARK / SEARCH

Instructions that use a statement label may specify the label as either a standard code (“00-00”) or by the key mnemonic (“E0”). The disassembler favors the key mnemonic.

ASSEMBLER ERRORS

The following error letters are used:

V	Invalid characters in ENTER operand.
O	Invalid opcode mnemonic.
S	Syntax error (missing operand).
P	Operand error.
R	Register value error.
F	Printer format error.
I	I/O operand error.

EXAMPLES

This example uses the “.REG” psuedo-op to create a register within a program that contains a pattern for a blank display on the Wang 600:

```
...      RECALL &blank
          ALPHA STOP
          ALPHA STOP
...      .REG blank "FFFFFFFFFFFF00A"
          END
```

Note that, due to wasm being a single-pass assembler, the listing output shows a dummy value in the RECALL instruction even though the final program file contains the actual register number code.

There is currently no way to tell the disassembler about sections of a file that contain register data.

(end of document)