

WANG SERIES 706/707 (cont.)

MODEL 707-5 CURRENT CABLE

This cable is supplied with the Model 706 and is used to connect the Teletype to the Model 707 Interface Control Unit. It is also used as the interconnecting cable between Model 707-4 Teletype Connectors and the Model 707. It is furnished in a 12-foot length to fit most equipment setup applications. However, a user requiring a longer cable may increase this length to 1,000 feet using 4-conductor cable.

MODEL 706 TELETYPE

The Model 706 is an unmodified ASR 33TTY Teletype. All connections to the teletype are made at terminal 151411 on the rear panel. A Model 707-5 Current Cable, furnished with each Model 706 connects the teletype to the Model 707 Interface Control Unit.

MODES OF OPERATION:

700 to Teletype

Write Mode — function same as 701 Output Writer.

Example:

The X-register of the 700 has the following number:

—123.45600000

The following 700 commands are given:

WRITE 03 05

The teletype will print

—123.45600

Write Alpha Mode — function same as 701 with additional commands of teletype punch on and off with set tab and clear tab codes.

Example:

Assume that the following commands are given on the 700:

WRITE ALPHA, 01 08, END ALPHA

The teletype will perform a carriage return and line feed.

Teletype to 700 (Run Mode)

Group-I 15X. The teletype will respond to the 15X command. Control will pass to the teletype. 700 will then be in the Run Mode. The 700 will then only respond to the teletype characters 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, ., ↑(set exp.), —(CHS), ←(clear display), Control A(GO), Control B(S&R00), Control C(S&R01), Control D(S&R02). Rubouts will be ignored. Any other character will be considered illegal and will automatically generate a "resume" to the 700 if the illegal character was preceded by a legal character.

Example:

Assume that the following 700 commands are given:

GROUP 1, 15 05

These two commands pass control to the teletype leaving the 700 in the Run Mode. If the characters 1, 2, & 3 are typed on the teletype, the X-register of the 700 will display

+123

If a Control C is now typed on the teletype, the 700 will begin executing subroutine 01.

Teletype to 700 (Learn Mode)

Group II 15X. The teletype will respond to the 15X command. Control will pass to the teletype. The 700 will then be in the Learn Mode. All of the alpha and numeric characters may be learned into the 700 as well as Control U (Write A), and Control V (End A), Control H (upper case), Control L (lower case).

Example:

Assume that the following 700 commands are given:

GROUP 2, 15 06

These two commands pass control to the teletype leaving the 700 in the Learn Mode. We can now learn into the 700 from the teletype any alpha-numeric character (e.g., Control U(Write Alpha), W, A, N, G, Control V(End Alpha), Control A(resume to 700). The word "WANG" will now be in the memory of the 700.

The following 700 codes apply to both Group I and Group II operations.

A 700 XX code of 15 00 will generate an X ON (Reader on) and control will pass to the tape reader.

A 700 XX code of 15 01 will generate a 1 to the teletype. Control will pass to the teletype.

A 700 XX code of 15 02 will generate a 2 to the teletype. Control will pass to the teletype.

A 700 XX code of 15 03 will generate a 3 to the teletype. Control will pass to the teletype.

A 700 XX code of 15 04 will generate a 4 to the teletype. Control will pass to the teletype.

700 XX codes of 15 05 through 15 15 will just pass control to the teletype.