

Teletype to 700 I/O Bus (700 placed in Learn Mode by Group 2 command or 700 to teletype when used as an output writer).
700 output codes used for teletype operations are for the most part identical to 701 Selectric codes.

CHARACTER		L.C.	TELETYPE ASCII CODE		SERIES 700 CODE	CHARACTER		L.C.	TELETYPE ASCII CODE		SERIES 700 CODE
U.C.			Upper Case	Lower Case		U.C.			Uppercase	Lowercase	
	A		100 0001	Same	01 12	&		6	—	011 0110	03 04
	B		100 0010		02 00	*		7	010 0110	011 0111	03 13
	C		100 0011		02 12			8	010 1010	011 1000	03 12
	D		100 0100		02 13	(		9	010 1000	011 1001	03 00
	E		100 0101		02 05	)		0	010 1001	011 0000	03 01
	F		100 0110		00 14			-	—	010 1101	00 00
	G		100 0111		00 15	+		=	010 1011	011 1101	00 06
	H		100 1000		02 01	:		;	011 1010	011 1011	00 13
	I		100 1001		01 04	;			010 0010	010 0111	01 05
	J		100 1010		00 07	”			010 1100	Same	00 12
	K		100 1011		02 04	?		/	010 1110	Same	01 06
	L		100 1100		03 15			!	011 1111	010 1111	00 09
	M		100 1101		01 15				—	010 0001	01 07
	N		100 1110		02 06				010 0000	Same	00 02
	O		100 1111		01 09				000 1010		01 10
	P		101 0000		00 05				000 1000		01 03
	Q		101 0001		00 04						
	R		101 0010		01 13				000 1100		01 02
	S		101 0011		01 01						
	T		101 0100		02 07						
	U		101 0101		02 14				000 1101		01 08
	V		101 0110		01 14				000 1010		00 10
	W		101 0111		01 00				001 0010		
	X		101 1000		02 15				001 0100		00 11
	Y		101 1001		00 01						
	Z		101 1010		03 07				001 0101		04 12
	I		011 0001		02 09						
		2	110 0000	011 0010	03 06				001 0110		04 13
@		3	010 0011	011 0011	03 14						
#		4	*010 0100	011 0100	03 09				000 0001		05 14
\$		5	010 0101	011 0101	03 05						
%											

Teletype to 700 I/O Bus (700 placed in Run Mode by Group 1 Command)

CHARACTER (COMMAND)	TELETYPE ASCII CODE	SERIES 700 CODE	CHARACTER (COMMAND)	TELETYPE ASCII CODE	SERIES 700 CODE
0	011 0000	07 00	←(CL. DISP.)	010 1101	07 11
1	011 0001	07 01	↑(SET EXP.)	101 1111	07 15
2	011 0010	07 02	Control A	101 1110	07 10
3	011 0011	07 03	(GO)	000 0001	05 14
4	011 0100	07 04	Control B	000 0010	00 00
5	011 0101	07 05	(S&R 00)	000 0011	00 01
6	011 0110	07 06	Control C	000 0100	00 02
7	011 0111	07 07	(S&R 01)		
8	011 1000	07 08	Control D		
9	011 1001	07 09	(S&R 02)		
.	010 1110	07 12			

The last four codes will generate an X OFF in the teletype in a numeric character. In this latter case an illegal code will generate a
addition to the 700 generated codes. All other codes except rub-out
are illegal. All illegal codes will be ignored except when preceded by
GO to the 700 and an X OFF to the teletype. Rub-outs will just
be ignored.