LOOM-SMK / LOOM-8 on the M-VAVE SMK-37

Quick reference guide · branch loom8-smk37 (beta), build of 1 November 2026 · the SMK's printed names first, the FM-1's after them

Track colours (b/w theme)

T1 T2 T3 T4 T5 T6 T7 T8

8 KNOBS

K1	**Volume** (the FM-1's MASTER); the screen shows the level
K2	SELECT · the button's next page; in a list, up / down
K3	ALGORITHM · picks the track: T1–T8, COND, THROW, WEAVE
K4	PRESETS · the next preset, drum key, effect, pattern or scene
K5–K8	KNOB 1–4 · the four values along the bottom of the screen
On Steps (SEQ)	
Nothing held	K5 pattern · K6 length · K7 scale · K8 groove
A pad held	K5 velocity · K6 length · K7 chance · K8 pitch
Pad + ARP	K5 trick 1 · K6 its value · K7 trick 2 · K8 its value

4 FADERS + 2 WHEELS

Faders 1–4	Levels of T1–T4; after **FADER BANK** (lit), T5–T8. A fader acts once it moves
Pitch wheel	Bends the track the keys play, up to a fifth (±7 semitones)
Mod wheel	That track's filter cutoff (DYNAMIC filter: its hi cut). Picks up: acts once it passes the track's value

37 KEYS

F3–G5	The FM-1's 27 keys, with velocity. **White 1–16** are their white keys from F3, **black 1–11** their black keys
Outer 10	C3–E3 and G♯5–C6: more notes on the same track; on a kit, its keys
On a kit	Black 1–11: its eleven drum sounds (black 1 the kick)
Arrange	White: scenes 1–16 (OCT+: 17–32). Black: mutes
Throws	FX, K2 to Throws. Hold a white key, F3–E4 on the drums, F4–E5 on the melodic tracks: mute · stutter · repeat · echo · build · floor · jumble. Black keys: warble · pan · octave · chop · ring

BUTTONS

SMK-37	FM-1 name · what it does
PATCH	HOME · Arrange; again: Song. Held: a shift (undo, redo, tempo). To a question: no
BT	SAVE · saves now (lit: unsaved). Held + white 1–2: to that slot. On a sound page, held + a white key: keep the sound
PARA	EDIT · the sound: Engine, Play, Play 2 (K2 turns the pages)
CHORD	ENV · Envelope, Filter, Filter envelope
FX	FX · Character, Sends, FX I, FX II, Throws
SCALE	SEL · the page's settings and actions. To a question: yes
GLOBE	GLO · Mix, Master EQ, Master color, Master out, LFO, Setup
ARP	ARP · Players (arp, strum, hold), Weave. A step's pad held: its two tricks
SEQ	SEQ · Steps; K2: Bar. Held on Steps: the keys play, and set what a pad writes
PLAY	PLAY · start / stop. SEQ + PLAY on Steps: from this bar
REC	REC · REC + PLAY: record live. Held while playing: records while held. Tapped, stopped, on Steps: step record
NOTE REPEAT	LFO · tapped: note repeat on / off (lit). Held + pads 1–8: its rate. Held and let go alone: the LFO page
KNOB BANK	The pads: on Steps, cells ↔ live pads (lit); elsewhere, opens Steps
FADER BANK	The faders: T1–T4 ↔ T5–T8 (lit)
< / >	The bar before / after, on any page, when let go
< + >	**DAW mode** on / off: the second pressed while the first is held
OCT– / OCT+	The keys' octave. A step's pad held: nudge it. SEQ held on Steps: the pattern an octave. Arrange: scenes 1–16 / 17–32. Step record: back / rest

QUICK MOVES

Undo / redo	PATCH + REC / PATCH + PLAY
Tempo	PATCH held + turn K2, on any page
Write a note	Hold SEQ, play it, let go, tap a pad
Lock a knob	Hold a pad, press PARA, CHORD or FX, turn
New scene	PATCH, then an empty white key
Solo	GLOBE (Mix): hold the track's black key

16 PADS

On Steps and Bar (SEQ): the bar's 16 cells

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16

Track colour: notes dim, playing bright, held white. Hold + a later pad: length

Every other page (or KNOB BANK on Steps): live pads

T1	T2	T3	T4	T5	T6	T7	T8
D1	D2	D3	D4	D5	D6	D7	D8

Top: mutes T1–T8 (dark: muted). **Bottom:** the kit's first 8 sounds, with velocity, whatever track is selected

NOTE REPEAT held: the top row sets the rate

1/4	1/8	1/8T	1/16	1/16T	1/32	1/32T	1/64

In use: bright (1/16 at first). A pick turns repeat on: a held drum pad plays again in time

DAW MODE (< + >)

Keys	Notes on CHANNEL (1), C3 = 48. OCT–/+: ±3; both: 0
K1–K8	CC 70–77; KNOB BANK: CC 102–109
Faders	CC 20–23; FADER BANK: CC 24–27
Pads	Ch 10: bottom 36–43, top 44–51; both BANKs: 52–59, 60–67
Buttons	CC, 127 / 0: < 110 · > 111 · SEQ 112 · FX 113 · PARA 114 · PLAY 115 · REC 117 · ARP 118 · NOTE REPEAT 119 · SCALE 85 · CHORD 86 · GLOBE 87 · BT 88
Wheels	Pitch bend; mod: CC 1
PATCH	Tapped: LOCAL (the keys play LOOM-8 too). Held: K5 CHANNEL · K6 map · K7 knobs ABS / REL · OCT+ map editor

POWER-ON AND HELP

Power-on	OCT– + OCT+ held: recalibrate the buttons and knobs
Help	Hold any button 1 s for its card. The screen's bottom lines name each control's job