LOOM-SMK / LOOM-8 on the M-VAVE SMK-37

Quick reference guide · branch loom8-smk37 (beta), build of 6 November 2026 · the SMK's printed names first, the FM-1's after them

Track colours (b/w theme)

T1 T2 T3 T4 T5 T6 T7 T8

8 KNOBS

K1	**Volume** (the FM-1's MASTER); the screen shows the level
K2	SELECT · the button's next page; in a list, up / down
K3	ALGORITHM · picks the track: T1–T8, COND, THROW, WEAVE
K4	PRESETS · the next preset, drum key, effect, pattern or scene
K5–K8	KNOB 1–4 · the four values along the bottom of the screen
On Steps (SEQ)	
Nothing held	K5 pattern · K6 length · K7 scale · K8 groove
A pad held	K5 velocity · K6 length · K7 chance · K8 pitch
Pad + ARP	K5 trick 1 · K6 its value · K7 trick 2 · K8 its value

4 FADERS + 2 WHEELS

Faders 1–4	Levels of T1–T4; after **FADER BANK** (lit), T5–T8. A fader acts once it moves
Pitch wheel	Bends the track the keys play, up to a fifth (±7 semitones)
Mod wheel	That track's filter cutoff (DYNAMIC filter: its hi cut). Picks up: acts once it passes the track's value

37 KEYS

F3–G5	The FM-1's 27 keys, with velocity (GLOBE, Setup: KEY VELOCITY). **White 1–16** are their white keys from F3, **black 1–11** their black keys
Outer 10	C3–E3 and G♯5–C6: more notes on the same track; on a kit, its keys
On a kit	Black 1–11: its eleven drum sounds (black 1 the kick)
Arrange	White: scenes 1–16 (OCT+: 17–32). Black: mutes
Throws	FX, K2 to Throws. Hold a white key, F3–E4 on the drums, F4–E5 on the melodic tracks: mute · stutter · repeat · echo · build · floor · jumble. Black keys: warble · pan · octave · chop · ring

BUTTONS

SMK-37	FM-1 name · what it does
PATCH	HOME · Arrange; again: Song. Held: a shift (undo, redo, tempo). To a question: no
BT	SAVE · saves now (lit: unsaved). Held + white 1–2: to that slot. On a sound page, held + a white key: keep the sound
PARA	EDIT · the sound: Engine, Play, Play 2 (K2 turns the pages)
CHORD	ENV · Envelope, Filter, Filter envelope
FX	FX · Character, Sends, FX I, FX II, Throws
SCALE	SEL · the page's settings and actions. To a question: yes
GLOBE	GLO · Mix, Master EQ, Master color, Master out, LFO, Setup
ARP	ARP · Players (arp, strum, hold, random), Weave. A step's pad held: its two tricks
SEQ	SEQ · Steps; K2: Bar. Held on Steps: the keys play, and set what a pad writes
PLAY	PLAY · start / stop. SEQ + PLAY on Steps: from this bar
REC	REC · REC + PLAY: record live. Held while playing: records while held. Tapped, stopped, on Steps: step record. **Tapped twice:** a counted-in take: stopped, a bar of clicks then from step 1; playing, from the next bar
NOTE REPEAT	LFO · tapped: note repeat on / off (lit). Held + pads 1–8: its rate. Held and let go alone: the LFO page
KNOB BANK	The pads: on Steps, cells ↔ live pads (lit); elsewhere, opens Steps
FADER BANK	The faders: T1–T4 ↔ T5–T8 (lit)
< / >	The bar before / after, on any page, when let go
< + >	**DAW mode** on / off: the second pressed while the first is held
OCT– / OCT+	The keys' octave. A step's pad held: nudge it. SEQ held on Steps: the pattern an octave. Arrange: scenes 1–16 / 17–32. Step record: back / rest

QUICK MOVES

Undo / redo	PATCH + REC / PATCH + PLAY
Tempo	PATCH held + turn K2, on any page
Write a note	Hold SEQ, play it, let go, tap a pad
Lock a knob	Hold a pad, press PARA, CHORD or FX, turn
New scene	PATCH, then an empty white key
Solo	GLOBE (Mix): hold the track's black key

16 PADS

On Steps and Bar (SEQ): the bar's 16 cells

1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16

Track colour: notes dim, playing bright, held white. Hold + a later pad: length

Every other page (or KNOB BANK on Steps): live pads

T1	T2	T3	T4	T5	T6	T7	T8
D1	D2	D3	D4	D5	D6	D7	D8

Top: mutes T1–T8 (dark: muted). **Bottom:** the kit's first 8 sounds, with velocity, whatever track is selected

NOTE REPEAT held: the top row sets the rate

1/4	1/8	1/8T	1/16	1/16T	1/32	1/32T	1/64

In use: bright (1/16 at first). A pick turns repeat on: a held drum pad plays again in time

DAW MODE (< + >)

Keys	Notes on CHANNEL (1), C3 = 48. OCT–/+: ±3; both: 0
K1–K8	CC 70–77; KNOB BANK: CC 102–109
Faders	CC 20–23; FADER BANK: CC 24–27
Pads	Ch 10: bottom 36–43, top 44–51; both BANKs: 52–59, 60–67
Buttons	CC, 127 / 0: < 110 · > 111 · SEQ 112 · FX 113 · PARA 114 · PLAY 115 · REC 117 · ARP 118 · NOTE REPEAT 119 · SCALE 85 · CHORD 86 · GLOBE 87 · BT 88
Wheels	Pitch bend; mod: CC 1
PATCH	Tapped: LOCAL (the keys play LOOM-8 too). Held: K5 CHANNEL · K6 map · K7 knobs ABS / REL · K8 key velocity · OCT+ map editor
REAPER	PATCH + K6: Mackie Control on USB port 2

POWER-ON AND HELP

Power-on	OCT– + OCT+ held: recalibrate the buttons and knobs
Help	Hold any button 1 s for its card. The screen's bottom lines name each control's job

REAPER / DAW mode's REAPER profile

Reverse · SPIDER on the M-VAVE SMK-37, branch spider2 (beta), build of 6 November 2026 · Mackie Control for REAPER's own control surface

Try it first in the emulator: < + >, PATCH held + K6 to REAPER, then **Pretend REAPER**

TURN IT ON

1	**< + >**: DAW mode (it starts in DAW mode if left there)
2	**PATCH held, K6** (CC MAP) to **REAPER**: DEFAULT, USER, REAPER, a detent a step. Kept
3	**Waiting for REAPER** until REAPER answers. Every 3 s of silence SPIDER asks it to send everything again

TWO USB MIDI PORTS

1 · music	**SPIDER SMK-37**: keys (CHANNEL, 1 to start), drum pads (ch 10), wheels, the NAV knobs (ch 16), clock. As DEFAULT; LOCAL as always
2 · control	Windows: **MIDIIN2 / MIDIOUT2 (SPIDER SMK-37)**; macOS, Linux: **SPIDER DAW**. Mackie Control both ways; never plays SPIDER

8 KNOBS

KNOB BANK unlit: MIX	
K1–K8	V-pots: the pan of strips 1–8 (with FX's flip: volume)
KNOB BANK lit: NAV (K2–K6, K8: port 1, ch 16, learnt in REAPER)	
K1	Jog: the edit cursor (with PARA's scrub: scrubs)
K2 · CC 102	View: Scroll horizontally
K3 · CC 103	View: Zoom horizontally
K4 · CC 104	View: Scroll vertically
K5 · CC 105	View: Zoom vertically. K2–K5: the *MIDI CC relative/mousewheel* actions, mode **Relative 2**
K6 · CC 106 / 107	Track: Go to previous / next track
K7	The marker before / after (Mackie's << >>: nothing to learn)
K8 · CC 111	Anticlockwise: undo. Clockwise: CC 111, learn Edit: Redo

4 FADERS + 2 WHEELS

Faders 1–4	Volume of strips 1–4; FADER BANK lit: 5–8. With FX's flip: pan
Pick-up	A fader waits until it crosses REAPER's value (the screen says up or down), then follows: nothing jumps
Wheels	Pitch bend and CC 1 on port 1, as DEFAULT

BUTTONS

SMK-37	In REAPER
PLAY	Play; while REAPER plays, stop
REC	Record
NOTE REPEAT	Loop on / off
ARP	Metronome (click)
FX	Flip: the faders on pan, the knobs on volume
PARA	Scrub: K1's jog scrubs
SCALE	Add a marker
CHORD	Undo
BT	Save the project
< / >	The strips by 8 (GLOBE held: by 1), when let go
< + >	DAW mode off: SPIDER again
SEQ	The pads' page: DRUMS → MIXER → ACTIONS
GLOBE	Held: shift (MIXER's pads arm and solo; < > by 1)
PATCH	Tapped: LOCAL (keys and drum pads play SPIDER too). Held: K5 CHANNEL · K6 CC MAP · K7 ABS / REL · K8 key velocity
OCT– / OCT+	The keys' octave, ±3; both: 0

LIT WHEN

PLAY	REAPER plays	**REC**	it records
NOTE REPEAT	loop on	**ARP**	click on
FX	flipped	**PARA**	scrub on
CHORD	undo (a flash)	**BT**	saved (1 s)
SEQ	not on DRUMS	**PATCH**	LOCAL on
KNOB BANK	NAV	**FADER BANK**	strips 5–8

THE SCREEN

Top	REAPER: playing, stopped or recording, loop, click; the time (bars.beats.ticks or min:sec.ms)
Strips	Eight in two rows of four: name, pan mark, meter. The faders' row framed, the selected strip filled. Red dot: armed. Amber: soloed. Faint name: muted
Bottom	TRACKS 1–8 · PADS and their page · MIX or NAV · OCT; the control touched last and what it did

16 PADS: SEQ TURNS THE PAGE

DRUMS (SEQ unlit): notes on ch 10, as DEFAULT

44	45	46	47	48	49	50	51
36	37	38	39	40	41	42	43

Blue. With LOCAL the bottom row plays SPIDER's kit too

MIXER (SEQ lit): strips 1–8

SEL	SEL	SEL	SEL	SEL	SEL	SEL	SEL
MUTE	MUTE	MUTE	MUTE	MUTE	MUTE	MUTE	MUTE

Top: select (white). Bottom: mute (red). Bright: on. **GLOBE held:** top arm (red), bottom solo (amber, blinking as REAPER sends it). Dark: no track there

ACTIONS (SEQ lit): yours to learn

F1	F2	F3	F4	F5	F6	F7	F8
V1	V2	V3	V4	V5	V6	V7	V8

Purple. Mackie's F1–F8 and its eight view buttons: REAPER hands them to its action list, so learn each to any action

SET UP REAPER (ONCE)

1	**Preferences → Audio → MIDI Devices:** SPIDER SMK-37 in on (and *for control messages*), out on. MIDIIN2 / MIDIOUT2: leave off here
2	**Preferences → Control/OSC/web → Add → Mackie Control Universal:** in MIDIIN2, out MIDIOUT2 (SPIDER SMK-37). *Map F1–F8 to markers*: off
3	**Actions → Show action list:** pick an action, Add..., turn the NAV knob or press the ACTIONS pad. K2–K5: mode Relative 2
4	**Tracks you record:** input SPIDER SMK-37, channel 1 (keys) or 10 (pads), not all channels, so NAV's ch 16 stays out of takes

SPIDER IN TIME WITH REAPER

Set	Out of DAW mode, CLOCK on receive (GLOBE, Setup; the default). REAPER's MIDI Devices, the SPIDER SMK-37 out: *Send clock* (and SPP)
Then	Play from anywhere in REAPER: SPIDER starts each track at the step it would be on there, and the bar count with it