SoftingOPCToolboxClient ::ServerStatus::getBandwidth SoftingOPCToolboxClient ::ServerStatus::getCurrentTime SoftingOPCToolboxClient ::ServerStatus::getGroupCount SoftingOPCToolboxClient ::ServerStatus::getLastUpdateTime SoftingOPCToolboxClient ::ServerStatus::getProductVersion SoftingOPCToolboxClient SoftingOPCToolboxClient ::ExecutionOptions::getExecution ::ServerStatus::getStartTime Context OpcClient::getSyncServer Status SoftingOPCToolboxClient SoftingOPCToolboxClient ::ExecutionOptions::getExecutionType ::ServerStatus::getState SoftingOPCToolboxClient SoftingOPCToolboxClient ::AeSession::getStatus ::Application::Instance SoftingOPCToolboxClient **OTCGetServerStatus** ::ServerStatus::getStatusInfo OTFreeMemory SoftingOPCToolboxClient ::ServerStatus::getSupportedLclds SoftingOPCToolboxClient ::ServerStatus::getVendorInfo DateTime::toString