NAME

mbio − Format independent input/output library for swath mapping sonar data.

VERSION

Version 5.8

DESCRIPTION

MBIO (**M**ulti**B**eam **I**nput/**O**utput) is a library of functions used for reading and writing swath mapping sonar data files. **MBIO** supports a large number of data formats associated with different institutions and different sonar systems. The purpose of **MBIO** is to allow users to write processing and display programs which are independent of particular data formats and to provide a standard approach to swath mapping sonar data i/o.

MB-SYSTEM AUTHORSHIP

David W. Caress
Monterey Bay Aquarium Research Institute
Christian do Santos Ferreira
Center for Marine Environmental Sciences (MARUM)
University of Bremen
Dale N. Chayes
Center for Coastal and Ocean Mapping
University of New Hampshire

DATA TERMINOLOGY

MBIO handles three types of swath mapping data: beam bathymetry, beam amplitude, and sidescan. Both amplitude and sidescan represent measures of backscatter strength. Beam amplitudes are backscatter values associated with the same preformed beams used to obtain bathymetry; **MBIO** assumes that a bathymetry value exists for each amplitude value and uses the bathymetry beam location for the amplitude. Sidescan is generally constructed with a higher spatial resolution than bathymetry, and carries its own location parameters. In the context of **MB-System** documentation, the discrete values of bathymetry and amplitude are referred to as "beams", and the discrete values of sidescan are referred to as "pixels". An additional difference between "beam" and "pixel" data involves data flagging. An array of "beamflags" is carried by **MBIO** functions which allows the bathymetry (and by extension the amplitude) data to be flagged as bad. The details of the beamflagging scheme are presented below.

OVERVIEW

MBIO opens and initializes sonar data files for reading and writing using the functions **mb_read_init** and **mb_write_init**, respectively. These functions return a pointer to a data structure including all relevant information about the opened file, the control parameters which determine how data is read or written, and the arrays used for processing the data as it is read or written. This pointer is then passed to the functions used for reading or writing. There is no limit on the number of files which may be opened for reading or writing at any given time in a program.

The **mb_read_init** and **mb_write_init** functions also return initial maximum numbers of bathymetry beams, amplitude beams, and sidescan pixels that can be used to allocate data storage arrays of the appropriate sizes. However, for some data formats there are no specified maximum numbers of beams and pixels, and so in general the required dimensions may increase as data are read. Applications must pass appropriately dimensioned arrays into data extraction routines such as **mb_read**, **mb_get**, and **mb_get_all**. In order to enable dynamic memory management of thse application arrays, the application must first register each array by passing the array pointer location to the function **mb_register_array**.

Data files are closed using the function **mb_close**. All internal and registered arrays are deallocated as part of

closing the file.

When it comes to actually reading and writing swath mapping sonar data, **MBIO** has three levels of i/o functionality:

1: Simple reading of swath data files. The primary functions are:
mb_read()
mb_get()
The positions of individual beams and pixels are returned in longitude and latitude by **mb_read()** and in acrosstrack and alongtrack distances by **mb_get()**. Only a limited set of navigation information is returned. Comments are also returned. These functions can be used without any special include files or any knowledge of the actual data structures used by the data formats or **MBIO**.

2: Complete reading and writing of data structures containing all of the available information. Data records may be read or written without extracting any of the information, or the swath data may be passed with the data structure. Several functions exist to extract information from or insert information into the data structures; otherwise, special include files are required to make sense of the sonar-specific data structures passed by level 2 i/o functions. The basic read and write functions that only pass pointers to internal data structures are:
mb_read_ping()
mb_write_ping()
The read and write routines which also extract or insert information are:
mb_get_all()
mb_put_all()
mb_put_comment()
The information extraction and insertion functions are:
mb_insert()
mb_extract()
mb_extract_lonlat()
mb_extract_nav()
mb_insert_nav()
mb_extract_altitude()
mb_insert_altitude()
mb_ttimes()
mb_copyrecord()

3: Buffered reading and writing of data structures containing all of the available information. The primary functions are:
mb_buffer_init()
mb_buffer_close()
mb_buffer_load()

mb_buffer_dump()
mb_buffer_get_kind()
mb_buffer_get_next_data()
mb_buffer_extract()
mb_buffer_insert()
mb_buffer_get_next_nav()
mb_buffer_extract_nav()
mb_buffer_insert_nav()

The level 1 **MBIO** functions allow users to read sonar data independent of format, with the limitation that only a limited set of navigation information is passed. Thus, some of the information contained in certain data formats (e.g. the "heave" value in Hydrosweep DS data) is not passed by **mb_read()** or **mb_get()**. In general, the level 1 functions are useful for applications such as graphics which require only the navigation and the depth and/or backscatter values.

The level 2 functions (**mb_get_all()** and **mb_put_all()**) read and write the complete data structures, translate the data to internal data structures associated with each of the supported sonar systems, and pass pointers to these internal data structures. Additional functions allow a variety of information to be extracted from or inserted into the data structures (e.g. mb_extract() and mb_insert()). Additional information may be accessed using special include files to decode the data structures. The great majority of processing programs use level 2 functions.

The level 3 functions provide buffered reading and writing which is useful for applications that generate output files and need access to multiple pings at a time. In addition to reading (**mb_buffer_load()**) and writing (**mb_buffer_dump()**), functions exist for extracting information from the buffer (**mb_buffer_extract()**) and inserting information into the buffer (**mb_buffer_insert()**).

MBIO supports swath data in a number of different formats, each specified by a unique id number. The function **mb_format()** determines if a format id is valid. A set of similar functions returns information about the specified format (e.g. **mb_format_description()**, **mb_format_system()**, **mb_format_description()**, **mb_format_dimensions()**, **mb_format_flags()**, **mb_format_source()**, **mb_format_beamwidth()**).

Some **MB-System** programs can process multiple data files specified in "datalist" files. Each line of a datalist file contains a file path and the corresponding **MBIO** format id. Datalist files can be recursive and can contain comments. The functions used to extract input swath data file paths from datalist files includes **mb_datalist_open()**, **mb_datalist_read()**, and **mb_datalist_close()**.

A number of other **MBIO** functions dealing with default values for important parameters, error messages, memory management, and time conversions also exist and are discussed below.

SUPPORTED SWATH SONAR SYSTEMS

Each swath mapping sonar system outputs a data stream which includes some values or parameters unique to that system. In general, a number of different data formats have come into use for data from each of the sonar systems; many of these formats include only a subset of the original data stream. Internally, **MBIO** recognizes which sonar system each data format is associated with and uses a data structure including the complete data stream for that sonar. Consequently, it is possible to read and write the complete data stream when using the level 2 or 3 **MBIO** functions. The sonars and other sensors associated with supported formats include:

SeaBeam "classic" 16 beam multibeam sonar
Hydrosweep DS 59 beam multibeam sonar
Hydrosweep MD 40 beam mid-depth multibeam sonar
SeaBeam 2000 multibeam sonar
SeaBeam 2112, 2120, and 2130 multibeam sonars

Simrad EM12, EM121, EM950, and EM1000 multibeam sonars
Simrad EM120, EM300, EM1002, and EM3000 multibeam sonars
Kongsberg EM122, EM302, EM710, EM2040
Kongsberg EM124, EM304, EM712, EM2040
Hawaii MR-1 shallow tow interferometric sonar
ELAC Bottomchart 1180 and 1050 multibeam sonars
ELAC/SeaBeam Bottomchart Mk2 1180 and 1050 multibeam sonars
Reson Seabat 9001/9002 multibeam sonars
Reson Seabat 8101 multibeam sonars
Simrad/Mesotech SM2000 multibeam sonars
WHOI DSL AMS-120 deep tow interferometric sonar AMS-60 interferometric sonar
WASSP multibeams (old format)
Reson 7125 multibeam
Teledyne T20, T50 multibeams
R2Sonic multibeam
3D at Depth subsea lidars (SL-1, SL-2, WiSSL)

SUPPORTED FORMATS

The following swath mapping sonar data formats are supported in this version of **MBIO**:

MBIO Data Format ID: 11
Format name: MBF_SBSIOMRG
Informal Description: SIO merge Sea Beam
Attributes: Sea Beam, bathymetry, 16 beams, binary, uncentered, SIO.

MBIO Data Format ID: 12
Format name: MBF_SBSIOCEN
Informal Description: SIO centered Sea Beam
Attributes: Sea Beam, bathymetry, 19 beams, binary, centered, SIO.

MBIO Data Format ID: 13
Format name: MBF_SBSIOLSI
Informal Description: SIO LSI Sea Beam
Attributes: Sea Beam, bathymetry, 19 beams, binary, centered, obsolete, SIO.

MBIO Data Format ID: 14
Format name: MBF_SBURICEN
Informal Description: URI Sea Beam
Attributes: Sea Beam, bathymetry, 19 beams, binary, centered, URI.

MBIO Data Format ID: 15
Format name: MBF_SBURIVAX
Informal Description: URI Sea Beam from VAX
Attributes: Sea Beam, bathymetry, 19 beams, binary, centered, VAX byte order, URI.

MBIO Data Format ID: 16
Format name: MBF_SBSIOSWB
Informal Description: SIO Swath-bathy SeaBeam

Attributes: Sea Beam, bathymetry, 19 beams, binary, centered, SIO.

MBIO Data Format ID: 17
Format name: MBF_SBIFREMR
Informal Description: IFREMER Archive SeaBeam
Attributes: Sea Beam, bathymetry, 19 beams, ascii, centered, IFREMER.

MBIO Data Format ID: 21
Format name: MBF_HSATLRAW
Informal Description: Raw Hydrosweep
Attributes: Hydrosweep DS, bathymetry and amplitude, 59 beams, ascii, Atlas Electronik.

MBIO Data Format ID: 22
Format name: MBF_HSLDEDMB
Informal Description: EDMB Hydrosweep
Attributes: Hydrosweep DS, bathymetry, 59 beams, binary, NRL.

MBIO Data Format ID: 23
Format name: MBF_HSURICEN
Informal Description: URI Hydrosweep
Attributes: Hydrosweep DS, 59 beams, bathymetry, binary, URI.

MBIO Data Format ID: 24
Format name: MBF_HSLDEOIH
Informal Description: L-DEO in-house binary Hydrosweep
Attributes: Hydrosweep DS, 59 beams, bathymetry and amplitude, binary, centered, L-DEO.

MBIO Data Format ID: 25
Format name: MBF_HSURIVAX
Informal Description: URI Hydrosweep from VAX
Attributes: Hydrosweep DS, 59 beams, bathymetry, binary, VAX byte order, URI.

MBIO Data Format ID: 26
Format name: MBF_HSUNKNWN
Informal Description: Unknown Hydrosweep
Attributes: Hydrosweep DS, bathymetry, 59 beams, ascii, unknown origin, SOPAC.

MBIO Data Format ID: 32
Format name: MBF_SB2000SB
Informal Description: SIO Swath-bathy SeaBeam 2000 format
Attributes: SeaBeam 2000, bathymetry, 121 beams, binary, SIO.

MBIO Data Format ID: 33
Format name: MBF_SB2000SS
Informal Description: SIO Swath-bathy SeaBeam 2000 format
Attributes: SeaBeam 2000, sidescan, 1000 pixels for 4-bit sidescan,

2000 pixels for 12+-bit sidescan,
binary, SIO.

MBIO Data Format ID: 41
Format name: MBF_SB2100RW
Informal Description: SeaBeam 2100 series vender format
Attributes: SeaBeam 2100, bathymetry, amplitude
and sidescan, 151 beams and 2000 pixels, ascii
with binary sidescan, SeaBeam Instruments.

MBIO Data Format ID: 42
Format name: MBF_SB2100B1
Informal Description: SeaBeam 2100 series vender format
Attributes: SeaBeam 2100, bathymetry, amplitude
and sidescan, 151 beams bathymetry,
2000 pixels sidescan, binary,
SeaBeam Instruments and L-DEO.

MBIO Data Format ID: 43
Format name: MBF_SB2100B2
Informal Description: SeaBeam 2100 series vender format
Attributes: SeaBeam 2100, bathymetry and amplitude,
151 beams bathymetry,
binary,
SeaBeam Instruments and L-DEO.

MBIO Data Format ID: 51
Format name: MBF_EMOLDRAW
Informal Description: Old Simrad vendor multibeam format
Attributes: Simrad EM1000, EM12S, EM12D,
and EM121 multibeam sonars,
bathymetry, amplitude, and sidescan,
60 beams for EM1000, 81 beams for EM12S/D,
121 beams for EM121, variable pixels,
ascii + binary, Simrad.

MBIO Data Format ID: 53
Format name: MBF_EM12IFRM
Informal Description: IFREMER TRISMUS format for Simrad EM12
Attributes: Simrad EM12S and EM12D,
bathymetry, amplitude, and sidescan
81 beams, variable pixels, binary,
read-only, IFREMER.

MBIO Data Format ID: 54
Format name: MBF_EM12DARW
Informal Description: Simrad EM12S RRS Darwin processed format
Attributes: Simrad EM12S, bathymetry and amplitude,
81 beams, binary, Oxford University.

MBIO Data Format ID: 56
Format name: MBF_EM300RAW
Informal Description: Simrad current multibeam vendor format

Attributes: Simrad EM120, EM300, EM1002, EM3000,
bathymetry, amplitude, and sidescan,
up to 256 beams, variable pixels, ascii + binary, Simrad.

MBIO Data Format ID: 57
Format name: MBF_EM300MBA
Informal Description: Simrad multibeam processing format
Attributes: Old and new Simrad multibeams,
EM12S, EM12D, EM121, EM120, EM300,
EM100, EM1000, EM950, EM1002, EM3000,
bathymetry, amplitude, and sidescan,
up to 256 beams, variable pixels, ascii + binary, MBARI.

MBIO Data Format ID: 58
Format name: MBF_EM710RAW
Informal Description: Kongsberg 3rd generation multibeam vendor format
Attributes: Kongsberg EM122, EM302, EM710,
bathymetry, amplitude, and sidescan,
up to 400 beams, variable pixels, binary, Kongsberg.

MBIO Data Format ID: 59
Format name: MBF_EM710MBA
Informal Description: Kongsberg current multibeam processing format
Attributes: Kongsberg EM122, EM302, EM710,
bathymetry, amplitude, and sidescan,
up to 400 beams, variable pixels, binary, MBARI.

MBIO Data Format ID: 61
Format name: MBF_MR1PRHIG
Informal Description: Obsolete SOEST MR1 post processed format
Attributes: SOEST MR1, bathymetry and sidescan,
variable beams and pixels, xdr binary,
SOEST, University of Hawaii.

MBIO Data Format ID: 62
Format name: MBF_MR1ALDEO
Informal Description: L-DEO MR1 post processed format with travel times
Attributes: L-DEO MR1, bathymetry and sidescan,
variable beams and pixels, xdr binary,
L-DEO.

MBIO Data Format ID: 63
Format name: MBF_MR1BLDEO
Informal Description: L-DEO small MR1 post processed format with travel times
Attributes: L-DEO MR1, bathymetry and sidescan,
variable beams and pixels, xdr binary,
L-DEO.

MBIO Data Format ID: 64
Format name: MBF_MR1PRVR2
Informal Description: SOEST MR1 post processed format
Attributes: SOEST MR1, bathymetry and sidescan,
variable beams and pixels, xdr binary,

SOEST, University of Hawaii.

MBIO Data Format ID: 71
Format name: MBF_MBLDEOIH
Informal Description: L-DEO in-house generic multibeam
Attributes: Data from all sonar systems, bathymetry,
amplitude and sidescan, variable beams and pixels,
binary, centered, L-DEO.

MBIO Data Format ID: 72
Format name: MBF_MBARIMB1
Informal Description: MBARI TRN swath bathymetry
Attributes: Downsampled bathymetry from multibeam sonars,
bathymetry only, variable beams, binary, MBARI

MBIO Data Format ID: 75
Format name: MBF_MBNETCDF
Informal Description: CARAIBES CDF multibeam
Attributes: Data from all sonar systems, bathymetry only,
variable beams, netCDF, IFREMER.

MBIO Data Format ID: 76
Format name: MBF_MBNCDFXT
Informal Description: CARAIBES CDF multibeam extended
Attributes: Superset of MBF_MBNETCDF, includes (at least SIMRAD EM12) amplitude,
variable beams, netCDF, IFREMER.

MBIO Data Format ID: 81
Format name: MBF_CBAT9001
Informal Description: Reson SeaBat 9001 shallow water multibeam
Attributes: 60 beam bathymetry and amplitude,
binary, University of New Brunswick.

MBIO Data Format ID: 82
Format name: MBF_CBAT8101
Informal Description: Reson SeaBat 8101 shallow water multibeam
Attributes: 101 beam bathymetry and amplitude,
binary, SeaBeam Instruments.

MBIO Data Format ID: 83
Format name: MBF_HYPC8101
Informal Description: Reson SeaBat 8101 shallow water multibeam
Attributes: 101 beam bathymetry,
ASCII, read-only, Coastal Oceanographics.

MBIO Data Format ID: 84
Format name: MBF_XTFR8101
Informal Description: XTF format Reson SeaBat 81XX
Attributes: 240 beam bathymetry and amplitude,
1024 pixel sidescan
binary, read-only,
Triton-Elics.

MBIO Data Format ID: 88
Format name: MBF_RESON7KR
Informal Description: Reson 7K multibeam vendor format
Attributes: Reson 7K series multibeam sonars,
bathymetry, amplitude, three channels sidescan, and subbottom
up to 254 beams, variable pixels, binary, Reson.

MBIO Data Format ID: 89
Format name: MBF_RESON7K3
Informal Description: Reson 7K multibeam vendor format
Attributes: Reson 7K series multibeam sonars,
bathymetry, amplitude, three channels sidescan, and subbottom
up to 254 beams, variable pixels, binary, Reson.

MBIO Data Format ID: 91
Format name: MBF_BCHRTUNB
Informal Description: Elac BottomChart shallow water multibeam
Attributes: 56 beam bathymetry and amplitude,
binary, University of New Brunswick.

MBIO Data Format ID: 92
Format name: MBF_ELMK2UNB
Informal Description: Elac BottomChart MkII shallow water multibeam
Attributes: 126 beam bathymetry and amplitude,
binary, University of New Brunswick.

MBIO Data Format ID: 93
Format name: MBF_BCHRXUNB
Informal Description: Elac BottomChart shallow water multibeam
Attributes: 56 beam bathymetry and amplitude,
binary, University of New Brunswick.

MBIO Data Format ID: 94
Format name: MBF_L3XSERAW
Informal Description: ELAC/SeaBeam XSE vendor format
Attributes: Bottomchart MkII 50 kHz and 180 kHz multibeam,
SeaBeam 2120 20 KHz multibeam,
bathymetry, amplitude and sidescan,
variable beams and pixels, binary,
L3 Communications (Elac Nautik
and SeaBeam Instruments).

MBIO Data Format ID: 101
Format name: MBF_HSMDARAW
Informal Description: Atlas HSMD medium depth multibeam raw format
Attributes: 40 beam bathymetry, 160 pixel sidescan,
XDR (binary), STN Atlas Elektronik.

MBIO Data Format ID: 102
Format name: MBF_HSMDLDIH
Informal Description: Atlas HSMD medium depth multibeam processed format
Attributes: 40 beam bathymetry, 160 pixel sidescan,
XDR (binary), L-DEO.

MBIO Data Format ID: 111
Format name: MBF_DSL120PF
Informal Description: WHOI DSL AMS-120 processed format
Attributes: 2048 beam bathymetry, 8192 pixel sidescan,
binary, parallel bathymetry and amplitude files, WHOI DSL.

MBIO Data Format ID: 112
Format name: MBF_DSL120SF
Informal Description: WHOI DSL AMS-120 processed format
Attributes: 2048 beam bathymetry, 8192 pixel sidescan,
binary, single files, WHOI DSL.

MBIO Data Format ID: 121
Format name: MBF_GSFGENMB
Informal Description: Leidos Generic Sensor Format (GSF) version GSF-v03.11
Attributes: variable beams, bathymetry and amplitude,
binary, single files, Leidos (formerly SAIC).

MBIO Data Format ID: 131
Format name: MBF_MSTIFFSS
Informal Description: MSTIFF sidescan format
Attributes: variable pixels, sidescan,
binary TIFF variant, single files, Sea Scan.

MBIO Data Format ID: 132
Format name: MBF_EDGJSTAR
Informal Description: Edgetech Jstar format
Attributes: variable pixels, dual frequency sidescan and subbottom,
binary SEGY variant, single files,
low frequency sidescan returned as
survey data, Edgetech.

MBIO Data Format ID: 133
Format name: MBF_EDGJSTR2
Informal Description: Edgetech Jstar format
Attributes: variable pixels, dual frequency sidescan and subbottom,
binary SEGY variant, single files,
high frequency sidescan returned as
survey data, Edgetech.

MBIO Data Format ID: 141
Format name: MBF_OICGEODA
Informal Description: OIC swath sonar format
Attributes: variable beam bathymetry and
amplitude, variable pixel sidescan, binary,
Oceanic Imaging Consultants

MBIO Data Format ID: 142
Format name: MBF_OICMBARI
Informal Description: OIC-style extended swath sonar format
Attributes: variable beam bathymetry and
amplitude, variable pixel sidescan, binary,
MBARI

MBIO Data Format ID: 151
Format name: MBF_OMGHDCSJ
Informal Description: UNB OMG HDCS format (the John Hughes Clarke format)
Attributes: variable beam bathymetry and
amplitude, variable pixel sidescan, binary,
UNB

MBIO Data Format ID: 160
Format name: MBF_SEGYSEGY
Informal Description: SEGY seismic data format
Attributes: seismic or subbottom trace data,
single beam bathymetry, nav,
binary, SEG (SIOSEIS variant)

MBIO Data Format ID: 161
Format name: MBF_MGD77DAT
Informal Description: NGDC MGD77 underway geophysics format
Attributes: single beam bathymetry, nav, magnetics,
gravity, ascii, NOAA NGDC

MBIO Data Format ID: 162
Format name: MBF_ASCIIXYZ
Informal Description: Generic XYZ sounding format
Attributes: XYZ (lon lat depth) ASCII soundings, generic

MBIO Data Format ID: 163
Format name: MBF_ASCIIYXZ
Informal Description: Generic YXZ sounding format
Attributes: YXZ (lat lon depth) ASCII soundings, generic

MBIO Data Format ID: 164
Format name: MBF_HYDROB93
Informal Description: NGDC binary hydrographic sounding format
Attributes: XYZ (lon lat depth) binary soundings

MBIO Data Format ID: 165
Format name: MBF_MBARIROV
Informal Description: MBARI ROV navigation format
Attributes: ROV navigation, MBARI

MBIO Data Format ID: 166
Format name: MBF_MBPRONAV
Informal Description: MB-System simple navigation format
Attributes: navigation, MBARI

MBIO Data Format ID: 167
Format name: MBF_NVNETCDF
Informal Description: CARAIBES CDF navigation
Attributes: netCDF, IFREMER.

MBIO Data Format ID: 168
Format name: MBF_ASCIIXYT
Informal Description: Generic XYT sounding format

Attributes: XYT (lon lat topography) ASCII soundings, generic

MBIO Data Format ID: 169
Format name: MBF_ASCIIYXT
Informal Description: Generic YXT sounding format
Attributes: YXT (lat lon topograpy) ASCII soundings, generic

MBIO Data Format ID: 170
Format name: MBF_MBARROV2
Informal Description: MBARI ROV navigation format
Attributes: ROV navigation, MBARI

MBIO Data Format ID: 171
Format name: MBF_HS10JAMS
Informal Description: Furuno HS-10 multibeam format,
Attributes: 45 beams bathymetry and amplitude,
ascii, JAMSTEC

MBIO Data Format ID: 172
Format name: MBF_HIR2RNAV
Informal Description: SIO GDC R2R navigation format
Attributes: R2R navigation, ascii, SIO

MBIO Data Format ID: 173
Format name: MBF_MGD77TXT
Informal Description: NGDC MGD77 underway geophysics format
Attributes: single beam bathymetry, nav, magnetics, gravity,
122 byte ascii records with CRLF line breaks, NOAA NGDC

MBIO Data Format ID: 174
Format name: MBF_MGD77TAB
Informal Description: NGDC MGD77 underway geophysics format
Attributes: single beam bathymetry, nav, magnetics, gravity,
122 byte ascii records with CRLF line breaks, NOAA NGDC

MBIO Data Format ID: 175
Format name: MBF_SOIUSBLN
Informal Description: SOI USBL navigation format
Attributes: SOI navigation, ascii, Schmidt Ocean Institute

MBIO Data Format ID: 176
Format name: MBF_SOIROVNV
Informal Description: SOI ROV navigation format(s)
Attributes: SOI navigation, ascii, Schmidt Ocean Institute

MBIO Data Format ID: 181
Format name: MBF_SAMESURF
Informal Description: SAM Electronics SURF format.
Attributes: variable beams, bathymetry, amplitude, and sidescan,
binary, single files, SAM Electronics (formerly Krupp-Atlas Electronik).

MBIO Data Format ID: 182
Format name: MBF_HSDS2RAW

Informal Description: STN Atlas raw multibeam format
Attributes: STN Atlas multibeam sonars,
Hydrosweep DS2, Hydrosweep MD,
Fansweep 10, Fansweep 20,
bathymetry, amplitude, and sidescan,
up to 1440 beams and 4096 pixels,
XDR binary, STN Atlas.

MBIO Data Format ID: 183
Format name: MBF_HSDS2LAM
Informal Description: L-DEO HSDS2 processing format
Attributes: STN Atlas multibeam sonars,
Hydrosweep DS2, Hydrosweep MD,
Fansweep 10, Fansweep 20,
bathymetry, amplitude, and sidescan,
up to 1440 beams and 4096 pixels,
XDR binary, L-DEO.

MBIO Data Format ID: 191
Format name: MBF_IMAGE83P
Informal Description: Imagenex DeltaT Multibeam
Attributes: Multibeam, bathymetry, 480 beams, ascii + binary, Imagenex.

MBIO Data Format ID: 192
Format name: MBF_IMAGEMBA
Informal Description: MBARI DeltaT Multibeam
Attributes: Multibeam, bathymetry, 480 beams, ascii + binary, MBARI.

MBIO Data Format ID: 201
Format name: MBF_HYSWEEP1
Informal Description: HYSWEEP multibeam data format
Attributes: Many multibeam sonars,
bathymetry, amplitude
variable beams, ascii, HYPACK.

MBIO Data Format ID: 211
Format name: MBF_XTFB1624
Informal Description: XTF format Benthos Sidescan SIS1624
Attributes: variable pixels, dual frequency sidescan and subbottom,
xtf variant, single files,
low frequency sidescan returned as
survey data, Benthos.

MBIO Data Format ID: 221
Format name: MBF_SWPLSSXI
Informal Description: SEA interferometric sonar vendor intermediate format
Attributes: SEA SWATHplus,
bathymetry and amplitude,
variable beams, binary, SEA.

MBIO Data Format ID: 222
Format name: MBF_SWPLSSXP
Informal Description: SEA interferometric sonar vendor processed data format

Attributes: SEA SWATHplus,
bathymetry and amplitude,
variable beams, binary, SEA.

MBIO Data Format ID: 231
Format name: MBF_3DDEPTHP
Informal Description: 3DatDepth prototype binary swath mapping LIDAR format
Attributes: 3DatDepth LIDAR, variable pulses, bathymetry and amplitude,
binary, 3DatDepth.

MBIO Data Format ID: 232
Format name: MBF_3DWISSLR
Informal Description: 3D at Depth Wide Swath Subsea Lidar (WiSSL) raw format
Attributes: 3D at Depth lidar, variable pulses, bathymetry and amplitude,
binary, 3D at Depth.

MBIO Data Format ID: 233
Format name: MBF_3DWISSLP
Informal Description: 3D at Depth Wide Swath Subsea Lidar (WiSSL) processing format
Attributes: 3D at Depth lidar, variable pulses, bathymetry and amplitude,
binary, MBARI.

MBIO Data Format ID: 234
Format name: MBF_3DWISSL2
Informal Description: 3D at Depth Second Generation Wide Swath Subsea Lidar (WiSSL2) SRIAT format
Attributes: 3D at Depth lidar, variable pulses, bathymetry and amplitude,
binary, MBARI.

MBIO Data Format ID: 241
Format name: MBF_WASSPENL
Informal Description: WASSP Multibeam Vendor Format
Attributes: WASSP multibeams,
bathymetry and amplitude,
122 or 244 beams, binary, Electronic Navigation Ltd.

MBIO Data Format ID: 251
Format name: MBF_PHOTGRAM
Informal Description: Stereo Photogrammetry format
Attributes: Stereo camera rigs, bathymetry, variable
soundings, binary, MBARI.

MBIO Data Format ID: 261
Format name: MBF_KEMKMALL
Informal Description: Kongsberg multibeam echosounder system kmall datagram format
Attributes: Kongsberg fourth generation multibeam sonars (EM2040, EM712,
EM304, EM124), bathymetry, amplitude, backscatter, variable beams,
binary datagrams, Kongsberg.

The institutional acronyms used above have the following meanings:

L-DEO	Lamont-Doherty Earth Observatory
MBARI	Monterey Bay Aquarium Research Institute
SIO	Scripps Institution of Oceanography
WHOI	Woods Hole Oceanographic Institution

URI University of Rhode Island
NRL Naval Research Laboratory
UNB University of New Brunswick
UH University of Hawaii
NOAA National Oceans and Atmospheres Agency
NGDC National Geophysical Data Center
USGS United States Geological Survey
IFREMER French government agency responsible for operation of French oceanographic research fleet.

FUNCTION STATUS AND ERROR CODES

All of the **MBIO** functions return an integer status value with the convention that:

status = 1: success
status = 0: failure

All **MBIO** functions also pass an error value argument which gives somewhat more information about problems than the status value. The full suite of possible error values and the associated error messages are:

error = 0: "No error",
error = −1: "Time gap in data",
error = −2: "Data outside specified location bounds",
error = −3: "Data outside specified time interval",
error = −4: "Ship speed too small",
error = −5: "Comment record",
error = −6: "Neither a data record nor a comment record",
error = −7: "Unintelligible data record",
error = −8: "Ignore this data",
error = −9: "No data requested for buffer load",
error = −10: "Data buffer is full",
error = −11: "No data was loaded into the buffer",
error = −12: "Data buffer is empty",
error = −13: "No data was dumped from the buffer"
error = −14: "No more survey data records in buffer"
error = −15: "Data inconsistencies prevented inserting data into storage structure"
error = 1: "Unable to allocate memory, initialization failed",
error = 2: "Unable to open file, initialization failed",
error = 3: "Illegal format identifier, initialization failed",
error = 4: "Read error, probably end-of-file",
error = 5: "Write error",
error = 6: "No data in specified location bounds",
error = 7: "No data in specified time interval",
error = 8: "Invalid MBIO descriptor",
error = 9: "Inconsistent usage of MBIO descriptor",
error = 10: "No pings binned but no fatal error - this should not happen!",
error = 11: "Invalid data record type specified for writing",
error = 12: "Invalid control parameter specified

by user",
error = 13: "Invalid buffer id",
error = 14: "Invalid system id − this should not happen!"
error = 15: "This data file is not in the specified format!"

In general, programs should treat negative error values as non-fatal (reading and writing can continue) and positive error values as fatal (the data files should be closed and the program terminated).

FUNCTION VERBOSITY

All of the **MBIO** functions are passed a *verbose* parameter which controls how much debugging information is output to standard error. If *verbose* is 0 or 1, the **MBIO** functions will be silent. If *verbose* is 2, then each function will output information as it is entered and as it returns, along with the parameter values passed into and returned out of the function. Greater values of *verbose* will cause additional information to be output, including values at various stages of data processing during read and write operations. In general, programs using **MBIO** functions should adopt the following verbosity conventions:

verbose = 0: "silent" or near-"silent" execution
verbose = 1: simple output including program name, version and simple progress updates
verbose >= 2: debug mode with copious output including every function call and status listings

INITIALIZATION AND CLOSING FUNCTIONS

int **mb_read_init**(
int *verbose*,
char **file*,
int *format*,
int *pings*,
int *lonflip*,
double *bounds[4]*,
int *btime_i[7]*,
int *etime_i[7]*,
double *speedmin*,
double *timegap*,
void ***mbio_ptr*,
double **btime_d*,
double **etime_d*,
int **beams_bath*,
int **beams_amp*,
int **pixels_ss*,
int **error*);

The function **mb_read_init** initializes the data file to be read and the data structures required for reading the data. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

file: input filename
format: input **MBIO** data format id
pings: ping averaging
lonflip: longitude flipping
bounds: location bounds of acceptable data
btime_i: beginning time of acceptable data
etime_i: ending time of acceptable data

speedmin: minimum ship speed of acceptable data
timegap: maximum time allowed before data gap

The format identifier *format* specifies which of the supported data formats is being read or written; the currently supported formats are listed in the "SUPPORTED FORMATS" section.

The *pings* parameter determines whether and how pings are averaged as part of data input. This parameter is used only by the functions **mb_read** and **mb_get**; **mb_get_all** and **mb_buffer_load** do not average pings. If *pings* = 1, then no ping averaging will be done and each ping read will be returned unaltered by the reading function. If *pings* > 1, then the navigation and beam data for *pings* pings will be read, averaged, and returned as the data for a single ping. If *pings* = 0, then the ping averaging will be varied so that the along-track distance between averaged pings is as close as possible to the across-track distance between beams.

The *lonflip* paramenter determines the range in which longitude values are returned:
lonflip = −1 : −360 to 0
lonflip = 0 : −180 to 180
lonflip = 1 : 0 to 360

The *bounds* array sets the area within which data are desired. Data which lie outside the area specified by *bounds* will be returned with an error by the reading function. The functions **mb_read**, **mb_get** and **mb_get_all** use the *bounds* array; the function **mb_buffer_load** does no location checking.
bounds[0] : minimum longitude
bounds[1] : maximum longitude
bounds[2] : minimum latitude
bounds[3] : maximum latitude

The *btime_i* array sets the desired beginning time for the data and the *etime_i* array sets the desired ending time. If the beginning time is earlier than the ending time, then any data with a time stamp before the beginning time or after the ending time will be returned with an MB_ERROR_OUT_TIME error by the reading function. If the beginning time is after the ending time, then data with time stamps between the ending and beginning time are returned with an error. This scheme allows time windowing outside or inside a specified interval. The functions **mb_read**, **mb_get** and **mb_get_all** use the *btime_i* and *btime_i* arrays; the function **mb_buffer_load** does no time checking.
btime[0] : year
btime[1] : month
btime[2] : day
btime[3] : hour
btime[4] : minute
btime[5] : second
btime[6] : microsecond
etime[0] : year
etime[1] : month
etime[2] : day
etime[3] : hour
etime[4] : minute
etime[5] : second
etime[6] : microsecond

The *speedmin* parameter sets the minimum acceptable ship speed for the data. If the ship speed associated with any ping is less than *speedmin*, then that data will be returned with an error by the reading function. This is used to eliminate data collected while a ship is on station is a simple way. The functions **mb_read**, **mb_get** and **mb_get_all** use the *speedmin* value; the function **mb_buffer_load** does no speed checking.

The *timegap* parameter sets the threshold at which the time interval between sonar pings (or lidar scans, etc.) is regarded as a data gap. Swath data with ping intervals less than *timegap* are regarded as continuous; if the ping interval exceeds *timegap* then a data gap is declared. Ping averaging is not done across data gaps; an error is returned when time gaps are encountered. The functions **mb_read** and **mb_get** use the *timegap* value; the functions **mb_get_all** and **mb_buffer_load** do no ping averaging and thus have no need to check for time gaps.

The returned values are:

mbio_ptr:	pointer to an **MBIO** descriptor structure
btime_d:	desired beginning time in seconds since 1/1/70 00:00:0
etime_d:	desired ending time in seconds since 1/1/70 00:00:0
beams_bath:	maximum number of bathymetry beams
beams_amp:	maximum number of amplitude beams
pixels_ss:	maximum number of sidescan pixels
error:	error value

The structure pointed to by *mbio_ptr* holds the file descriptor and all of the control parameters which govern how the data is read; this pointer must be provided to the functions **mb_read**, **mb_get**, **mb_get_all**, or **mb_buffer_load** to read data. The values *beams_bath*, *beams_amp*, and *pixels_ss* return initial estimates of the maximum number of bathymetry and amplitude beams and sidescan pixels, respectively, that the specified data format may contain. In general, *beams_amp* will either be zero or equal to *beams_bath*. The values *btime_d* and *etime_d* give the desired beginning and end times of the data converted to seconds since 00:00:00 on January 1, 1970; **MBIO** uses these units to calculate time internally.

For most data formats, the initial maximum beam and pixel dimensions will not change. However, a few formats support both variable and arbitrarily large numbers of beams and/or pixels, and so applications must be capable of handling dynamic changes in the numbers of beams and pixels. The arrays allocated internally in the *mbio_ptr* structure are automatically increased when necessary. However, in order to successfully extract swath data using *mb_get*, *mb_get_all*, *mb_read*, or *mb_extract*, an application must also provide pointers to arrays large enough to hold the current maximum numbers of bathymetry beams, amplitude beams, and sidescan pixels. The function *mb_register_array* allows applications to register array pointers so that these arrays are also dynamically allocated by *MBIO*. Registered arrays will be managed as data are read and then freed when **mb_close** is called.

A status value indicating success or failure is returned; an error value argument passes more detailed information about initialization failures.

−----------

int **mb_read_init_altnav**(
int *verbose*,
char **file*,
int *format*,
int *pings*,
int *lonflip*,
double *bounds[4]*,
int *btime_i[7]*,
int *etime_i[7]*,
double *speedmin*,
double *timegap*,
int *astatus*,
char **apath*,
void ***mbio_ptr*,

double **btime_d*,
double **etime_d*,
int **beams_bath*,
int **beams_amp*,
int **pixels_ss*,
int **error*);

The function **mb_read_init_altnav** initializes a data file for reading in exactly the same manner as **mb_read_init**, except that it also arranges for navigation to be drawn from an alternative navigation file *apath* rather than (or in addition to) the navigation embedded in *file* itself, where *astatus* (**MB_ALTNAV_USE** or **MB_ALTNAV_NONE**) indicates whether the alternative navigation should be used (see **mb_datalist_read3**, which supplies these values when reading a datalist).

−----------

int **mb_input_init**(
int *verbose*,
char **socket_definition*,
int *format*,
int *pings*,
int *lonflip*,
double *bounds[4]*,
int *btime_i[7]*,
int *etime_i[7]*,
double *speedmin*,
double *timegap*,
void ***mbio_ptr*,
double **btime_d*,
double **etime_d*,
int **beams_bath*,
int **beams_amp*,
int **pixels_ss*,
int *(*input_open)(int verbose, void *mbio_ptr, char *definition, int *error)*,
int *(*input_read)(int verbose, void *mbio_ptr, size_t *size, char *buffer, int *error)*,
int *(*input_close)(int verbose, void *mbio_ptr, int *error)*,
int **error*);

The function **mb_input_init** initializes an **MBIO** descriptor for reading in the same manner as **mb_read_init**, except that the data source is a socket, pipe, or other streamed input identified by *socket_definition* rather than an ordinary file, and the calling program supplies its own *input_open*, *input_read*, and *input_close* callback functions to open, read raw bytes from, and close that input source. This allows **MBIO** to read swath data streamed in real time (e.g. **mbtrnpp**) using the same **mb_read**/**mb_get_all**/**mb_extract** interface used for ordinary files.

−----------

int **mb_set_debug_records**(
int *verbose*,
void **mbio_ptr*,
bool *enable_debug_record_type_listing*,
int *num_debug_record_identifiers*,
mb_name **debug_record_identifiers*,
int **error*);

The function **mb_set_debug_records** configures the **MBIO** descriptor pointed to by *mbio_ptr* to print a

debug listing of selected data record types as they are read. If *enable_debug_record_type_listing* is true, the *num_debug_record_identifiers* record type names in the array *debug_record_identifiers* are the ones listed; this is a debugging aid for programs (e.g. **mbtrnpp**) that process streamed input.

−----------

int **mb_set_platform**(
int *verbose*,
void **mbio_ptr*,
void **mbplatform_ptr*,
int **error*);

The function **mb_set_platform** attaches a previously initialized sensor platform model (see **mb_platform_init**) pointed to by *mbplatform_ptr* to the **MBIO** descriptor pointed to by *mbio_ptr*, so that subsequent reads through that descriptor can make use of the platform's sensor offsets.

−----------

int **mb_write_init**(
int *verbose*,
char **file*,
int *format*,
void ***mbio_ptr*,
int **beams_bath*,
int **beams_amp*,
int **pixels_ss*,
int **error*);

The function **mb_write_init** initializes the data file to be written and the data structures required for writing the data. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

file:	output filename
format:	output **MBIO** data format id

The returned values are:

mbio_ptr:	pointer to a structure describing the output file
beams_bath:	maximum number of bathymetry beams
beams_back:	maximum number of backscatter beams
error:	error value

The structure pointed to by *mbio_ptr* holds the output file descriptor; this pointer must be provided to the functions **mb_write**, **mb_put**, **mb_put_all**, or **mb_buffer_dump** to write data. The values *beams_bath*, *beams_amp*, and *pixels_ss* return the maximum number of bathymetry and amplitude beams and sidescan pixels, respectively, that the specified data format may contain. In general, *beams_amp* will either be zero or equal to *beams_bath*. In order to successfully write data, the calling program must provide pointers to arrays large enough to hold *beams_bath* bathymetry values, *beams_amp* amplitude values, and *pixels_ss* sidescan values.

For most data formats, the initial maximum beam and pixel dimensions will not change. However, a few formats support both variable and arbitrarily large numbers of beams and/or pixels, and so applications must be capable of handling dynamic changes in the numbers of beams and pixels. The arrays allocated internally in the *mbio_ptr* structure are automatically increased when necessary. However, in order to successfully insert modified swath data using *mb_put*, *mb_put_all*, or *mb_insert*, an application must also provide pointers to

arrays large enough to hold the current maximum numbers of bathymetry beams, amplitude beams, and sidescan pixels. The function *mb_register_array* allows applications to register array pointers so that these arrays are also dynamically allocated by *MBIO*. Registered arrays will be managed as data are read and written and then freed when **mb_close** is called.

A status value indicating success or failure is returned; an error value argument passes more detailed information about initialization failures.

−----------

int **mb_register_array**(
int *verbose*,
void **mbio_ptr*,
int *type*,
size_t *size*,
void ***handle*,
int **error*);

Registers an array pointer **handle* so that the size of the allocated array can be managed dynamically by **MBIO**. Note that the location ***handle of the array pointer must be supplied, not the pointer value *handle. The pointer value *handle should initially be NULL. The type value indicates whether this array is to be dimensioned according to the maximum number of bathymetry beams (type = 1), amplitude beams (type = 2), or sidescan pixels (type = 3). The size value indicates the size of each element array in bytes (e.g. a char array has size = 1, a short array has size = 2, an int array or a float array have size = 4, and a double array has size = 8). The array is associated with the* **MBIO** *descriptor mbio_ptr, and is freed when mb_close is called for this particular mbio_ptr.*

−----------

int **mb_close***(*
int verbose,
*void **mbio_ptr,*
*int *error);*

Closes the data file listed in the **MBIO** *descriptor pointed to by *mbio_ptr and releases all specially allocated memory, including all application arrays registered using* **mb_register_array**. *The pointer *mbio_ptr is deallocated and set to NULL. The verbose value controls the standard error output verbosity of the function. A status value indicating success or failure is returned; an error value argument passes more detailed information about failures.*

−----------

int **mb_fileio_open***(*
int verbose,
*void *mbio_ptr,*
*int *error);*

The function **mb_fileio_open** *initializes low level byte input/output for a single regular file associated with the* **MBIO** *descriptor pointed to by mbio_ptr, and is called internally by* **mb_read_init** *and* **mb_write_init**. *Depending on the platform and data format, the underlying implementation may use buffered fread()/fwrite(), local buffering, or mmap().*

−----------

int **mb_fileio_close***(*
int verbose,
*void *mbio_ptr,*

*int *error);*

The function **mb_fileio_close** *releases the resources allocated by* **mb_fileio_open** *for the* **MBIO** *descriptor pointed to by mbio_ptr, and is called internally by* **mb_close**.

−--
int **mb_fileio_get***(*
int verbose,
*void *mbio_ptr,*
*char *buffer,*
*size_t *size,*
*int *error);*

The function **mb_fileio_get** *reads *size bytes from the input file associated with the* **MBIO** *descriptor pointed to by mbio_ptr into buffer.*

−--
int **mb_fileio_put***(*
int verbose,
*void *mbio_ptr,*
*char *buffer,*
*size_t *size,*
*int *error);*

The function **mb_fileio_put** *writes *size bytes from buffer to the output file associated with the* **MBIO** *descriptor pointed to by mbio_ptr.*

−--
int **mb_copyfile***(*
int verbose,
*const char *src,*
*const char *dst,*
*int *error);*

The function **mb_copyfile** *copies the file src to the file dst.*

−--
int **mb_catfiles***(*
int verbose,
*const char *src1,*
*const char *src2,*
*const char *dst,*
*int *error);*

The function **mb_catfiles** *concatenates the files src1 and src2, in that order, into the file dst.*

LEVEL 1 FUNCTIONS

−--
int **mb_read**(
int *verbose*,
void **mbio_ptr*,
int **kind*,
int **pings*,

int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **distance*,
double **altitude*,
double **sonardepth*,
int **nbath*,
int **namp*,
int **nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathlon*,
double **bathlat*,
double **ss*,
double **sslon*,
double **sslat*,
char **comment*,
int **error*);

The function **mb_read** reads, processes, and returns sonar data according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. A number of different data record types are recognized by **MB-System**, but **mb_read()** only returns survey and comment data records. The *kind* value indicates which type of record has been read. The data is in the form of bathymetry, amplitude, and sidescan values combined with the longitude and latitude locations of the bathymetry and sidescan measurements (amplitudes are coincident with the bathymetry).

The return values are:

kind: kind of data record read
1 survey data
2 comment
>=3 other data that cannot be passed by **mb_read**

pings: number of pings averaged to give current data

time_i: time of current ping
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond

time_d: time of current ping in seconds since 1/1/70 00:00:00

navlon: longitude

navlat: latitude

speed: ship speed in km/s

heading: ship heading in degrees

distance: distance along shiptrack since last ping in km

altitude:	altitude of sonar above seafloor in m
sonardepth:	depth of sonar in m
nbath:	number of bathymetry values
namp:	number of amplitude values
nss:	number of sidescan values
beamflag:	array of bathymetry flags
bath:	array of bathymetry values in meters
amp:	array of amplitude values in unknown units
bathlon:	array of longitude values corresponding to bathymetry
bathlat:	array of latitude values corresponding to bathymetry
ss:	array of sidescan values in unknown units
sslon:	array of longitude values corresponding to sidescan
sslat:	array of latitude values corresponding to sidescan
comment:	comment string
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about read failures.

–----------

int **mb_get**(
int *verbose*,
void **mbio_ptr*,
int **kind*,
int **pings*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **distance*,
double **altitude*,
double **sonardepth*,
int **nbath*,
int **namp*,
int **nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
char **comment*,
int **error*);

The function **mb_get** reads, processes, and returns sonar data according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. A number of different data record types are recognized by **MB-System**, but **mb_get()** only returns survey and comment data records. The *kind* value indicates which type of record has been read. The data is in the form of bathymetry, amplitude, and sidescan values combined with the acrosstrack and alongtrack distances relative to the navigation of the bathymetry and sidescan measurements (amplitudes are coincident with the bathymetry values).

The return values are:

kind:	kind of data record read 1 survey data 2 comment >=3 other data that cannot be passed by **mb_get**
pings:	number of pings averaged to give current data
time_i:	time of current ping *time_i*[0]: year *time_i*[1]: month *time_i*[2]: day *time_i*[3]: hour *time_i*[4]: minute *time_i*[5]: second *time_i*[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
distance:	distance along shiptrack since last ping in km
altitude:	altitude of sonar above seafloor in m
sonardepth:	depth of sonar in m
nbath:	number of bathymetry values
namp:	number of amplitude values
nss:	number of sidescan values
beamflag:	array of bathymetry flags
bath:	array of bathymetry values in meters
amp:	array of amplitude values in unknown units
bathacrosstrack:	array of acrosstrack distances in meters corresponding to bathymetry
bathalongtrack:	array of alongtrack distances in meters corresponding to bathymetry
ss:	array of sidescan values in unknown units
ssacrosstrack:	array of acrosstrack distances in meters corresponding to sidescan
ssacrosstrack:	array of alongtrack distances in meters corresponding to sidescan
comment:	comment string
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about read failures.

LEVEL 2 FUNCTIONS

int **mb_read_ping**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int **error*);

The function **mb_read_ping** reads and returns sonar data according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The data is returned one record at a time; no averaging is performed. A pointer to a data structure containing all of the data read is returned as *store_ptr*; the form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record has been read.

The return values are:

store_ptr: pointer to complete data structure

kind: kind of data record read

1	survey data
2	comment
3	header
4	calibrate
5	mean sound speed
6	SVP
7	standby
8	nav source
9	parameter
10	start
11	stop
12	nav
13	run parameter
14	clock
15	tide
16	height
17	heading
18	attitude
19	ssv
20	angle
21	event
22	history
23	summary
24	processing parameters
25	sensor parameters
26	navigation error
27	uninterpretable line

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about read failures.

−----------

int **mb_write_ping**(
int *verbose*,

void **mbio_ptr*,
void **store_ptr*,
int **error*);

The function **mb_write_ping** writes sonar data to the file listed in the **MBIO** descriptor pointed to by *MBIO_ptr*. The *verbose* value controls the standard error output verbosity of the function. A pointer to a data structure containing all of the data read is passed as *store_ptr*; the form of the data structure is determined by the sonar system associated with the format of the data being written. The values to be output are:

store_ptr: pointer to complete data structure

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about write failures.

−----------

int **mb_get_store**(
int *verbose*,
void **mbio_ptr*,
void ***store_ptr*,
int **error*);

The function **mb_get_store()** returns a pointer **store_ptr* to the data storage structure associated with a particular **MBIO** descriptor *mbio_ptr*. The **mb_read_init()** and **mb_write_init()** functions both allocate one of these internal storage structures. The form of the data structure is determined by the sonar system associated with the format of the data being written. Storage structure pointers must be passed to level two **MBIO** functions such as **mb_write_ping()** and **mb_insert()**. The *verbose* value controls the standard error output verbosity of the function.

The return values are:

store_ptr: pointer to complete data structure
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_dimensions**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int **nbath*,
int **namp*,
int **nss*,
int **error*);

The function **mb_dimensions** returns the kind of the current data record along with the numbers of bathymetry, amplitude, and sidescan values contained in it, without extracting the values themselves. This is useful for sizing arrays before calling **mb_extract** or similar functions.

−----------

int **mb_pingnumber**(
int *verbose*,
void **mbio_ptr*,
unsigned int **pingnumber*,
int **error*);

The function **mb_pingnumber** returns a ping number for the survey data record most recently read, taken directly from the data if the format records one, or otherwise set to the count of survey records read so far by this **MBIO** descriptor.

−----------

int **mb_segynumber**(
int *verbose*,
void **mbio_ptr*,
unsigned int **line*,
unsigned int **shot*,
unsigned int **cdp*,
int **error*);

The function **mb_segynumber** returns the seismic reflection line number, shot number, and common depth point (cdp) number associated with the current data record, for data formats that carry subbottom or seismic reflection data that can be represented in **SEGY** form (see **mb_extract_segy** below). For formats that do not provide these values, **shot* is set to the count of survey records read so far and **line* and **cdp* are set to zero.

−----------

int **mb_beamwidths**(
int *verbose*,
void **mbio_ptr*,
double **beamwidth_xtrack*,
double **beamwidth_ltrack*,
int **error*);

The function **mb_beamwidths** returns the nominal athwartships and alongtrack sonar beam widths in degrees, as stored in the **MBIO** descriptor pointed to by *mbio_ptr* when the file was opened (see **mb_format_beamwidth**).

−----------

int **mb_sonartype**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **sonartype*,
int **error*);

The function **mb_sonartype** returns a code (one of the **MB_TOPOGRAPHY_TYPE** values, e.g. multibeam, sidescan, interferometric, or unknown) indicating the general type of sonar that produced the current data record, where the data format and system can distinguish this.

−----------

int **mb_sidescantype**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,

int **ss_type*,
int **error*);

The function **mb_sidescantype** returns a code (one of the **MB_SIDESCAN_TYPE** values) indicating whether the sidescan imagery associated with the current data record is referenced to a linear (uncorrected) or logarithmic (corrected) intensity scale, where the data format and system can distinguish this.

−----------

int **mb_get_all**(
int *verbose*,
void **mbio_ptr*,
void ***store_ptr*,
int **kind*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **distance*,
double **altitude*,
double **sonardepth*,
int **nbath*,
int **namp*,
int **nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
char **comment*,
int **error*);

The function **mb_get_all** reads and returns sonar data according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The data is returned one record at a time; no averaging is performed. A pointer to a data structure containing all of the data read is returned as *store_ptr*; the form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record has been read. Additional data is returned if the data record is survey data (navigation, bathymetry, amplitude, and sidescan), navigation data (navigation only), or comment data (comment only).

The return values are:

store_ptr:	pointer to complete data structure	
kind:	kind of data record read	
	1	survey data
	2	comment
	3	header
	4	calibrate
	5	mean sound speed

6	SVP
7	standby
8	nav source
9	parameter
10	start
11	stop
12	nav
13	run parameter
14	clock
15	tide
16	height
17	heading
18	attitude
19	ssv
20	angle
21	event
22	history
23	summary
24	processing parameters
25	sensor parameters
26	navigation error
27	uninterpretable line

time_i: time of current ping
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond

time_d: time of current ping in seconds since 1/1/70 00:00:00

navlon: longitude

navlat: latitude

speed: ship speed in km/s

heading: ship heading in degrees

distance: distance along shiptrack since last ping in km

altitude: altitude of sonar above seafloor in m

sonardepth: depth of sonar in m

nbath: number of bathymetry values

namp: number of amplitude values

nss: number of sidescan values

beamflag: array of bathymetry flags

bath: array of bathymetry values in meters

amp: array of amplitude values in unknown units

bathacrosstrack: array of acrosstrack distances in meters corresponding to bathymetry

bathalongtrack: array of alongtrack distances in meters corresponding to bathymetry

ss: array of sidescan values in unknown units

ssacrosstrack: array of acrosstrack distances

	in meters corresponding to sidescan
ssacrosstrack:	array of alongtrack distances
	in meters corresponding to sidescan
comment:	comment string
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about read failures.

−----------

int **mb_put_all**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int *usevalues*,
int *kind*,
int *time_i[7]*,
double *time_d*,
double *navlon*,
double *navlat*,
double *speed*,
double *heading*,
int *nbath*,
int *namp*,
int *nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
char **comment*,
int **error*);

The function **mb_put_all** writes sonar data to the file listed in the **MBIO** descriptor pointed to by *MBIO_ptr*. The *verbose* value controls the standard error output verbosity of the function. A pointer to a data structure containing all of the data read is passed as *store_ptr*; the form of the data structure is determined by the sonar system associated with the format of the data being written. Additional data is passed if the data record is survey data (navigation, bathymetry, amplitude, and sidescan), navigation data (navigation only), or comment data (comment only). If the *usevalues* flag is set to 1, then the passed values will be inserted in the data structure pointed to by *store_ptr* before the data is written. If the *usevalues* flag is set to 0, the data structure pointed to by *store_ptr* will be written without modification. The values to be output are:

store_ptr:	pointer to complete data structure	
usevalues:	flag controlling use of data passed by value	
	0	do not insert into data structure before writing the data
	1	insert into data structure before writing the data
kind:	kind of data record to be written	
	1	survey data

2	comment
3	header
4	calibrate
5	mean sound speed
6	SVP
7	standby
8	nav source
9	parameter
10	start
11	stop
12	nav
13	run parameter
14	clock
15	tide
16	height
17	heading
18	attitude
19	ssv
20	angle
21	event
22	history
23	summary
24	processing parameters
25	sensor parameters
26	navigation error
27	uninterpretable line

time_i: time of current ping (used if *time_i*[0] != 0)
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond

time_d: time of current ping in seconds since 1/1/70 00:00:00 (used if *time_i*[0] = 0)

navlon: longitude

navlat: latitude

speed: ship speed in km/s

heading: ship heading in degrees

nbath: number of bathymetry values

namp: number of amplitude values

nss: number of sidescan values

beamflag: array of bathymetry flags

bath: array of bathymetry values in meters

amp: array of amplitude values in unknown units

bathacrosstrack: array of acrosstrack distances in meters corresponding to bathymetry

bathalongtrack: array of alongtrack distances in meters corresponding to bathymetry

ss: array of sidescan values in unknown units

ssacrosstrack: array of acrosstrack distances in meters corresponding to sidescan

ssacrosstrack: array of alongtrack distances
in meters corresponding to sidescan
comment: comment string

The return values are:
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about write failures.

−----------

int **mb_put_comment**(
int *verbose*,
void **mbio_ptr*,
char **comment*,
int **error*);

The function **mb_put_comment** writes a comment to the file listed in the **MBIO** descriptor pointed to by *MBIO_ptr*. The *verbose* value controls the standard error output verbosity of the function. The data is in the form of a null terminated string. The maximum length of comments varies with different data formats. In general individual comments should be less than 80 characters long to insure compatibility with all formats. The values to be output are:
comment: comment string

The return values are:
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about write failures.

−----------

int **mb_extract_platform**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
void ***platform_ptr*,
int **error*);

The function **mb_extract_platform** extracts sensor platform information (the sonar and auxiliary sensor positions and orientation offsets) embedded in the current data record, where the data format supports this, and returns it as a newly allocated platform structure pointed to by **platform_ptr* (see **mb_platform_init** below). This is used by **mb_preprocess** when a per-file or per-record platform definition is available directly from the raw data rather than from a separately supplied platform file.

−----------

int **mb_sensorhead**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **sensorhead*,
int **error*);

The function **mb_sensorhead** returns the index of the sensor head (transducer) that produced the current data record, for multi-head sonar systems (e.g. the Kraken/RESON WISSL laser system) where the data format distinguishes among heads.

−----------

int **mb_preprocess**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
void **platform_ptr*,
void **preprocess_pars_ptr*,
int **error*);

The function **mb_preprocess** applies sensor offset, timing, and navigation/attitude merging corrections to the current data record read by *mbio_ptr*, using the platform model pointed to by *platform_ptr* (see **mb_platform_init**) and the options and merge navigation/attitude time series pointed to by *preprocess_pars_ptr* (a *struct mb_preprocess_struct*, filled in by the calling program, typically **mbpreprocess**). If the data format has registered its own preprocessing routine, that routine is called; otherwise **mb_preprocess_generic** is called so that platform-based preprocessing is available for every supported data format.

−----------

int **mb_preprocess_generic**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
void **platform_ptr*,
void **preprocess_pars_ptr*,
int **error*);

The function **mb_preprocess_generic** implements the format-independent (generic) version of the preprocessing corrections applied by **mb_preprocess**, operating solely through the standard **MBIO mb_extract**/**mb_insert** family of functions. It is used automatically by **mb_preprocess** for any data format that has not registered a format-specific preprocessing routine of its own.

−----------

int **mb_extract**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
int **nbath*,
int **namp*,
int **nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,

double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
char **comment*,
int **error*);

The function **mb_extract** extracts sonar data from the structure pointed to by **store_ptr* according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is stored in **store_ptr*. Additional data is returned if the data record is survey data (navigation, bathymetry, amplitude, and sidescan), navigation data (navigation only), or comment data (comment only).

The return values are:

kind:	kind of data record read 1 survey data 2 comment 12 navigation
time_i:	time of current ping *time_i*[0]: year *time_i*[1]: month *time_i*[2]: day *time_i*[3]: hour *time_i*[4]: minute *time_i*[5]: second *time_i*[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
distance:	distance along shiptrack since last ping in km
altitude:	altitude of sonar above seafloor in m
sonardepth:	depth of sonar in m
nbath:	number of bathymetry values
namp:	number of amplitude values
nss:	number of sidescan values
beamflag:	array of bathymetry flags
bath:	array of bathymetry values in meters
amp:	array of amplitude values in unknown units
bathacrosstrack:	array of acrosstrack distances in meters corresponding to bathymetry
bathalongtrack:	array of alongtrack distances in meters corresponding to bathymetry
ss:	array of sidescan values in unknown units
ssacrosstrack:	array of acrosstrack distances in meters corresponding to sidescan
ssalongtrack:	array of alongtrack distances

in meters corresponding to sidescan
comment: comment string
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about extract failures.

−----------

int **mb_extract_lonlat**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
int **nbath*,
int **namp*,
int **nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathlon*,
double **bathlat*,
double **ss*,
double **sslon*,
double **sslat*,
char **comment*,
int **error*);

The function **mb_extract_lonlat** extracts sonar data from the structure pointed to by **store_ptr* according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is stored in **store_ptr*. Additional data is returned if the data record is survey data (navigation, bathymetry, amplitude, and sidescan), navigation data (navigation only), or comment data (comment only).

The return values are:

kind: kind of data record read
1 survey data
2 comment
12 navigation

time_i: time of current ping
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second

time_i[6]: microsecond
time_d: time of current ping in seconds since 1/1/70 00:00:00
navlon: longitude
navlat: latitude
speed: ship speed in km/s
heading: ship heading in degrees
distance: distance along shiptrack since last ping in km
altitude: altitude of sonar above seafloor in m
sonardepth: depth of sonar in m
nbath: number of bathymetry values
namp: number of amplitude values
nss: number of sidescan values
beamflag: array of bathymetry flags
bath: array of bathymetry values in meters
amp: array of amplitude values in unknown units
bathlon: array of longitude positions in degrees corresponding to bathymetry
bathlat: array of latitude positions in degrees corresponding to bathymetry
ss: array of sidescan values in unknown units
sslon: array of longitude positions in degrees corresponding to sidescan
sslat: array of latitude positions in degrees corresponding to sidescan
comment: comment string
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about extract failures.

−--
int **mb_insert**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int *kind*,
int *time_i[7]*,
double *time_d*,
double *navlon*,
double *navlat*,
double *speed*,
double *heading*,
int *nbath*,
int *namp*,
int *nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,

double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
char **comment*,
int **error*);

The function **mb_insert** inserts sonar data into the structure pointed to by **store_ptr* according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is to be stored in **store_ptr*. Data will be inserted only if the data record is survey data (navigation, bathymetry, amplitude, and sidescan), navigation data (navigation only), or comment data (comment only). The values to be inserted are:

kind: kind of data record inserted
- 1 survey data
- 2 comment
- 12 navigation

time_i: time of current ping
- *time_i*[0]: year
- *time_i*[1]: month
- *time_i*[2]: day
- *time_i*[3]: hour
- *time_i*[4]: minute
- *time_i*[5]: second
- *time_i*[6]: microsecond

time_d: time of current ping in seconds since 1/1/70 00:00:00

navlon: longitude

navlat: latitude

speed: ship speed in km/s

heading: ship heading in degrees

distance: distance along shiptrack since last ping in km

altitude: altitude of sonar above seafloor in m

sonardepth: depth of sonar in m

nbath: number of bathymetry values

namp: number of amplitude values

nss: number of sidescan values

beamflag: array of bathymetry flags

bath: array of bathymetry values in meters

amp: array of amplitude values in unknown units

bathacrosstrack: array of acrosstrack distances in meters corresponding to bathymetry

bathalongtrack: array of alongtrack distances in meters corresponding to bathymetry

ss: array of sidescan values in unknown units

ssacrosstrack: array of acrosstrack distances in meters corresponding to sidescan

ssacrosstrack: array of alongtrack distances in meters corresponding to sidescan

comment: comment string

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about insert failures.

−----------

int **mb_extract_nav**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **draft*,
double **roll*,
double **pitch*,
double **heave*,
int **error*);

The function **mb_extract_nav** extracts navigation data from the structure pointed to by **store_ptr* according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is stored in **store_ptr*. Navigation data is returned if the data record is survey data (navigation, bathymetry, amplitude, and sidescan) or navigation data (navigation only).

The return values are:

kind: kind of data record read
1 survey data
12 navigation

time_i: time of current ping
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond

time_d: time of current ping in seconds since 1/1/70 00:00:00

navlon: longitude

navlat: latitude

speed: ship speed in km/s

heading: ship heading in degrees

draft: sonar depth in meters

roll: sonar roll in degrees

pitch: sonar pitch in degrees

heave: sonar heave in meters

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about extract failures.

−----------

int **mb_extract_nnav**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int *nmax*,
int **kind*,
int **n*,
int **time_i*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **draft*,
double **roll*,
double **pitch*,
double **heave*,
int **error*);

The function **mb_extract_nnav** extracts navigation in the same manner as **mb_extract_nav**, except that it returns as many as *nmax* navigation fixes associated with the current data record (some data formats, and the internally buffered asynchronous navigation used by **mb_navint_add** and related functions, can associate more than one navigation fix with a single survey ping). The number of fixes actually returned is placed in **n*, and the arrays *time_i*, *time_d*, *navlon*, *navlat*, *speed*, *heading*, *draft*, *roll*, *pitch*, and *heave* must each be allocated by the calling program to hold at least *nmax* values.

−----------

int **mb_insert_nav**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int *time_i[7]*,
double *time_d*,
double *navlon*,
double *navlat*,
double *speed*,
double *heading*,
double *draft*,
double *roll*,
double *pitch*,
double *heave*,
int **error*);

The function **mb_insert_nav** inserts navigation data into the structure pointed to by **store_ptr* according to the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is to be stored in **store_ptr*. Data will be inserted only if the data record is survey data (navigation, bathymetry, amplitude, and sidescan), or navigation data (navigation only). The values

to be inserted are:

time_i:	time of current ping
	time_i[0]: year
	time_i[1]: month
	time_i[2]: day
	time_i[3]: hour
	time_i[4]: minute
	time_i[5]: second
	time_i[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
draft:	sonar depth in meters
roll:	sonar roll in degrees
pitch:	sonar pitch in degrees
heave:	sonar heave in meters

The return values are:

error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about insert failures.

−----------

int **mb_extract_altitude**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
double **transducer_depth*,
double **altitude*,
int **error*);

The function **mb_extract_altitude** extracts the sonar transducer depth (**transducer_depth**) below the sea surface and the the sonar transducer **altitude** above the seafloor according to the **MBIO** descriptor pointed to by *mbio_ptr*. This function is not defined for all data formats. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is stored in **store_ptr*. These data are returned only if the data record is survey data. These values are useful for sidescan processing applications. Both transducer depths and altitudes are reported in meters.

The return values are:

kind:	kind of data record read (error if not survey data):
	1 survey data
transducer_depth:	depth of sonar in meters
altitude:	altitude of sonar above seafloor in meters.
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data extraction failures.

−----------

int **mb_insert_altitude**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
double *transducer_depth*,
double *altitude*,
int **error*);

The function **mb_insert_altitude** inserts sonar depth and altitude data into the structure pointed to by **store_ptr* according to the **MBIO** descriptor pointed to by *mbio_ptr*. This function is not defined for all data formats. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**. Data will be inserted only if the data record is survey data (navigation, bathymetry, amplitude, and sidescan). The values to be inserted are:

transducer_depth: depth of sonar in meters
altitude: altitude of sonar in meters

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about insert failures.

−----------

int **mb_extract_svp**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int **nsvp*,
double **depth*,
double **velocity*,
int **error*);

The function **mb_extract_svp** extracts a water sound velocity profile according to the **MBIO** descriptor pointed to by *mbio_ptr*. This function is not defined for all data formats. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**; the *kind* value indicates which type of record is stored in **store_ptr*. These data are returned only if the data record is a sound velocity profile record. These values are useful for calculating bathymetry from travel times and beam angles.

The return values are:

kind: kind of data record read (error if not SVP data):
6 SVP data
nsvp: number of depth and sound speed data in the profile
depth: array of depths in meters

velocity: array of sound speeds in m/sec
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data extraction failures.

−----------

int **mb_insert_svp**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int *nsvp*,
double **depth*,
double **velocity*,
int **error*);

The function **mb_insert_svp** inserts a water sound velocity profile according to the **MBIO** descriptor pointed to by *mbio_ptr*. This function is not defined for all data formats. The *verbose* value controls the standard error output verbosity of the function. The form of the data structure is determined by the sonar system associated with the format of the data being read. A number of different data record types are recognized by **MB-System**. These data are inserted only if the data record is a sound velocity profile record. These values are useful for calculating bathymetry from travel times and beam angles. The inserted values are:

nsvp: number of depth and sound speed data in the profile
depth: array of depths in meters
velocity: array of sound speeds in m/sec

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data insertion failures.

−----------

int **mb_ttimes**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int **nbeams*,
double **ttimes*,
double **angles*,
double **angles_forward*,
double **angles_null*,
double **heave*,
double **alongtrack_offset*,
double **draft*,
double **ssv*,
int **error*);

The function **mb_ttimes** extracts travel times and beam angles from a sonar-specific data structure pointed to by *store_ptr*. These values are used for calculating swath bathymetry. The *verbose* value controls the standard error output verbosity of the function. The coordinates of the beam angles can be a bit confusing. The angles

are returned in "takeoff angle coordinates" appropriate for raytracing. The array angles contains the angle from vertical and the array angles_forward contains the angle from acrosstrack. This coordinate system is distinct from the roll-pitch coordinates appropriate for correcting roll and pitch values. A description of these relevant coordinate systems is given below. The **angles_null** array contains the effective sonar array orientation for each beam. The **angles_null** array may be used to correct beam angles using Snell's law if the **ssv** is changed. The **angles_null** values reflect the sonar configuration. For example, some multibeam sonars have a flat transducer array, and so the **angles_null** array consists of **nbeams** zero values. Other multibeams have circular arrays so that the **angles_null** values equal the **angles** values. The **alongtrack_offset** array accommodates sonars which report multiple pings in a single survey record; each ping occurs at a different position along the shiptrack, producing alongtrack offsets relative to the navigation for some beam values. The sum of the **draft** value and the **heave** array values gives the depth of the sonar for each beam. For hull mounted installations the **draft** value is generally static but the **heave** values vary with time. For towed sonars the **draft** varies with time and the **heave** values are typically zero. The **ssv** value gives the water sound velocity at the sonar array.

The return values are:

kind:	kind of data record read (error if not survey data): 1 survey data
nbeams:	number of beams
ttimes:	array of two-way travel times in seconds
angles:	array of angles from vertical in degrees
angles_forward:	array of angles from acrosstrack in degrees
angles_null:	array of sonar array orientation in degrees
heave:	array of heave values for each beam in meters
alongtrack_offset:	array of alongtrack distance offsets for each beam in meters
draft:	draft of sonar in meters
ssv:	water sound velocity at sonar in m/seconds
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data extraction failures.

−----------

int **mb_detects**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int **nbeams*,
int **detects*,
int **error*);

The function **mb_detects** extracts beam bottom detect types from a sonar-specific data structure pointed to by *store_ptr*. These values indicate whether the depth value associated with a particular beam i derived from an amplitude detect (e.g. detects[i] = 1), a phase detect (e.g. detects[i] = 2), or the algorithm is unknown (e.g. detects[i] = 0). The *verbose* value controls the standard error output verbosity of the function.

The return values are:

kind:	kind of data record read (error if not survey data): 1 survey data

nbeams: number of beams
detects: array of *nbeams* bottom detect algorithm flags
0 = unknown 1 = amplitude detect 2 = phase detect
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data extraction failures. This functionality is available for only a subset of the supported sonars. If the corresponding low level routine is undefined, **error* will be set to MB_ERROR_BAD_SYSTEM (14).

−----------

int **mb_gains**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
double **transmit_gain*,
double **pulse_length*,
double **receive_gain*,
int **error*);

The function **mb_gains** extracts the most basic gain settings from a sonar-specific data structure pointed to by *store_ptr*. In many cases, sonars have more complicated gain functions, particularly with respect to the receiver TVG function. In those cases, the receive gain returned here refers to the constant gain setting and does not include any TVG parameters. The *verbose* value controls the standard error output verbosity of the function.

The return values are:
kind: kind of data record read (error if not survey data):
1 survey data
transmit_gain: transmit gain (dB)
pulse_length: transmit pulse length (sec)
receive_gain: receive gain (dB)
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data extraction failures. This functionality is available for only a subset of the supported sonars. If the corresponding low level routine is undefined, **error* will be set to MB_ERROR_BAD_SYSTEM (14).

−----------

int **mb_pulses**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int **nbeams*,
int **pulses*,
int **error*);

The function **mb_pulses** extracts, for each of the **nbeams* beams of the current data record, a code indicating

the type of transmit pulse (e.g. CW or FM chirp) used to obtain that beam, where the data format and sonar system record this information.

−----------

int **mb_sonarsettings**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
double **frequency*,
double **sample_rate*,
double **tx_pulse_width*,
double **power_selection*,
double **gain_selection*,
double **absorption*,
double **spreading*,
double **sound_velocity*,
double **beamwidth_tx*,
double **beamwidth_rx*,
int **error*);

The function **mb_sonarsettings** extracts the sonar transmit and receive settings (operating frequency, sample rate, transmit pulse width, power and gain selections, assumed absorption and spreading coefficients, assumed sound velocity, and transmit and receive beam widths) in effect for the current data record. This functionality is available for only a subset of the supported sonars; if the corresponding low level routine is undefined, **error* will be set to MB_ERROR_BAD_SYSTEM (14).

−----------

int **mb_makess**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int *pixel_size_set*,
double **pixel_size*,
int *swath_width_set*,
double **swath_width*,
int *pixel_int*,
int **error*);

The function **mb_makess** constructs a processed sidescan swath (uniformly spaced in acrosstrack distance) from the raw sidescan and/or bathymetry of the current data record. If *pixel_size_set* is nonzero, **pixel_size* is used as supplied; otherwise a pixel size is calculated automatically and returned in **pixel_size*. Likewise, if *swath_width_set* is nonzero **swath_width* is used as supplied, and otherwise a swath width is calculated and returned. If *pixel_int* is nonzero, pixels with no assigned sidescan value are interpolated from neighboring pixels. The resulting processed sidescan values are stored back into the sonar-specific structure pointed to by *store_ptr* for later extraction by **mb_extract** or **mb_get_all**.

−----------

int **mb_extract_rawssdimensions**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,

double **sample_interval*,
int **num_samples_port*,
int **num_samples_stbd*,
int **error*);

The function **mb_extract_rawssdimensions** returns the sample interval and the numbers of port and starboard side raw sidescan samples available in the current data record, without extracting the raw sidescan sample values themselves. This allows a program to size arrays appropriately before calling **mb_extract_rawss**.

−----------

int **mb_extract_rawss**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int **sidescan_type*,
double **sample_interval*,
double **beamwidth_xtrack*,
double **beamwidth_ltrack*,
int **num_samples_port*,
double **rawss_port*,
int **num_samples_stbd*,
double **rawss_stbd*,
int **error*);

The function **mb_extract_rawss** extracts the "raw" (as opposed to slant-range-corrected or otherwise processed) sidescan sample arrays for the port and starboard sides of the current data record, where the data format supports this. Since the meaning of "raw" sidescan and the way it is stored varies greatly among sonars, the values of **sidescan_type*, **sample_interval*, **beamwidth_xtrack*, and **beamwidth_ltrack* allow the calling program to interpret the returned sample arrays **rawss_port* and **rawss_stbd* (of length **num_samples_port* and **num_samples_stbd* respectively) correctly. This function is not implemented for all data formats.

−----------

int **mb_insert_rawss**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int *kind*,
int *sidescan_type*,
double *sample_interval*,
double *beamwidth_xtrack*,
double *beamwidth_ltrack*,
int *num_samples_port*,
double **rawss_port*,
int *num_samples_stbd*,
double **rawss_stbd*,
int **error*);

The function **mb_insert_rawss** inserts "raw" port and starboard sidescan sample arrays into the data record pointed to by *store_ptr*, where the data format supports this. The parameters have the same meaning as the corresponding return values of **mb_extract_rawss**. This function is not implemented for all data formats.

−----------

int **mb_extract_segytraceheader**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
void **segytraceheader_ptr*,
int **error*);

The function **mb_extract_segytraceheader** extracts a **SEGY** trace header (a *struct mb_segytraceheader_struct*, supplied by the calling program and filled in by this function) describing the current data record, for data formats that carry subbottom profiler or other seismic reflection data that can be represented in **SEGY** form (see the **mbsegylist** and **mbsegygrid** manual pages).

−----------

int **mb_extract_segy**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **sampleformat*,
int **kind*,
void **segytraceheader_ptr*,
float **segydata*,
int **error*);

The function **mb_extract_segy** extracts both the **SEGY** trace header (as does **mb_extract_segytraceheader**) and the associated trace sample data for the current data record, placing the samples in the array **segydata* (allocated by the calling program to hold at least *nsamp* values as specified in the trace header). The value **sampleformat* indicates how the trace samples are to be interpreted (e.g. **MB_SEGY_SAMPLEFORMAT_TRACE**, **MB_SEGY_SAMPLEFORMAT_ENVELOPE**, or **MB_SEGY_SAMPLEFORMAT_ANALYTIC**).

−----------

int **mb_insert_segy**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int *kind*,
void **segytraceheader_ptr*,
float **segydata*,
int **error*);

The function **mb_insert_segy** inserts a **SEGY** trace header and its associated trace sample data into the data record pointed to by *store_ptr*, where the data format supports this. The parameters have the same meaning as the corresponding arguments of **mb_extract_segy**.

−----------

int **mb_ctd**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int **nctd*,

double **time_d*,
double **conductivity*,
double **temperature*,
double **depth*,
double **salinity*,
double **soundspeed*,
int **error*);

The function **mb_ctd** extracts a set of **nctd* CTD (conductivity-temperature-depth) measurements associated with the current data record, where the data format carries CTD data (e.g. some AUV data formats). The arrays *time_d*, *conductivity*, *temperature*, *depth*, *salinity*, and *soundspeed* must each be allocated by the calling program to hold at least **MB_CTD_MAX** values.

−----------

int **mb_ancilliarysensor**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
int **kind*,
int **nsensor*,
double **time_d*,
double **sensor1*,
double **sensor2*,
double **sensor3*,
double **sensor4*,
double **sensor5*,
double **sensor6*,
double **sensor7*,
double **sensor8*,
int **error*);

The function **mb_ancilliarysensor** extracts a set of **nsensor* time-stamped samples from up to eight generic auxiliary sensor channels associated with the current data record, where the data format carries such data (e.g. some AUV data formats). The arrays *time_d*, *sensor1* through *sensor8* must each be allocated by the calling program to hold at least **MB_CTD_MAX** values.

−----------

int **mb_copyrecord**(
int *verbose*,
void **mbio_ptr*,
void **store_ptr*,
void **copy_ptr*,
int **error*);

The function **mb_copyrecord** copies the sonar-specific data structure pointed to by *store_ptr* into the data structure pointed to by **copy_ptr*. The data structures must already have been allocated.

The return values are:
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about data copy failures.

−----------

int **mb_indextable**(
int *verbose*,
void **mbio_ptr*,
int **num_indextable*,
void ***indextable_ptr*,
int **error*);

The function **mb_indextable** returns the number of entries **num_indextable* and a pointer **indextable_ptr* to an index table built by **MBIO** while reading the file associated with *mbio_ptr*. Each entry of the index table records the byte offset, kind, and time of a data record already read, allowing an application (e.g. **mbindex** or **mbnavadjust**) to later seek directly to particular records without a further sequential read.

−----------

int **mb_indextablefix**(
int *verbose*,
void **mbio_ptr*,
int *num_indextable*,
void **indextable_ptr*,
int **error*);

The function **mb_indextablefix** passes an index table of *num_indextable* entries (typically obtained from **mb_indextable** and possibly edited by the calling program) to the format-specific fixing routine registered for the file associated with *mbio_ptr*, where the data format supports this. This is used to make in-place corrections to records identified by the index table.

−----------

int **mb_indextableapply**(
int *verbose*,
void **mbio_ptr*,
int *num_indextable*,
void **indextable_ptr*,
int *n_file*,
int **error*);

The function **mb_indextableapply** applies an index table of *num_indextable* entries to the *n_file*th parallel data file (see **mb_format_info**) associated with *mbio_ptr*, using the format-specific apply routine registered for that format, where the data format supports this.

LEVEL 3 FUNCTIONS

int **mb_buffer_init**(
int *verbose*,
void ***buff_ptr*,
int **error*);

The function **mb_buffer_init** initializes the data structures required for buffered i/0. A pointer to the buffer data structure is returned as **buff_ptr*. The *verbose* value controls the standard error output verbosity of the function.

The return values are:

**buff_ptr*:	pointer to buffer structure
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer initialization failures.

−----------

int **mb_buffer_close**(
int *verbose*,
void ***buff_ptr*,
void **mbio_ptr*,
int **error*);

The function **mb_buffer_close** releases all memory allocated for buffered i/0, including the structure pointed to by **buff_ptr*. The *verbose* value controls the standard error output verbosity of the function.

The return values are:
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer deallocation failures.

−----------

int **mb_buffer_load**(
int *verbose*,
void **buff_ptr*,
void **mbio_ptr*,
int *nwant*,
int **nload*,
int **nbuff*,
int **error*);

The function **mb_buffer_load** loads data into the buffer pointed to by *buff_ptr* from the input file initialized in the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:
nwant: The number of data records desired
in the buffer.

The returned values are:
nload: The number of data records loaded into the buffer.
nbuff: The total number of data records in the buffer after loading.
error: error value

The buffer may already contain data records when the **mb_buffer_load** call is made; if the number of previously loaded records is less than *nwant*, the function will attempt to read and load records until a total of *nwant* records are loaded. The *nload* value is the number of data records loaded during the current function call, and the *nbuff* value is the number of data records in the buffer at the completion of the **mb_buffer_load** call. A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer deallocation failures.

−----------

int **mb_buffer_dump**(
int *verbose*,
void **buff_ptr*,

void **mbio_ptr*,
void **ombio_ptr*,
int *nhold*,
int **ndump*,
int **nbuff*,
int **error*);

The function **mb_buffer_dump** dumps data from the buffer pointed to by **buff_ptr* into the output file initialized in the **MBIO** descriptor pointed to by *ombio_ptr*. The data in the buffer were read from the input file initialized in the **MBIO** descriptor pointed to by *mbio_ptr*. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

nhold: The number of data records desired to be held in the buffer.

The returned values are:

nload: The number of data records dumped from the buffer.
nbuff: The total number of data records in the buffer after dumping.
error: error value

If the number of loaded records is more than *nhold*, the function will attempt to write out records from the beginning of the buffer until *nhold* records are left in the buffer. The *ndump* value is the number of data records dumped during the current function call, and the *nbuff* value is the number of data records in the buffer at the completion of the **mb_buffer_dump** call. A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer deallocation failures.

−----------

int **mb_buffer_clear**(
int *verbose*,
void **buff_ptr*,
void **mbio_ptr*,
int *nhold*,
int **ndump*,
int **nbuff*,
int **error*);

The function **mb_buffer_clear** removes data from the buffer pointed to by **buff_ptr* without writing those data records to an output file. An **MBIO** descriptor pointed to by *mbio_ptr* is still required, and generally represents the **MBIO** descriptor used to read and load the data originally. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

nhold: The number of data records desired to be held in the buffer.

The returned values are:

ndump: The number of data records cleared from the buffer.
nbuff: The total number of data records in the buffer after dumping.
error: error value

If the number of loaded records is more than *nhold*, the function will attempt to clear out records from the beginning of the buffer until *nhold* records are left in the buffer. The *ndump* value is the number of data records

cleared during the current function call, and the *nbuff* value is the number of data records in the buffer at the completion of the **mb_buffer_dump** call. A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer deallocation failures.

−----------

int **mb_buffer_get_kind**(
int *verbose*,
void **buff_ptr*,
void **mbio_ptr*,
int *id*,
int **kind*,
int **error*);

The function **mb_buffer_get_kind** returns the data record kind **kind* (e.g. survey data, comment, navigation) of the buffer entry numbered *id* in the buffer pointed to by **buff_ptr*. An **MBIO** descriptor pointed to by *mbio_ptr* is still required, and generally represents the **MBIO** descriptor used to read and load the data originally. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

id:	id number of the data record of interest

The returned values are:

kind:	kind of data record found
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_buffer_get_next_data**(
int *verbose*,
void **buff_ptr*,
void **mbio_ptr*,
int *start*,
int **id*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
int **nbath*,
int **namp*,
int **nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
int **error*);

The function **mb_buffer_get_next_data** searches for the next survey data record in the buffer, beginning at buffer index *start*. Since buffer indexes begin at 0, the first call to **mb_buffer_get_next_data** should have *start* = 0. If a survey data record is found at or beyond *start*, **mb_buffer_get_next_data** returns the buffer index of that record in *id*. Data is also returned in the forms of bathymetry, amplitude, and sidescan survey data. No comments or other non-survey data records are returned. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

start:	The buffer index at which to start searching for a survey data record.

The returned values are:

id:	The buffer index of the first survey data record at or after *start*.
time_i:	time of current ping *time_i*[0]: year *time_i*[1]: month *time_i*[2]: day *time_i*[3]: hour *time_i*[4]: minute *time_i*[5]: second *time_i*[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
nbath:	number of bathymetry values
namp:	number of amplitude values
nss:	number of sidescan values
beamflag:	array of bathymetry flags
bath:	array of bathymetry values in meters
amp:	array of amplitude values in unknown units
bathacrosstrack:	array of acrosstrack distances in meters corresponding to bathymetry
bathalongtrack:	array of alongtrack distances in meters corresponding to bathymetry
ss:	array of sidescan values in unknown units
ssacrosstrack:	array of acrosstrack distances in meters corresponding to sidescan
ssacrosstrack:	array of alongtrack distances in meters corresponding to sidescan
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures. The most common error occurs when no more survey data records remain to be found in the buffer; in this case, *error* = −14.

−----------

int **mb_buffer_extract**(
int *verbose*,
void **buff_ptr*,

void **mbio_ptr*,
int *id*,
int **kind*,
int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
int **nbath*,
int **namp*,
int **nss*,
char **beamflag*,
double **bath*,
double **amp*,
double **bathacrosstrack*,
double **bathalongtrack*,
double **ss*,
double **ssacrosstrack*,
double **ssalongtrack*,
char **comment*,
int **error*);

The function **mb_buffer_extract** extracts and returns a subset of the data in a buffer record. The *verbose* value controls the standard error output verbosity of the function. The buffer record is specified with the buffer index *id*. The data is either in the form of bathymetry, amplitude, and sidescan survey data or a comment string.

The input control parameters have the following significance:

id: The buffer index of the data record to extract.

The returned values are:

kind: kind of data record extracted

1	survey data
2	comment
>=3	other data that cannot be passed by **mb_buffer_extract**

time_i: time of current ping
time_i[0]: year
time_i[1]: month
time_i[2]: day
time_i[3]: hour
time_i[4]: minute
time_i[5]: second
time_i[6]: microsecond

time_d: time of current ping in seconds since 1/1/70 00:00:00

navlon: longitude

navlat: latitude

speed: ship speed in km/s

heading: ship heading in degrees

nbath: number of bathymetry values

namp: number of amplitude values
nss: number of sidescan values
beamflag: array of bathymetry flags
bath: array of bathymetry values in meters
amp: array of amplitude values in unknown units
bathacrosstrack: array of acrosstrack distances in meters corresponding to bathymetry
bathalongtrack: array of alongtrack distances in meters corresponding to bathymetry
ss: array of sidescan values in unknown units
ssacrosstrack: array of acrosstrack distances in meters corresponding to sidescan
ssacrosstrack: array of alongtrack distances in meters corresponding to sidescan
comment: comment string
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about extract failures.

```
-----------------------------------------------------
int mb_buffer_insert(
                int verbose,
                void *buff_ptr,
                void *mbio_ptr,
                int id,
                int time_i[7],
                double time_d,
                double navlon,
                double navlat,
                double speed,
                double heading,
                int nbath,
                int namp,
                int nss,
                char *beamflag,
                double *bath,
                double *amp,
                double *bathacrosstrack,
                double *bathalongtrack,
                double *ss,
                double *ssacrosstrack,
                double *ssalongtrack,
                char *comment,
                int *error);
```

The function **mb_buffer_insert** inserts data into a buffer record, replacing a subset of the original values. The *verbose* value controls the standard error output verbosity of the function. The buffer record is specified with the buffer index *id*. The data is either in the form of bathymetry, amplitude, and sidescan survey data or a comment string.

The input control parameters have the following significance:
id: The buffer index of the data

record to insert.

The returned values are:

kind:	kind of data record inserted 1 survey data 2 comment >=3 other data that cannot be passed by **mb_buffer_insert**
time_i:	time of current ping *time_i*[0]: year *time_i*[1]: month *time_i*[2]: day *time_i*[3]: hour *time_i*[4]: minute *time_i*[5]: second *time_i*[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
nbath:	number of bathymetry values
namp:	number of amplitude values
nss:	number of sidescan values
beamflag:	array of bathymetry flags
bath:	array of bathymetry values in meters
amp:	array of amplitude values in unknown units
bathacrosstrack:	array of acrosstrack distances in meters corresponding to bathymetry
bathalongtrack:	array of alongtrack distances in meters corresponding to bathymetry
ss:	array of sidescan values in unknown units
ssacrosstrack:	array of acrosstrack distances in meters corresponding to sidescan
ssacrosstrack:	array of alongtrack distances in meters corresponding to sidescan
comment:	comment string

The returned values are:

error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about insert failures.

−----------

int **mb_buffer_get_next_nav**(
int *verbose*,
void **buff_ptr*,
void **mbio_ptr*,
int *start*,
int **id*,
int *time_i[7]*,

double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **draft*,
double **roll*,
double **pitch*,
double **heave*,
int **error*);

The function **mb_buffer_get_next_nav** searches for the next survey data record in the buffer, beginning at buffer index *start*. Since buffer indexes begin at 0, the first call to **mb_buffer_get_next_nav** should have *start* = 0. If a survey data record is found at or beyond *start*, **mb_buffer_get_next_nav** returns the buffer index of that record in *id*. Navigation and vertical reference sensor data is also returned. No comments or other non-survey data records are returned. The *verbose* value controls the standard error output verbosity of the function.

The input control parameters have the following significance:

start:	The buffer index at which to start searching for a survey data record.

The returned values are:

id:	The buffer index of the first survey data record at or after *start*.
time_i:	time of current ping *time_i*[0]: year *time_i*[1]: month *time_i*[2]: day *time_i*[3]: hour *time_i*[4]: minute *time_i*[5]: second *time_i*[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
roll:	ship roll in degrees
pitch:	ship pitch in degrees
heave:	ship heave in meters

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures. The most common error occurs when no more survey data records remain to be found in the buffer; in this case, *error* = −14.

−----------

int **mb_buffer_extract_nav**(
int *verbose*,
void **buff_ptr*,
void **mbio_ptr*,
int *id*,
int **kind*,

int *time_i[7]*,
double **time_d*,
double **navlon*,
double **navlat*,
double **speed*,
double **heading*,
double **draft*,
double **roll*,
double **pitch*,
double **heave*,
int **error*);

The function **mb_buffer_extract_nav** extracts and returns a subset of the data in a buffer record. The *verbose* value controls the standard error output verbosity of the function. The buffer record is specified with the buffer index *id*. The data returned consists of navigation and vertical reference sensor data.

The input control parameters have the following significance:

id:	The buffer index of the data record to extract.

The returned values are:

kind:	kind of data record extracted
	1 survey data
	2 comment
	>=3 other data that cannot be passed by **mb_buffer_extract_nav**
time_i:	time of current ping
	time_i[0]: year
	time_i[1]: month
	time_i[2]: day
	time_i[3]: hour
	time_i[4]: minute
	time_i[5]: second
	time_i[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
roll:	ship roll in degrees
pitch:	ship pitch in degrees
heave:	ship heave in meters

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about extract failures.

−----------
int **mb_buffer_insert_nav**(
int *verbose*,
void **buff_ptr*,
void **mbio_ptr*,
int *id*,

int *time_i[7]*,
double *time_d*,
double *navlon*,
double *navlat*,
double *speed*,
double *heading*,
double *draft*,
double *roll*,
double *pitch*,
double *heave*,
int **error*);

The function **mb_buffer_insert_nav** inserts navigation and vertical reference sensor data into a buffer record, replacing a subset of the original values. The *verbose* value controls the standard error output verbosity of the function. The buffer record is specified with the buffer index *id*.

The input control parameters have the following significance:

id:	The buffer index of the data record to insert.

The returned values are:

kind:	kind of data record inserted 1 survey data 2 comment >=3 other data that cannot be passed by **mb_buffer_insert_nav**
time_i:	time of current ping *time_i*[0]: year *time_i*[1]: month *time_i*[2]: day *time_i*[3]: hour *time_i*[4]: minute *time_i*[5]: second *time_i*[6]: microsecond
time_d:	time of current ping in seconds since 1/1/70 00:00:00
navlon:	longitude
navlat:	latitude
speed:	ship speed in km/s
heading:	ship heading in degrees
roll:	ship roll in degrees
pitch:	ship pitch in degrees
heave:	ship heave in meters

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about insert failures.

−----------

int **mb_buffer_get_ptr**(
int *verbose*,
void **buff_ptr*,
void **mbio_ptr*,
int *id*,

void ***store_ptr*,
int **error*);

The function **mb_buffer_get_ptr** returns a pointer to the data structure in a buffer record. The *verbose* value controls the standard error output verbosity of the function. The buffer record is specified with the buffer index *id*. The data returned consists of a pointer to the data structure stored in the specified buffer record.

The input control parameters have the following significance:

id: The buffer index of the data record to locate.

The return values are:

**store_ptr*: pointer to data in specified buffer record
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about buffer failures.

MISCELLANEOUS FUNCTIONS

int **mb_version**(
int *verbose*,
char **version_string*,
int **version_id*,
int **version_major*,
int **version_minor*,
int **version_archive*,
int **error*);

The function **mb_version** returns the **MB-System** release version as both a string **version_string* (e.g. "5.8.0") and, parsed from that string, the major, minor, and archive version numbers and a single combined numeric **version_id* (e.g. version 5.8.2303 becomes 50802303) suitable for numeric comparisons.

−----------

int **mb_user_host_date**(
int *verbose*,
char *user[256]*,
char *host[256]*,
char *date[32]*,
int **error*);

The function **mb_user_host_date** returns the current user name *user* (from the **USER** or **LOGNAME** environment variable), host name *host*, and current date and time *date* as strings. This is used by many **MB-System** programs to record who processed a file, on what machine, and when, typically in a processing comment record.

−----------

int **mb_default_defaults**(
int *verbose*,
int **format*,
int **pings*,
int **lonflip*,
double *bounds[4]*,

int **btime_i*,
int **etime_i*,
double **speedmin*,
double **timegap*);

The function **mb_default_defaults** sets the hardwired **MBIO** default control parameter values in the same manner as **mb_defaults** below, but without consulting a possible *.mbio_defaults* file in the user's home directory.

−----------

int **mb_defaults**(
int *verbose*,
int **format*,
int **pings*,
int **lonflip*,
double *bounds[4]*,
int **btime_i*,
int **etime_i*,
double **speedmin*,
double **timegap*);

The function **mb_defaults** provides default values of control parameters used by some of the **MBIO** functions. The *verbose* value controls the standard error output verbosity of the function. The other parameters are set by the function; the meaning of these parameters is discussed in the listings of the functions **mb_read_init** and **mb_write_init**. If an .mbio_defaults file exists in the user's home directory, the lonflip and timegap defaults are read from this file. Otherwise, the values are set as:

**lonflip* = 0
**timegap* = 1

The other values are simply set as:

**format* = 0
**pings* = 1
bounds[0] = −360.
bounds[1] = 360.
bounds[2] = −90.
bounds[3] = 90.
btime_i[0] = 1962;
btime_i[1] = 2;
btime_i[2] = 21;
btime_i[3] = 10;
btime_i[4] = 30;
btime_i[5] = 0;
btime_i[6] = 0;
etime_i[0] = 2062;
etime_i[1] = 2;
etime_i[2] = 21;
etime_i[3] = 10;
etime_i[4] = 30;
etime_i[5] = 0;
etime_i[6] = 0;
**speedmin* = 0.0

A status value is returned to indicate success or failure.

−----------

int **mb_lonflip**(
int *verbose*,
int **lonflip*);

The function **mb_lonflip** returns just the default **lonflip* value described above under **mb_defaults**, reading it from a *.mbio_defaults* file in the user's home directory if one exists (otherwise 0).

−----------

int **mb_fbtversion**(
int *verbose*,
int **fbtversion*);

The function **mb_fbtversion** returns the version number of the fast bathymetry (*.fbt*) file format to be generated by **mb_make_info** and related functions, reading it from a *.mbio_defaults* file in the user's home directory if one exists (otherwise 3, the current *.fbt* format version).

−----------

int **mb_uselockfiles**(
int *verbose*,
bool **uselockfiles*);

The function **mb_uselockfiles** returns true if **MBIO** should create lock files to prevent simultaneous editing of swath data files by multiple programs (e.g. **mbedit**), reading this setting from a *.mbio_defaults* file in the user's home directory if one exists (otherwise true). On Windows, **uselockfiles* is always returned false because lock file creation is not supported there.

−----------

int **mb_fileiobuffer**(
int *verbose*,
int **fileiobuffer*);

The function **mb_fileiobuffer** returns the size (in some implementation-defined unit) of the buffer to be used for low level file input/output by **mb_fileio_open**, reading this setting from a *.mbio_defaults* file in the user's home directory if one exists (otherwise 0, meaning the system default buffering is used).

−----------

int **mb_mbview_defaults**(
int *verbose*,
int **primary_colortable*,
int **primary_colortable_mode*,
int **primary_shade_mode*,
int **slope_colortable*,
int **slope_colortable_mode*,
int **secondary_colortable*,
int **secondary_colortable_mode*,
double **illuminate_magnitude*,
double **illuminate_elevation*,
double **illuminate_azimuth*,
double **slope_magnitude*);

The function **mb_mbview_defaults** returns default color table, shading mode, and illumination parameter values used by the **mbview** 3D visualization widget, reading them from a *.mbio_defaults* file in the user's home

directory if one exists.

−----------

int **mb_env**(
int *verbose*,
char **psdisplay*,
char **imgdisplay*,
char **mbproject*);

The function **mb_env** provides default values of Postscript and image display programs invoked by some **MB-System** programs and macros, and a default value for a working project name that will be used by future applications. The *verbose* value controls the standard error output verbosity of the function. If an .mbio_defaults file exists in the user's home directory, the **psdisplay*, **imgdisplay*, **mbproject* defaults are read from this file. Otherwise, the values are set as:

psdisplay = "xpsview" (IRIX OS)
"pageview" (Solaris OS)
"gv" (other OS)
"ghostview" (other OS)
imgdisplay = "gimp" (Linux OS)
"xv" (other than Linux OS)
mbproject = "none"

−----------

int **mb_format**(
int *verbose*,
int **format*,
int **error*);

Given the format identifier *format*, **mb_format** checks if the format is valid. If the format id corresponds to a value used in previous (<4.00) versions of **MB-System**, then the format value will be aliased to the current corresponding value.

The return values are:

format: **MBIO** format id
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_format_register**(
int *verbose*,
int **format*,
void **mbio_ptr*,
int **error*);

The function **mb_format_register** is called by **mb_read_init** and **mb_write_init** and serves to load format specific parameters and function parameters into the **MBIO** control structure pointed to by **error*. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values.

The input values are:

format*: **MBIO format id

**mbio_ptr*: pointer to data in specified buffer record

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_format_info**(
int *verbose*,
int **format*,
int **system*,
int **beams_bath_max*,
int **beams_amp_max*,
int **pixels_ss_max*,
char **format_name*,
char **system_name*,
char **format_description*,
int **numfile*,
int **filetype*,
bool **variable_beams*,
bool **traveltime*,
bool **beam_flagging*,
int **platform_source*,
int **nav_source*,
int **sensordepth_source*,
int **heading_source*,
int **attitude_source*,
int **svp_source*,
double **beamwidth_xtrack*,
double **beamwidth_ltrack*,
int **error*);

The function **mb_format_info** returns a variety of data format specific parameters. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values.

The input values are:

format*: **MBIO format id

The return values are:

format*: **MBIO format id
system*: **MBIO sonar system id
**beams_bath_max*: maximum number of bathymetry beams
**beams_amp_max*: maximum number of amplitude beams
**pixels_ss_max*: maximum number of sidescan pixels
format_name*: **MBIO format name
system_name*: **MBIO sonar system name
format_description*: **MBIO format description
**numfile*: number of parallel data files used in format
**filetype*: type of data files

**variable_beams*: number of beams can vary [boolean]
**traveltime*: travel time data available [boolean]
**beam_flagging*: beam flagging supported [boolean]
**platform_source*: kind of data records containing sensor platform (mounting/offset) information
**nav_source*: kind of data records containing navigation
**sensordepth_source*: kind of data records containing sensor (transducer) depth
**heading_source*: kind of data records containing heading
**attitude_source*: kind of data records containing attitude (roll, pitch, heave)
**svp_source*: kind of data records containing sound velocity profiles
**beamwidth_xtrack*: typical athwartships beam width [degrees]
**beamwidth_ltrack*: typical alongtrack beam width [degrees]
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_format_system**(
int *verbose*,
int **format*,
int **system*,
int **error*);

The function **mb_format_system** returns the **MBIO** sonar system id. The format id **format* is first checked for validity. In some cases, formerly valid but now oattintbsolete format id values are mapped to current values. The input values are:
format*: **MBIO format id
The return values are:
format*: **MBIO format id
system*: **MBIO sonar system id
error: error value
A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_format_description**(
int *verbose*,
int **format*,
char **description*,
int **error*);

The function **mb_format_description** returns a short description of the format in the string **description*. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values. The input values are:
format*: **MBIO format id

The return values are:

format*: **MBIO format id
format_description*: **MBIO format description
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_format_dimensions**(
int *verbose*,
int **format*,
int **beams_bath_max*,
int **beams_amp_max*,
int **pixels_ss_max*,
int **error*);

The function **mb_format_dimensions** returns the maximum numbers of beams and pixels associated with a particular data format. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values. The input values are:

format*: **MBIO format id

The return values are:

format*: **MBIO format id
**beams_bath_max*: maximum number of bathymetry beams
**beams_amp_max*: maximum number of amplitude beams
**pixels_ss_max*: maximum number of sidescan pixels
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_format_flags**(
int *verbose*,
int **format*,
bool **variable_beams*,
bool **traveltime*,
bool **beam_flagging*,
int **error*);

The function **mb_format_flags** returns flags indicating certain characteristics of the specified data format. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values. The input values are:

format*: **MBIO format id

The return values are:

format*: **MBIO format id
**variable_beams*: number of beams can vary [boolean]
**traveltime*: travel time data available [boolean]
**beam_flagging*: beam flagging supported [boolean]
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_format_source**(

int *verbose*,
int **format*,
int **platform_source*,
int **nav_source*,
int **sensordepth_source*,
int **heading_source*,
int **attitude_source*,
int **svp_source*,
int **error*);

The function **mb_format_source** returns flags indicating what kinds of data records contain platform, navigation, sensor depth, heading, attitude, and sound velocity profile values in the specified data format. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values. The input values are:

format*: **MBIO format id

The return values are:

format*: **MBIO format id
**platform_source*: kind of data records containing sensor platform information
**nav_source*: kind of data records containing navigation
**sensordepth_source*: kind of data records containing sensor (transducer) depth
**heading_source*: kind of data records containing heading
**attitude_source*: kind of data records containing attitude
**svp_source*: kind of data records containing sound velocity profiles
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_format_beamwidth**(
int *verbose*,
int **format*,
double **beamwidth_xtrack*,
double **beamwidth_ltrack*,
int **error*);

The function **mb_format_beamwidth** returns typical, upper bound values for athwartships and alongtrack beam widths. The format id **format* is first checked for validity. In some cases, formerly valid but now obsolete format id values are mapped to current values. The input values are:

format*: **MBIO format id

The return values are:

format*: **MBIO format id
**beamwidth_xtrack*: typical athwartships beam width [degrees]
**beamwidth_ltrack*: typical alongtrack beam width [degrees]
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed

information about failures.

−----------

int **mb_get_format**(
int *verbose*,
char **filename*,
char **fileroot*,
int **format*,
int **error*);

The function **mb_get_format** attempts to determine the **MBIO** format id **format* of *filename* from a recognized filename suffix convention (e.g. *.mbXXX*, *.mb1*, or *.nve*), and if successful returns in **fileroot* the part of *filename* preceding that suffix. If no recognized suffix is found, **format* is returned as 0.

−----------

int **mb_get_relative_path**(
int *verbose*,
char **path*,
char **pwd*,
int **error*);

The function **mb_get_relative_path** rewrites **path* in place, replacing it with the equivalent path relative to the working directory *pwd*, if *path* lies within (or below) *pwd*. This is used, for instance, by **mbdatalist** so that datalist files can reference data files with relative rather than absolute paths.

−----------

int **mb_get_absolute_path**(
int *verbose*,
char **path*,
char **pwd*,
int **error*);

The function **mb_get_absolute_path** rewrites **path* in place, replacing a relative path with the equivalent absolute path obtained by prepending the working directory *pwd*, if *path* is not already absolute.

−----------

int **mb_get_shortest_path**(
int *verbose*,
char **path*,
int **error*);

The function **mb_get_shortest_path** rewrites **path* in place with the shortest equivalent path, removing redundant ./ and ../ path components.

−----------

int **mb_get_basename**(
int *verbose*,
char **path*,
int **error*);

The function **mb_get_basename** rewrites **path* in place, replacing it with just its final path component (the part following the last "/").

−----------

int **mb_cvt_to_nix_path**(
char **path*);

The function **mb_cvt_to_nix_path**, available only when **MB-System** is built for Windows, rewrites *path* in place, converting a Windows-style path (using "\e" separators and a drive letter) into the equivalent Unix-style path (using "/" separators, with any drive letter removed) used internally by **MBIO**.

−----------

int **mb_datalist_open**(
int *verbose*,
void ***datalist_ptr*,
char **path*,
int *look_processed*,
int **error*);

The function **mb_datalist_open** initializes reading from a datalist tree. The string **path* is the path to the top level datalist file to be opened. The value *look_processed* indicates whether the datalist parsing should look for or ignore processed data files (see the **mbprocess** and **mbdatalist** manual pages). The input values are:

path: datalist file to be opened
look_processed: processed file behavior
0 : unset
1 : ignore processed files
2 : return processed files

The return values are:

***datalist_ptr*: pointer to datalist structure
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_datalist_read**(
int *verbose*,
void **datalist_ptr*,
char **path*,
char **dpath*,
int **format*,
double **weight*,
int **error*);

The function **mb_datalist_read** reads from a datalist tree, attempting to return the path to the next valid swath data file, the corresponding data format id, and a gridding weight (see the **mbprocess** and **mbdatalist** manual pages). If a processed version of the data file exists and processed files are to be used, **path* is returned as the path to the processed file. Information about the datalist tree is embedded in a data structure pointed to by **datalist_ptr*. The input values are:

**datalist_ptr*: pointer to datalist structure

The return values are:

**path*: swath data file (or its processed equivalent, if used)
**dpath*: path of the datalist file referencing **path*

format*: **MBIO format id
weight*: **mbgrid gridding weight
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures. This function is implemented as a call to **mb_datalist_read3**.

−----------

int **mb_datalist_readorg**(
int *verbose*,
void **datalist_ptr*,
char **path*,
int **format*,
double **weight*,
int **error*);

The function **mb_datalist_readorg** reads from a datalist tree exactly as **mb_datalist_read** does, except that the original (unprocessed) file path is always returned in **path*, even when a processed version of the file exists.

−----------

int **mb_datalist_read2**(
int *verbose*,
void **datalist_ptr*,
int **pstatus*,
char **path*,
char **ppath*,
char **dpath*,
int **format*,
double **weight*,
int **error*);

The function **mb_datalist_read2** reads from a datalist tree, returning both the original file path **path* and, separately, the path **ppath* of the processed version of that file (if one exists). The value **pstatus* indicates whether a processed file exists (**MB_PROCESSED_EXIST**) and if so whether it should be used (**MB_PROCESSED_USE**) or not (**MB_PROCESSED_NONE**). **dpath* is returned as the path of the datalist file that references **path*. **mb_datalist_read** is implemented as a call to **mb_datalist_read3**, which is in turn implemented as a call to **mb_datalist_read2** with the addition of alternative navigation file handling.

−----------

int **mb_datalist_read3**(
int *verbose*,
void **datalist_ptr*,
int **pstatus*,
char **path*,
char **ppath*,
int **astatus*,
char **apath*,
char **dpath*,
int **format*,
double **weight*,
int **error*);

The function **mb_datalist_read3** reads from a datalist tree exactly as **mb_datalist_read2** does, and in

addition returns the path **apath* to an alternative navigation file associated with the data file, if one is specified in the datalist. The value **astatus* indicates whether an alternative navigation file was found (**MB_ALTNAV_USE**) or not (**MB_ALTNAV_NONE**).

−----------

int **mb_datalist_recursion**(
int *verbose*,
void **datalist_ptr*,
bool *print*,
int **recursion*,
int **error*);

The function **mb_datalist_recursion** returns the current recursion depth of the datalist tree rooted at **datalist_ptr* (datalist files may reference other datalist files, and this value tracks how deeply nested the currently open file is). If *print* is true, a summary of the recursive datalist structure is printed to standard error.

−----------

int **mb_datalist_close**(
int *verbose*,
void ***datalist_ptr*,
int **error*);

The function **mb_datalist_close** closes an open datalist tree, and deallocates the data structure pointed to by **datalist_ptr*. The input values are:

**datalist_ptr*: pointer to datalist structure

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_imagelist_open**(
int *verbose*,
void ***imagelist_ptr*,
char **path*,
int **error*);

The function **mb_imagelist_open** initializes reading from an imagelist tree in the same manner that **mb_datalist_open** does for a datalist tree. An imagelist references still or video camera image files (and, for stereo cameras, pairs of image files) associated with a survey, along with per-image navigation and timing metadata used when merging images with swath data (see the **mbphotomosaic** manual page). The string **path* is the path to the top level imagelist file to be opened. The return values are:

***imagelist_ptr*: pointer to imagelist structure

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_imagelist_read**(
int *verbose*,
void **imagelist_ptr*,

int **imagestatus*,
bool **rectified*,
char **path0*,
char **path1*,
char **dpath*,
double **time_d0*,
double **time_d1*,
double **gain0*,
double **gain1*,
double **exposure0*,
double **exposure1*,
int **error*);

The function **mb_imagelist_read** reads from an imagelist tree, attempting to return the path (or, for a stereo pair, paths) to the next image file along with its timestamp(s), camera gain(s), and exposure time(s). The value **imagestatus* indicates the kind of image record obtained (e.g. single image or stereo pair), and **rectified* indicates whether the image(s) have already been rectified. The return values are:

**path0*:	path of the (first) image file
**path1*:	path of the second image file of a stereo pair, if any
**dpath*:	path of the imagelist file referencing **path0* and **path1*
**time_d0*:	time stamp of first image
**time_d1*:	time stamp of second image, if any
**gain0*:	camera gain for first image
**gain1*:	camera gain for second image, if any
**exposure0*:	exposure time for first image
**exposure1*:	exposure time for second image, if any
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_imagelist_recursion**(
int *verbose*,
void **imagelist_ptr*,
bool *print*,
int **recursion*,
int **error*);

The function **mb_imagelist_recursion** returns the current recursion depth of the imagelist tree rooted at **imagelist_ptr*, in the same manner that **mb_datalist_recursion** does for a datalist tree. If *print* is true, a summary of the recursive imagelist structure is printed to standard error.

−----------

int **mb_imagelist_close**(
int *verbose*,
void ***imagelist_ptr*,
int **error*);

The function **mb_imagelist_close** closes an open imagelist tree, and deallocates the data structure pointed to by **imagelist_ptr*. A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_check_info**(
int *verbose*,
char **file*,
int *lonflip*,
double *bounds[4]*,
bool **file_in_bounds*,
int **error*);

The function **mb_check_info** checks whether the swath data file *file* has any data within the region specified by *lonflip* and *bounds*, without opening or reading the data file itself. This is done by reading the **mbinfo** summary statistics from the associated *.inf* file (see the **mbinfo** and **mbdatalist** manual pages), which lists the geographic bounds of the data. If *file* is "stdin" or no *.inf* file exists, **file_in_bounds* is simply set true. This function is used by **mbdatalist** and other programs to quickly exclude files with no data in a region of interest without opening every file in a large datalist.

−----------

bool **mb_should_make_fbt**(
int *verbose*,
int *format*);

The function **mb_should_make_fbt** returns true if swath data files of the given **MBIO** *format* benefit from having an associated fast bathymetry file (*.fbt* suffix; see **mb_get_fbt** below) generated for them, and false for formats (e.g. navigation-only or ASCII formats) for which a *.fbt* file is not useful.

−----------

bool **mb_should_make_fnv**(
int *verbose*,
int *format*);

The function **mb_should_make_fnv** returns true if swath data files of the given **MBIO** *format* benefit from having an associated fast navigation file (*.fnv* suffix; see **mb_get_fnv** below) generated for them, and false otherwise.

−----------

int **mb_make_info**(
int *verbose*,
bool *force*,
char **file*,
int *format*,
int **error*);

The function **mb_make_info** checks the modification times of the *.inf*, *.fbt*, and *.fnv* ancillary files associated with the swath data file *file* against the modification time of *file* itself, and regenerates any that are missing or out of date by invoking **mbinfo** (for the *.inf* file) and **mbcopy** (for the *.fbt* and *.fnv* files) as subprocesses. If *force* is true, the ancillary files are regenerated unconditionally.

−----------

int **mb_make_info_datalist**(
int *verbose*,
bool *force*,
char **read_file*,
int **format*,

int **error*);

The function **mb_make_info_datalist** calls **mb_make_info** for every swath data file referenced (directly or recursively) by the datalist or single swath file named *read_file*.

−----------

int **mb_get_fbt**(
int *verbose*,
char **file*,
int **format*,
int **error*);

The function **mb_get_fbt** checks whether a fast bathymetry file (*file* with a *.fbt* suffix appended) exists and is present; if so **file* is replaced with the path of the *.fbt* file and **format* is set to the fast bathymetry format id (71). If no *.fbt* file exists, **file* and **format* are left unchanged. This allows an application such as **mbgrid** to transparently read the much smaller and faster *.fbt* file in place of the original data file when one is available.

−----------

int **mb_get_fnv**(
int *verbose*,
char **file*,
int **format*,
int **error*);

The function **mb_get_fnv** behaves exactly as **mb_get_fbt** does, except that it looks for a fast navigation file (a *.fnv* suffix) and, if found, sets **format* to the fast navigation format id (166).

−----------

int **mb_get_ffa**(
int *verbose*,
char **file*,
int **format*,
int **error*);

The function **mb_get_ffa** behaves exactly as **mb_get_fbt** does, except that it looks for a fast amplitude file (a *.ffa* suffix) and, if found, sets **format* to the fast bathymetry/amplitude format id (71).

−----------

int **mb_get_ffs**(
int *verbose*,
char **file*,
int **format*,
int **error*);

The function **mb_get_ffs** behaves exactly as **mb_get_fbt** does, except that it looks for a fast sidescan file (a *.ffs* suffix) and, if found, sets **format* to the fast bathymetry/sidescan format id (71).

−----------

int **mb_swathbounds**(
int *verbose*,
int *checkgood*,
int *nbath*,
int *nss*,

char **beamflag*,
double **bathacrosstrack*,
double **ss*,
double **ssacrosstrack*,
int **ibeamport*,
int **ibeamcntr*,
int **ibeamstbd*,
int **ipixelport*,
int **ipixelcntr*,
int **ipixelstbd*,
int **error*);

The function **mb_swathbounds** examines the bathymetry and sidescan acrosstrack distance arrays of a ping (of *nbath* beams and *nss* pixels) and returns the port-most, center, and starboard-most beam and pixel indices. If *checkgood* is set, beams and pixels flagged bad are excluded from consideration. This is used by plotting and processing programs (e.g. **mbedit** and **mbeditviz**) to quickly determine the acrosstrack extent of a ping's good data.

−----------
int **mb_info_init**(
int *verbose*,
struct mb_info_struct **mb_info*,
int **error*);

The function **mb_info_init** initializes (zeroes) the fields of the *struct mb_info_struct* pointed to by *mb_info*, the data structure used by **mb_get_info** to hold the summary statistics parsed from an *.inf* file.

−----------
int **mb_get_info**(
int *verbose*,
char **file*,
struct mb_info_struct **mb_info*,
int *lonflip*,
int **error*);

The function **mb_get_info** reads the **mbinfo** summary statistics for the swath data file *file* from its associated *.inf* file (generating that file first with **mb_make_info** if necessary) and returns them in the *struct mb_info_struct* pointed to by *mb_info*. The *lonflip* value controls how longitude values are wrapped when read from the *.inf* file.

−----------
int **mb_get_info_datalist**(
int *verbose*,
char **read_file*,
int **format*,
struct mb_info_struct **mb_info*,
int *lonflip*,
int **error*);

The function **mb_get_info_datalist** behaves as **mb_get_info** does, but accepts a datalist as well as a single swath file for *read_file*; when given a datalist, the summary statistics returned in *mb_info* are accumulated over every swath file referenced by the datalist.

−----------

int **mb_alloc**(
int *verbose*,
void **mbio_ptr*,
void ***store_ptr*,
int **error*);

The function **mb_alloc** allocates a data structure for internal storage of swath sonar data and returns a pointer to this structure in **store_ptr*. The data structure is specific to the data format identified in the **MBIO** data structure pointed to by **mbio_ptr*. The input values are:

mbio_ptr*: pointer to **MBIO structure

The return values are:

***store_ptr*: pointer to storage data structure

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_deall**(
int *verbose*,
void **mbio_ptr*,
void ***store_ptr*,
int **error*);

The function **mb_deall** deallocates a format specific swath sonar data structure pointed to by **store_ptr*. The input values are:

mbio_ptr*: pointer to **MBIO structure

**store_ptr*: pointer to storage data structure

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_malloc**(
int *verbose*,
size_t *size*,
void ***ptr*,
int **error*);

The function **mb_malloc** allocates *size* bytes of memory, returning the new pointer in **ptr*, in the same manner as the standard C *malloc*() function, but also optionally tracking the allocation (see **mb_mem_list_enable**) and printing debug messages when *verbose* is high enough or debugging has been turned on with **mb_mem_debug_on**.

−----------

int **mb_realloc**(
int *verbose*,
size_t *size*,
void ***ptr*,
int **error*);

The function **mb_realloc** resizes the memory block pointed to by **ptr* (allocated by **mb_malloc** or **mb_realloc**) to *size* bytes, in the same manner as the standard C *realloc*() function, updating **ptr* and any memory tracking as **mb_malloc** does.

−----------

int **mb_free**(
int *verbose*,
void ***ptr*,
int **error*);

The function **mb_free** frees the memory pointed to by **ptr* (allocated by **mb_malloc** or **mb_realloc**), sets **ptr* to NULL, and updates any memory tracking as **mb_malloc** does.

−----------

int **mb_mallocd**(
int *verbose*,
const char **sourcefile*,
int *sourceline*,
size_t *size*,
void ***ptr*,
int **error*);

The function **mb_mallocd** behaves exactly as **mb_malloc** does, but also records the *sourcefile* name and *sourceline* number of the call site in the memory tracking list (when enabled), to aid in locating memory leaks. **MB-System** source code normally invokes this indirectly via the **mb_mallocd** macro, which supplies **__FILE__** and **__LINE__** automatically.

−----------

int **mb_reallocd**(
int *verbose*,
const char **sourcefile*,
int *sourceline*,
size_t *size*,
void ***ptr*,
int **error*);

The function **mb_reallocd** behaves exactly as **mb_realloc** does, but also records the *sourcefile* name and *sourceline* number of the call site, in the same manner as **mb_mallocd**.

−----------

int **mb_freed**(
int *verbose*,
const char **sourcefile*,
int *sourceline*,
void ***ptr*,
int **error*);

The function **mb_freed** behaves exactly as **mb_free** does, but also records the *sourcefile* name and *sourceline* number of the call site, in the same manner as **mb_mallocd**.

−----------

int **mb_mem_list_enable**(
int *verbose*,

int **error*);

The function **mb_mem_list_enable** turns on internal tracking, by **mb_malloc**/**mb_realloc**/**mb_free** and related functions, of a list of all currently allocated memory blocks, enabling the use of **mb_memory_status** and **mb_memory_list**.

−----------

int **mb_mem_list_disable**(
int *verbose*,
int **error*);

The function **mb_mem_list_disable** turns off the memory allocation tracking enabled by **mb_mem_list_enable**.

−----------

int **mb_mem_debug_on**(
int *verbose*,
int **error*);

The function **mb_mem_debug_on** turns on printing of debug messages by the memory allocation functions above regardless of the *verbose* level passed to them.

−----------

int **mb_mem_debug_off**(
int *verbose*,
int **error*);

The function **mb_mem_debug_off** turns off the unconditional debug message printing enabled by **mb_mem_debug_on**.

−----------

int **mb_memory_clear**(
int *verbose*,
int **error*);

The function **mb_memory_clear** frees every memory block currently in the allocation list maintained when memory tracking is enabled (see **mb_mem_list_enable**), and empties the list.

−----------

int **mb_memory_status**(
int *verbose*,
int **nalloc*,
int **nallocmax*,
int **overflow*,
size_t **allocsize*,
int **error*);

The function **mb_memory_status** returns, when memory tracking is enabled (see **mb_mem_list_enable**), the number of memory blocks currently allocated (**nalloc*), the maximum number of blocks the tracking list can hold (**nallocmax*), a flag (**overflow*) indicating whether that maximum has been exceeded (in which case tracking becomes incomplete), and the total number of bytes currently allocated (**allocsize*).

−----------

int **mb_memory_list**(
int *verbose*,
int **error*);

The function **mb_memory_list** prints to standard error a listing of every memory block currently in the allocation tracking list (see **mb_mem_list_enable**), including the source file and line number recorded by **mb_mallocd**.

−----------
int **mb_update_arrays**(
int *verbose*,
void **mbio_ptr*,
int *nbath*,
int *namp*,
int *nss*,
int **error*);

The function **mb_update_arrays** resizes every array registered with **mb_register_array** for the **MBIO** descriptor pointed to by *mbio_ptr* to match new maximum numbers of bathymetry beams *nbath*, amplitude beams *namp*, and sidescan pixels *nss*. It is called internally as necessary while reading data whose numbers of beams or pixels can vary from ping to ping.

−----------
int **mb_update_arrayptr**(
int *verbose*,
void **mbio_ptr*,
void ***handle*,
int **error*);

The function **mb_update_arrayptr** updates the stored copy of one registered array pointer **handle* for the **MBIO** descriptor pointed to by *mbio_ptr*, for use after the calling program has reallocated that array itself.

−----------
int **mb_list_arrays**(
int *verbose*,
void **mbio_ptr*,
int **error*);

The function **mb_list_arrays** prints to standard error a listing of every array registered with **mb_register_array** for the **MBIO** descriptor pointed to by *mbio_ptr*.

−----------
int **mb_deall_ioarrays**(
int *verbose*,
void **mbio_ptr*,
int **error*);

The function **mb_deall_ioarrays** frees every array registered with **mb_register_array** for the **MBIO** descriptor pointed to by *mbio_ptr*. It is called internally by **mb_close**.

−----------
int **mb_get_time**(
int *verbose*,

int *time_i[7]*,
double **time_d*);

The function **mb_get_time** converts the seven-element time array *time_i* (year, month, day, hour, minute, second, microsecond) into **time_d*, the number of seconds since January 1, 1970 (with no time zone correction applied - **MB-System** always works in whatever time standard was used when the data were logged). Leap days are accounted for; leap seconds are not.

−----------

int **mb_get_date**(
int *verbose*,
double *time_d*,
int *time_i[7]*);

The function **mb_get_date** is the inverse of **mb_get_time**, converting *time_d* seconds since January 1, 1970 into the seven-element time array *time_i*.

−----------

int **mb_get_date_string**(
int *verbose*,
double *time_d*,
char **string*);

The function **mb_get_date_string** converts *time_d* seconds since January 1, 1970 into a human-readable date and time *string*.

−----------

int **mb_get_jtime**(
int *verbose*,
int *time_i[7]*,
int *time_j[5]*);

The function **mb_get_jtime** converts the seven-element time array *time_i* into the five-element Julian day time array *time_j* (year, Julian day of year, hour, minute, second - with *time_j*[4] tracking the residual microseconds), the alternate time representation used internally by some sonar systems and data formats.

−----------

int **mb_get_itime**(
int *verbose*,
int *time_j[5]*,
int *time_i[7]*);

The function **mb_get_itime** is the inverse of **mb_get_jtime**, converting the five-element Julian day time array *time_j* into the seven-element time array *time_i*.

−----------

char ***mb_day_name**(
int *verbose*,
int *day*);

The function **mb_day_name** returns a pointer to a static string naming the day of the week numbered 1 (Sunday) through 7 (Saturday) by *day*; any other value returns "Unknown".

−----------

char ***mb_month_name**(
int *verbose*,
int *month*);

The function **mb_month_name** returns a pointer to a static string naming the month numbered 1 (January) through 12 (December) by *month*; any other value returns "Unknown".

−----------

int **mb_fix_y2k**(
int *verbose*,
int *year_short*,
int **year_long*);

The function **mb_fix_y2k** converts a two digit year value *year_short* into a four digit year **year_long*, adding 1900 if *year_short* is 62 or greater and 2000 otherwise (no digital swath sonar data predates 1962, when multibeam sonars were first patented and built).

−----------

int **mb_unfix_y2k**(
int *verbose*,
int *year_long*,
int **year_short*);

The function **mb_unfix_y2k** is the inverse of **mb_fix_y2k**, converting a four digit year *year_long* into a two digit year **year_short*.

−----------

int **mb_error**(
int *verbose*,
int *error*,
char ***message*);

Given the error value *error*, **mb_error** returns a short error message in the string ***message*. The *verbose* value controls the standard error output verbosity of the function. The return status value signals success if *error* is a recognized **MBIO** error value and failure otherwise.

−----------

int **mb_notice_log_datatype**(
int *verbose*,
void **mbio_ptr*,
int *data_id*);

The function **mb_notice_log_datatype** increments the count, in the notice list maintained in the **MBIO** descriptor pointed to by *mbio_ptr*, of data records of kind *data_id* that have been read or written. This supports the end-of-run notice summary printed by many **MB-System** programs.

−----------

int **mb_notice_log_error**(
int *verbose*,
void **mbio_ptr*,
int *error_id*);

The function **mb_notice_log_error** behaves as **mb_notice_log_datatype** does, but increments the count of occurrences of the (nonfatal) error condition *error_id*.

−----------

int **mb_notice_log_problem**(
int *verbose*,
void **mbio_ptr*,
int *problem_id*);

The function **mb_notice_log_problem** behaves as **mb_notice_log_datatype** does, but increments the count of occurrences of the data problem condition *problem_id* (e.g. a recognized but questionable value encountered while reading).

−----------

int **mb_notice_get_list**(
int *verbose*,
void **mbio_ptr*,
int **notice_list*);

The function **mb_notice_get_list** copies the notice list maintained in the **MBIO** descriptor pointed to by *mbio_ptr* (as tallied by **mb_notice_log_datatype**, **mb_notice_log_error**, and **mb_notice_log_problem**) into the array *notice_list*, which must be allocated by the calling program to hold **MB_NOTICE_MAX** values.

−----------

int **mb_notice_message**(
int *verbose*,
int *notice*,
char ***message*);

The function **mb_notice_message** returns, in the string ***message*, a short description of the notice list entry *notice* (one of the data record, error, or problem identifiers logged by the **mb_notice_log_*** functions above).

−----------

int **mb_navint_add**(
int *verbose*,
void **mbio_ptr*,
double *time_d*,
double *lon_easting*,
double *lat_northing*,
int **error*);

The function **mb_navint_add** adds a navigation fix to a circular buffer of navigation values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate navigation for data formats where the navigation is asynchronous (where navigation and survey pings come in different data records). The input values are:

**mbio_ptr*:	pointer to **MBIO** structure
time_d:	time of navigation fix in seconds since 1/1/70 00:00:00
lon_easting:	longitude (degrees), or projected easting if the **MBIO** structure has been set to use a projected coordinate system
lat_northing:	latitude (degrees), or projected

northing if the **MBIO** structure
has been set to use a projected
coordinate system

The return values are:

error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_navint_interp**(
int *verbose*,
void **mbio_ptr*,
double *time_d*,
double *heading*,
double *rawspeed*,
double **lon*,
double **lat*,
double **speed*,
int **error*);

The function **mb_navint_interp** interpolates navigation to the time *time_d* using a circular buffer of navigation values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate navigation for data formats where the navigation is asynchronous (where navigation and survey pings come in different data records). The input values are:

mbio_ptr: pointer to **MBIO** structure
time_d: time of current ping in seconds
since 1/1/70 00:00:00
heading: heading in degrees
rawspeed: speed in km/hr
(zero if not known)

The return values are:

**lon*: longitude (degrees)
**lat*: latitude (degrees)
**speed*: speed made good in km/hr
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_navint_prjinterp**(
int *verbose*,
void **mbio_ptr*,
double *time_d*,
double *heading*,
double *rawspeed*,
double **easting*,
double **northing*,
double **speed*,
int **error*);

The function **mb_navint_prjinterp** behaves exactly as **mb_navint_interp** does, except that it interpolates and returns projected easting and northing values (**easting*, **northing*) rather than longitude and latitude, for use when the **MBIO** structure has been set to work in a projected coordinate system.

−----------

int **mb_attint_add**(
int *verbose*,
void **mbio_ptr*,
double *time_d*,
double *heave*,
double *roll*,
double *pitch*,
int **error*);

The function **mb_attint_add** adds an attitude (heave, roll, pitch) data point to a circular buffer of attitude values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate attitude for data formats where the attitude is asynchronous (where attitude and survey pings come in different data records). The input values are:

**mbio_ptr*:	pointer to **MBIO** structure
time_d:	time of attitude in seconds since 1/1/70 00:00:00
heave:	heave (meters, up +)
roll:	roll (degrees, starboard up +)
pitch:	pitch (degrees, forward up +)

The return values are:

error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_attint_nadd**(
int *verbose*,
void **mbio_ptr*,
int *nsamples*,
double **time_d*,
double **heave*,
double **roll*,
double **pitch*,
int **error*);

The function **mb_attint_nadd** adds *nsamples* attitude (heave, roll, pitch) data points at once to the circular buffer described under **mb_attint_add** above, which is more efficient than calling **mb_attint_add** repeatedly when a block of attitude samples is available at once (e.g. when merging externally logged attitude data).

−----------

int **mb_attint_interp**(
int *verbose*,
void **mbio_ptr*,
double *time_d*,
double **heave*,
double **roll*,
double **pitch*,
int **error*);

The function **mb_attint_interp** interpolates attitude (heave, roll, pitch) data to the time *time_d* using a circular buffer of attitude values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate attitude for data formats where the attitude is asynchronous (where attitude and survey

pings come in different data records). The input values are:

**mbio_ptr*:	pointer to **MBIO** structure
time_d:	time of current ping in seconds since 1/1/70 00:00:00

The return values are:

**heave*:	heave (meters, up +)
**roll*:	roll (degrees, starboard up +)
**pitch*:	pitch (degrees, forward up +)
error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_depint_add**(
int *verbose*,
void **mbio_ptr*,
double *time_d*,
double *sensordepth*,
int **error*);

The function **mb_depint_add** adds a sensor (transducer) depth value to a circular buffer of sensor depth values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**, in the same manner that **mb_hedint_add** does for heading.

−----------

int **mb_depint_interp**(
int *verbose*,
void **mbio_ptr*,
double *time_d*,
double **sensordepth*,
int **error*);

The function **mb_depint_interp** interpolates sensor depth to the time *time_d* using the circular buffer maintained by **mb_depint_add**, in the same manner that **mb_hedint_interp** does for heading.

−----------

int **mb_altint_add**(
int *verbose*,
void **mbio_ptr*,
double *time_d*,
double *altitude*,
int **error*);

The function **mb_altint_add** adds an altitude value to a circular buffer of altitude values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**, in the same manner that **mb_hedint_add** does for heading.

−----------

int **mb_altint_interp**(
int *verbose*,
void **mbio_ptr*,
double *time_d*,
double **altitude*,
int **error*);

The function **mb_altint_interp** interpolates altitude to the time *time_d* using the circular buffer maintained by **mb_altint_add**, in the same manner that **mb_hedint_interp** does for heading.

−----------

int **mb_hedint_add**(
int *verbose*,
void **mbio_ptr*,
double *time_d*,
double *heading*,
int **error*);

The function **mb_hedint_add** adds a heading point to a circular buffer of heading values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate heading for data formats where the heading is asynchronous (where heading and survey pings come in different data records). The input values are:

**mbio_ptr*:	pointer to **MBIO** structure
time_d:	time of heading value in seconds since 1/1/70 00:00:00
heading:	heading (degrees)

The return values are:

error:	error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_hedint_nadd**(
int *verbose*,
void **mbio_ptr*,
int *nsamples*,
double **time_d*,
double **heading*,
int **error*);

The function **mb_hedint_nadd** adds *nsamples* heading values at once to the circular buffer described under **mb_hedint_add** above, which is more efficient than calling **mb_hedint_add** repeatedly when a block of heading samples is available at once.

−----------

int **mb_hedint_interp**(
int *verbose*,
void **mbio_ptr*,
double *time_d*,
double **heading*,
int **error*);

The function **mb_hedint_interp** interpolates heading to the time *time_d* using a circular buffer of heading values maintained in the **MBIO** data structure pointed to by ***mbio_ptr**. This buffer is used to interpolate heading for data formats where the heading is asynchronous (where heading and survey pings come in different data records). The input values are:

**mbio_ptr*:	pointer to **MBIO** structure
time_d:	time of current ping in seconds since 1/1/70 00:00:00

The return values are:

**heading*: heading in degrees
error: error value

A status value indicating success or failure is returned; the error value argument *error* passes more detailed information about failures.

−----------

int **mb_loadnavdata**(
int *verbose*,
char ***merge_nav_file*,
int *merge_nav_format*,
int *merge_nav_lonflip*,
int **merge_nav_num*,
int **merge_nav_alloc*,
double ***merge_nav_time_d*,
double ***merge_nav_lon*,
double ***merge_nav_lat*,
double ***merge_nav_speed*,
int **error*);

The function **mb_loadnavdata** reads an entire external navigation file *merge_nav_file* (of **MBIO** format *merge_nav_format*, applying *merge_nav_lonflip*) into time, longitude, latitude, and speed arrays that are allocated (or reallocated, tracked by **merge_nav_alloc*) and returned as **merge_nav_time_d*, **merge_nav_lon*, **merge_nav_lat*, and **merge_nav_speed*, with **merge_nav_num* set to the number of values read. This is used by programs such as **mbprocess** to merge externally logged navigation into swath data using **mb_linear_interp** or **mb_linear_interp_longitude** and **mb_linear_interp_latitude**.

−----------

int **mb_loadsensordepthdata**(
int *verbose*,
char ***merge_sensordepth_file*,
int *merge_sensordepth_format*,
int **merge_sensordepth_num*,
int **merge_sensordepth_alloc*,
double ***merge_sensordepth_time_d*,
double ***merge_sensordepth_sensordepth*,
int **error*);

The function **mb_loadsensordepthdata** behaves as **mb_loadnavdata** does, but reads an external sensor depth time series into time and sensor depth arrays.

−----------

int **mb_loadaltitudedata**(
int *verbose*,
char ***merge_altitude_file*,
int *merge_altitude_format*,
int **merge_altitude_num*,
int **merge_altitude_alloc*,
double ***merge_altitude_time_d*,
double ***merge_altitude_altitude*,
int **error*);

The function **mb_loadaltitudedata** behaves as **mb_loadnavdata** does, but reads an external altitude time series into time and altitude arrays.

−----------

int **mb_loadheadingdata**(
int *verbose*,
char **merge_heading_file*,
int *merge_heading_format*,
int **merge_heading_num*,
int **merge_heading_alloc*,
double ***merge_heading_time_d*,
double ***merge_heading_heading*,
int **error*);

The function **mb_loadheadingdata** behaves as **mb_loadnavdata** does, but reads an external heading time series into time and heading arrays.

−----------

int **mb_loadattitudedata**(
int *verbose*,
char **merge_attitude_file*,
int *merge_attitude_format*,
int **merge_attitude_num*,
int **merge_attitude_alloc*,
double ***merge_attitude_time_d*,
double ***merge_attitude_roll*,
double ***merge_attitude_pitch*,
double ***merge_attitude_heave*,
int **error*);

The function **mb_loadattitudedata** behaves as **mb_loadnavdata** does, but reads an external attitude time series into time, roll, pitch, and heave arrays.

−----------

int **mb_loadsoundspeeddata**(
int *verbose*,
char **merge_soundspeed_file*,
int *merge_soundspeed_format*,
int **merge_soundspeed_num*,
int **merge_soundspeed_alloc*,
double ***merge_soundspeed_time_d*,
double ***merge_soundspeed_soundspeed*,
int **error*);

The function **mb_loadsoundspeeddata** behaves as **mb_loadnavdata** does, but reads an external near-surface sound speed time series into time and sound speed arrays.

−----------

int **mb_loadtimeshiftdata**(
int *verbose*,
char **merge_timeshift_file*,
int *merge_timeshift_format*,
int **merge_timeshift_num*,
int **merge_timeshift_alloc*,
double ***merge_timeshift_time_d*,
double ***merge_timeshift_timeshift*,

int *error);

The function **mb_loadtimeshiftdata** behaves as **mb_loadnavdata** does, but reads an external clock time-shift correction time series into time and timeshift arrays.

−----------

int **mb_apply_time_latency**(
int *verbose*,
int *data_num*,
double **data_time_d*,
int *time_latency_mode*,
double *time_latency_static*,
int *time_latency_num*,
double **time_latency_time_d*,
double **time_latency_value*,
int **error*);

The function **mb_apply_time_latency** corrects, in place, the *data_num* timestamps in *data_time_d* for sensor time latency (clock lag). If *time_latency_mode* is **MB_SENSOR_TIME_LATENCY_STATIC**, a constant *time_latency_static* offset (seconds) is subtracted from every timestamp. If *time_latency_mode* is **MB_SENSOR_TIME_LATENCY_MODEL**, a time-varying latency is instead interpolated from the *time_latency_num*-point model given by *time_latency_time_d* and *time_latency_value* and subtracted from each timestamp.

−----------

int **mb_apply_time_filter**(
int *verbose*,
int *data_num*,
double **data_time_d*,
double **data_value*,
double *filter_length*,
int **error*);

The function **mb_apply_time_filter** replaces, in place, the *data_num* values in *data_value* (timestamped by *data_time_d*) with a running-mean smoothed version computed over a time window of length *filter_length* seconds. This is used, for example, to smooth noisy externally logged sensor time series before merging them with swath data.

−----------

int **mb_get_double**(
double **value*,
char **str*,
int *nchar*);

The function **mb_get_double** parses the first *nchar* characters of the string **str* for a floating point value, storing this value as a double in **value*.

−----------

int **mb_get_int**(
int **value*,
char **str*,
int *nchar*);

The function **mb_get_int** parses the first *nchar* characters of the string **str* for an integer value, storing this value as a int in **value*.

−----------
int **mb_get_binary_short**(
bool *swapped*,
void **buffer*,
const void **ptr*);

The function **mb_get_binary_short** extracts a short int value from the first two bytes pointed to by **buffer*, copying the (possibly byte-swapped) result into the location pointed to by **ptr* (cast internally to *short **). If *swapped* is true, the byte order of the extracted value is swapped.

−----------
int **mb_get_binary_int**(
bool *swapped*,
void **buffer*,
const void **ptr*);

The function **mb_get_binary_int** extracts an int value from the first four bytes pointed to by **buffer*, copying the (possibly byte-swapped) result into the location pointed to by **ptr* (cast internally to *int **). If *swapped* is true, the byte order of the extracted value is swapped.

−----------
int **mb_get_binary_float**(
bool *swapped*,
void **buffer*,
const void **ptr*);

The function **mb_get_binary_float** extracts a float value from the first four bytes pointed to by **buffer*, copying the (possibly byte-swapped) result into the location pointed to by **ptr* (cast internally to *float **). If *swapped* is true, the byte order of the extracted value is swapped.

−----------
int **mb_get_binary_double**(
bool *swapped*,
void **buffer*,
const void **ptr*);

The function **mb_get_binary_double** extracts a double value from the first eight bytes pointed to by **buffer*, copying the (possibly byte-swapped) result into the location pointed to by **ptr* (cast internally to *double **). If *swapped* is true, the byte order of the extracted value is swapped.

−----------
int **mb_get_binary_long**(
bool *swapped*,
void **buffer*,
const void **ptr*);

The function **mb_get_binary_long** extracts a 64 bit long integer value from the first eight bytes pointed to by **buffer*, copying the (possibly byte-swapped) result into the location pointed to by **ptr* (cast internally to *mb_s_long **). If *swapped* is true, the byte order of the extracted value is swapped.

−----------

int **mb_put_binary_short**(
bool *swapped*,
short *value*,
void **buffer*);

The function **mb_put_binary_short** inserts a short int value into the first two bytes pointed to by **buffer*. If *swapped* is true, the byte order of *value* is swapped.

−----------

int **mb_put_binary_int**(
bool *swapped*,
int *value*,
void **buffer*);

The function **mb_put_binary_int** inserts an int value into the first four bytes pointed to by **buffer*. If *swapped* is true, the byte order of *value* is swapped.

−----------

int **mb_put_binary_float**(
bool *swapped*,
float *value*,
void **buffer*);

The function **mb_put_binary_float** inserts a float value into the first four bytes pointed to by **buffer*. If *swapped* is true, the byte order of *value* is swapped.

−----------

int **mb_put_binary_double**(
bool *swapped*,
double *value*,
void **buffer*);

The function **mb_put_binary_double** inserts a double value into the first eight bytes pointed to by **buffer*. If *swapped* is true, the byte order of *value* is swapped.

−----------

int **mb_put_binary_long**(
bool *swapped*,
mb_s_long *value*,
void **buffer*);

The function **mb_put_binary_long** inserts a 64 bit long integer value into the first eight bytes pointed to by **buffer*. If *swapped* is true, the byte order of *value* is swapped.

−----------

int **mb_swap_check**(void);

The function **mb_swap_check** returns true if the current machine is little-endian (byte-swapped relative to the big-endian byte order used to store most **MBIO** binary data formats) and false if it is big-endian.

−----------

int **mb_swap_float**(

float **a*);

The function **mb_swap_float** reverses the byte order of the float pointed to by *a*, in place.

−----------

int **mb_swap_double**(
double **a*);

The function **mb_swap_double** reverses the byte order of the double pointed to by *a*, in place.

−----------

int **mb_swap_long**(
mb_s_long **a*);

The function **mb_swap_long** reverses the byte order of the 64 bit long integer pointed to by *a*, in place.

−----------

int **mb_get_bounds**(
char **text*,
double **bounds*);

The function **mb_get_bounds** parses the string **text* and extracts geographic bounds of a rectangular region in the form:
bounds[0]: minimum longitude
bounds[1]: maximum longitude
bounds[2]: minimum latitude
bounds[3]: maximum latitude
where **text* is in the standard **GMT** bounds form. The longitude and latitude values in **text* should separated by a '/' character, and individual values may be represented in decimal degrees or in "dd:mm:ss" form (dd=degrees, mm=minutes, ss=seconds).

double **mb_ddmmss_to_degree**(
char **text*);

The function **mb_ddmmss_to_degree** parses the string **text* and extracts a decimal longitude or latitude value from a "dd:mm:ss" (dd=degrees, mm=minutes, ss=seconds) value.

−----------

int **mb_apply_lonflip**(
int *verbose*,
int *lonflip*,
double **longitude*);

The function **mb_apply_lonflip** rewrites **longitude* in place so that it falls in the range required by *lonflip*: if *lonflip* is negative, **longitude* is wrapped into [−360,0]; if zero, into [−180,180]; if positive, into [0,360]. See **mb_read_init** for the general meaning of *lonflip*.

−----------

int **mb_coor_scale**(
int *verbose*,
double *latitude*,
double **mtodeglon*,
double **mtodeglat*);

The function **mb_coor_scale** returns the scaling factors **mtodeglon* and **mtodeglat* that convert distances in meters to longitude and latitude differences in degrees at the given *latitude*, using a standard ellipsoidal earth model. These scale factors are used throughout **MB-System** to convert between geographic coordinates and local distances (for example, in computing sensor lever arm offsets).

−----------

int **mb_alvinxy_scale**(
int *verbose*,
double *latitude*,
double **mtodeglon*,
double **mtodeglat*);

The function **mb_alvinxy_scale** returns scaling factors **mtodeglon* and **mtodeglat* in the same sense as **mb_coor_scale**, but computed using the Clark 1866 spheroid coefficients used by the WHOI Alvin group's "AlvinXY" local rectilinear navigation coordinate frame convention (Murphy and Singh, 2010).

−----------

int **mb_proj_init**(
int *verbose*,
char **projection*,
void ***pjptr*,
int **error*);

The function **mb_proj_init** initializes, using the **libproj** cartographic projections library, a map projection described by *projection* (a **PROJ**/**EPSG** projection specification string, as also accepted by the **−J** options of many **MB-System** and **GMT** programs) and returns a pointer to the initialized projection in **pjptr* for use by **mb_proj_forward** and **mb_proj_inverse**.

−----------

int **mb_proj_free**(
int *verbose*,
void ***pjptr*,
int **error*);

The function **mb_proj_free** deallocates a projection previously initialized by **mb_proj_init** and pointed to by **pjptr*.

−----------

int **mb_proj_forward**(
int *verbose*,
void **pjptr*,
double *lon*,
double *lat*,
double **easting*,
double **northing*,
int **error*);

The function **mb_proj_forward** applies the forward map projection *pjptr* (initialized by **mb_proj_init**) to convert geographic longitude *lon* and latitude *lat* (degrees) into projected **easting* and **northing* (meters).

−----------

int **mb_proj_inverse**(
int *verbose*,

void **pjptr*,
double *easting*,
double *northing*,
double **lon*,
double **lat*,
int **error*);

The function **mb_proj_inverse** applies the inverse of the map projection *pjptr* (initialized by **mb_proj_init**) to convert projected *easting* and *northing* (meters) back into geographic **lon* and **lat* (degrees).

−----------

int **mb_spline_init**(
int *verbose*,
const double **x*,
const double **y*,
int *n*,
double *yp1*,
double *ypn*,
double **y2*,
int **error*);

The function **mb_spline_init** computes the second-derivative array **y2* of a natural cubic spline through the *n* data points (*x*[i], *y*[i]), given the first-derivative boundary conditions *yp1* and *ypn* at the two endpoints (following Press et al., *Numerical Recipes in C*). The array **y2* is then passed to **mb_spline_interp** to evaluate the spline at arbitrary points.

−----------

int **mb_spline_interp**(
int *verbose*,
const double **xa*,
const double **ya*,
double **y2a*,
int *n*,
double *x*,
double **y*,
int **i*,
int **error*);

The function **mb_spline_interp** evaluates, at the point *x*, the cubic spline defined by the *n* data points (*xa*[i], *ya*[i]) and the second-derivative array *y2a* computed by **mb_spline_init**, returning the interpolated value in **y*. The index **i* should be initialized to zero before the first call and is thereafter maintained across successive calls to speed up the table lookup when *x* values are supplied in increasing order.

−----------

int **mb_linear_interp**(
int *verbose*,
const double **xa*,
const double **ya*,
int *n*,
double *x*,
double **y*,
int **i*,
int **error*);

The function **mb_linear_interp** evaluates, at the point *x*, simple linear interpolation (or, outside the data range, extrapolation using the nearest endpoint) through the *n* data points (*xa*[i], *ya*[i]), returning the interpolated value in **y*. The index **i* is used in the same way as in **mb_spline_interp**.

−----------
int **mb_linear_interp_longitude**(
int *verbose*,
const double ***xa*,
const double ***ya*,
int *n*,
double *x*,
double ***y*,
int ***i*,
int ***error*);

The function **mb_linear_interp_longitude** behaves as **mb_linear_interp** does, but treats the *ya* values as longitudes, so that interpolation is done correctly across the +/−180 degree dateline discontinuity.

−----------
int **mb_linear_interp_latitude**(
int *verbose*,
const double ***xa*,
const double ***ya*,
int *n*,
double *x*,
double ***y*,
int ***i*,
int ***error*);

The function **mb_linear_interp_latitude** behaves as **mb_linear_interp** does, but treats the *ya* values as latitudes, without extrapolating beyond +/−90 degrees.

−----------
int **mb_linear_interp_heading**(
int *verbose*,
const double ***xa*,
const double ***ya*,
int *n*,
double *x*,
double ***y*,
int ***i*,
int ***error*);

The function **mb_linear_interp_heading** behaves as **mb_linear_interp** does, but treats the *ya* values as headings, so that interpolation is done correctly across the 0/360 degree discontinuity.

−----------
int **mb_takeoff_to_rollpitch**(
int *verbose*,
double *theta*,
double *phi*,
double ***alpha*,
double ***beta*,

int **error*);

The function **mb_takeoff_to_rollpitch** translates angles from the "takeoff" coordinate reference frame to the "rollpitch" coordinate system. See the discussion of coordinate systems below.

−----------

int **mb_rollpitch_to_takeoff**(
int *verbose*,
double *alpha*,
double *beta*,
double **theta*,
double **phi*,
int **error*);

The function **mb_rollpitch_to_takeoff** translates angles from the "rollpitch" coordinate reference frame to the "takeoff" coordinate system. See the discussion of coordinate systems below.

−----------

int **mb_xyz_to_takeoff**(
int *verbose*,
double *x*,
double *y*,
double *z*,
double **theta*,
double **phi*,
int **error*);

The function **mb_xyz_to_takeoff** converts a Cartesian beam direction vector (*x*, *y*, *z*) into the "takeoff" coordinate system angles **theta* (from vertical) and **phi* (from the alongtrack direction). See the discussion of coordinate systems below.

−----------

int **mb_lever**(
int *verbose*,
double *sonar_offset_x*,
double *sonar_offset_y*,
double *sonar_offset_z*,
double *nav_offset_x*,
double *nav_offset_y*,
double *nav_offset_z*,
double *vru_offset_x*,
double *vru_offset_y*,
double *vru_offset_z*,
double *vru_pitch*,
double *vru_roll*,
double **lever_x*,
double **lever_y*,
double **lever_z*,
int **error*);

The function **mb_lever** computes the effective lever arm correction (**lever_x*, **lever_y*, **lever_z*) that must be applied to sonar position because of the relative offsets between the sonar, the navigation antenna, and the attitude (VRU) sensor, given the current *vru_pitch* and *vru_roll*. This older, simpler lever arm calculation has

largely been superseded by the fuller sensor platform model implemented by **mb_platform_lever** below, but remains available for formats and programs that use it directly.

−----------

int **mb_beaudoin**(
int *verbose*,
mb_3D_orientation *tx_align*,
mb_3D_orientation *tx_orientation*,
double *tx_steer*,
mb_3D_orientation *rx_align*,
mb_3D_orientation *rx_orientation*,
double *rx_steer*,
double *reference_heading*,
double **beamAzimuth*,
double **beamDepression*,
int **error*);

The function **mb_beaudoin** implements the algorithm of Beaudoin et al. for computing the true beam azimuth **beamAzimuth* and depression angle **beamDepression* of a multibeam sonar beam given the transmit and receive array mounting alignments (*tx_align*, *rx_align*), the vessel orientations at ping and receive time (*tx_orientation*, *rx_orientation*), the transmit and receive beam steering angles (*tx_steer*, *rx_steer*), and a *reference_heading*. This properly accounts for the different vessel attitudes at transmit and receive time on a moving platform.

−----------

int **mb_beaudoin_unrotate**(
int *verbose*,
mb_3D_vector *orig*,
mb_3D_orientation *rotate*,
mb_3D_vector **final*,
int **error*);

The function **mb_beaudoin_unrotate** rotates the vector *orig* by the inverse of the roll, pitch, and heading orientation *rotate*, returning the result in **final*. This is a supporting calculation used by **mb_beaudoin**.

−----------

int **mb_platform_init**(
int *verbose*,
void ***platform_ptr*,
int **error*);

The function **mb_platform_init** allocates and initializes an empty sensor platform model, returning a pointer to it in **platform_ptr*. A platform model records the survey platform (ship, ROV, or AUV) identity together with a list of sensors, each with its position and attitude offsets relative to the platform's reference point, and is used throughout **MBIO** (see **mb_set_platform**, **mb_extract_platform**, and **mb_preprocess**) to convert raw sensor readings and geometry into properly located and oriented bathymetry, in place of the older, simpler **mb_lever** calculation. See also the **mbmakeplatform** manual page and the platform file format description therein.

−----------

int **mb_platform_setinfo**(
int *verbose*,
void **platform_ptr*,

int *type*,
char **name*,
char **organization*,
char **documentation_url*,
double *start_time_d*,
double *end_time_d*,
int **error*);

The function **mb_platform_setinfo** sets the identifying information of the platform pointed to by *platform_ptr*: its *type* (e.g. surface ship, ROV, AUV), *name*, *organization*, a *documentation_url*, and the time interval (*start_time_d* to *end_time_d*) over which this platform definition applies.

−----------

int **mb_platform_add_sensor**(
int *verbose*,
void **platform_ptr*,
int *type*,
mb_longname *model*,
mb_longname *manufacturer*,
mb_longname *serialnumber*,
int *capability1*,
int *capability2*,
int *num_offsets*,
int *num_time_latency*,
int **error*);

The function **mb_platform_add_sensor** appends a new sensor record to the platform pointed to by *platform_ptr*, of the given *type* (e.g. sonar, INS, GPS), identified by *model*, *manufacturer*, and *serialnumber*, with capability flags *capability1* and *capability2* describing what the sensor measures, and space allocated for *num_offsets* position/attitude offset records (see **mb_platform_set_sensor_offset**) and *num_time_latency* time latency model samples (see **mb_platform_set_sensor_timelatency**). Sensors are indexed in the order added, starting from zero.

−----------

int **mb_platform_set_sensor_offset**(
int *verbose*,
void **platform_ptr*,
int *isensor*,
int *ioffset*,
double *position_offset_x*,
double *position_offset_y*,
double *position_offset_z*,
double *attitude_offset_azimuth*,
double *attitude_offset_roll*,
double *attitude_offset_pitch*,
int **error*);

The function **mb_platform_set_sensor_offset** sets the *ioffset*th position offset (*position_offset_x*, *position_offset_y*, *position_offset_z*, in the platform's forward/starboard/down reference frame, meters) and attitude offset (*attitude_offset_azimuth*, *attitude_offset_roll*, *attitude_offset_pitch*, degrees) of sensor number *isensor* of the platform pointed to by *platform_ptr*, relative to the platform reference point.

−----------

int **mb_platform_set_sensor_timelatency**(
int *verbose*,
void **platform_ptr*,
int *isensor*,
int *time_latency_mode*,
double *time_latency_static*,
int *num_time_latency*,
double **time_latency_time_d*,
double **time_latency_value*,
int **error*);

The function **mb_platform_set_sensor_timelatency** sets the time latency model for sensor number *isensor* of the platform pointed to by *platform_ptr*, in the same sense as **mb_apply_time_latency**: if *time_latency_mode* is **MB_SENSOR_TIME_LATENCY_STATIC** a constant *time_latency_static* offset is used, and if **MB_SENSOR_TIME_LATENCY_MODEL** the *num_time_latency*-point model given by *time_latency_time_d* and *time_latency_value* is used instead.

−----------
int **mb_platform_set_sensor_flipsign_heading**(
int *verbose*,
void **platform_ptr*,
int *isensor*,
int **error*);
int **mb_platform_set_sensor_flipsign_roll**(
int *verbose*,
void **platform_ptr*,
int *isensor*,
int **error*);
int **mb_platform_set_sensor_flipsign_pitch**(
int *verbose*,
void **platform_ptr*,
int *isensor*,
int **error*);

The functions **mb_platform_set_sensor_flipsign_heading**, **mb_platform_set_sensor_flipsign_roll**, and **mb_platform_set_sensor_flipsign_pitch** each mark sensor number *isensor* of the platform pointed to by *platform_ptr* as having its heading, roll, or pitch sign convention reversed relative to the **MB-System** standard, so that **mb_platform_apply_flipsign_heading** and **mb_platform_apply_flipsign_attitude** will correct it.

−----------
int **mb_platform_set_source_sensor**(
int *verbose*,
void **platform_ptr*,
int *source_type*,
int *sensor*,
int **error*);

The function **mb_platform_set_source_sensor** designates sensor number *sensor* of the platform pointed to by *platform_ptr* as the source of a particular kind of data (*source_type* - e.g. navigation, heading, roll/pitch, heave, or sonar depth), so that functions such as **mb_platform_orientation** know which sensor's offsets to apply.

−----------

int **mb_platform_deall**(
int *verbose*,
void ***platform_ptr*,
int **error*);

The function **mb_platform_deall** deallocates a platform model previously allocated by **mb_platform_init** or **mb_platform_read** and pointed to by **platform_ptr*.

−----------

int **mb_platform_read**(
int *verbose*,
char **platform_file*,
void ***platform_ptr*,
int **error*);

The function **mb_platform_read** reads a platform definition from the file *platform_file* (as written by **mb_platform_write** or the **mbmakeplatform** program) and returns a newly allocated platform model in **platform_ptr*.

−----------

int **mb_platform_write**(
int *verbose*,
char **platform_file*,
void **platform_ptr*,
int **error*);

The function **mb_platform_write** writes the platform model pointed to by *platform_ptr* to the file *platform_file*, in the format read by **mb_platform_read**.

−----------

int **mb_platform_lever**(
int *verbose*,
void **platform_ptr*,
int *targetsensor*,
int *targetsensoroffset*,
double *heading*,
double *roll*,
double *pitch*,
double **lever_x*,
double **lever_y*,
double **lever_z*,
int **error*);

The function **mb_platform_lever** computes the lever arm correction (**lever_x*, **lever_y*, **lever_z*, in the platform reference frame) between the platform's navigation reference point and offset number *targetsensoroffset* of sensor number *targetsensor* of the platform pointed to by *platform_ptr*, given the platform's current *heading*, *roll*, and *pitch*. This generalizes the older **mb_lever** calculation to the full multi-sensor platform model.

−----------

int **mb_platform_position**(
int *verbose*,
void **platform_ptr*,
int *targetsensor*,

int *targetsensoroffset*,
double *navlon*,
double *navlat*,
double *sensordepth*,
double *heading*,
double *roll*,
double *pitch*,
double **targetlon*,
double **targetlat*,
double **targetz*,
int **error*);

The function **mb_platform_position** translates a navigation fix (*navlon*, *navlat*, *sensordepth*) obtained at the platform's navigation reference point, together with the current *heading*, *roll*, and *pitch*, into the corresponding position (**targetlon*, **targetlat*, **targetz*) of offset number *targetsensoroffset* of sensor number *targetsensor* of the platform pointed to by *platform_ptr*, applying the lever arm computed by **mb_platform_lever**.

−----------

int **mb_platform_position_offset**(
int *verbose*,
void **platform_ptr*,
int *targetsensor*,
int *targetsensoroffset*,
double **target_x_offset*,
double **target_y_offset*,
double **target_z_offset*,
int **error*);

The function **mb_platform_position_offset** returns just the position offset (**target_x_offset*, **target_y_offset*, **target_z_offset*, in the platform reference frame) of offset number *targetsensoroffset* of sensor number *target-sensor* of the platform pointed to by *platform_ptr*, without applying any attitude rotation.

−----------

int **mb_platform_apply_flipsign_attitude**(
int *verbose*,
void **platform_ptr*,
double **roll*,
double **pitch*,
int **error*);

The function **mb_platform_apply_flipsign_attitude** negates **roll* and/or **pitch* in place if the corresponding attitude source sensor of the platform pointed to by *platform_ptr* has been marked with **mb_plat-form_set_sensor_flipsign_roll** or **mb_platform_set_sensor_flipsign_pitch**.

−----------

int **mb_platform_apply_flipsign_heading**(
int *verbose*,
void **platform_ptr*,
double **heading*,
int **error*);

The function **mb_platform_apply_flipsign_heading** corrects **heading* in place if the heading source sensor of the platform pointed to by *platform_ptr* has been marked with

mb_platform_set_sensor_flipsign_heading.

−----------

int **mb_platform_orientation**(
int *verbose*,
void **platform_ptr*,
double *heading*,
double *roll*,
double *pitch*,
double **platform_heading*,
double **platform_roll*,
double **platform_pitch*,
int **error*);

The function **mb_platform_orientation** converts a raw *heading*, *roll*, and *pitch* reading from the platform's designated attitude and heading source sensors (see **mb_platform_set_source_sensor**) into the equivalent platform reference frame orientation (**platform_heading*, **platform_roll*, **platform_pitch*), correcting for that sensor's mounting angle offsets.

−----------

int **mb_platform_orientation_offset**(
int *verbose*,
void **platform_ptr*,
int *targetsensor*,
int *targetsensoroffset*,
double **target_hdg_offset*,
double **target_roll_offset*,
double **target_pitch_offset*,
int **error*);

The function **mb_platform_orientation_offset** returns just the mounting angle offsets (**target_hdg_offset*, **target_roll_offset*, **target_pitch_offset*) of offset number *targetsensoroffset* of sensor number *targetsensor* of the platform pointed to by *platform_ptr*.

−----------

int **mb_platform_orientation_target**(
int *verbose*,
void **platform_ptr*,
int *targetsensor*,
int *targetsensoroffset*,
double *heading*,
double *roll*,
double *pitch*,
double **target_heading*,
double **target_roll*,
double **target_pitch*,
int **error*);

The function **mb_platform_orientation_target** converts the platform reference frame orientation (*heading*, *roll*, *pitch*) into the corresponding orientation (**target_heading*, **target_roll*, **target_pitch*) of offset number *targetsensoroffset* of sensor number *targetsensor* of the platform pointed to by *platform_ptr*, applying that offset's mounting angles. This is the inverse sense of **mb_platform_orientation**.

−----------

int **mb_platform_copy**(
int *verbose*,
void **platform_ptr*,
void **platform_copy_ptr*,
int **error*);

The function **mb_platform_copy** copies the platform model pointed to by *platform_ptr* into the already-allocated platform structure pointed to by *platform_copy_ptr*.

−----------

int **mb_platform_print**(
int *verbose*,
void **platform_ptr*,
int **error*);

The function **mb_platform_print** prints, to standard error, a human-readable listing of the platform model pointed to by *platform_ptr*, including every sensor and its offsets. This is invoked automatically by many of the **mb_platform_*** functions above when *verbose* is 2 or greater.

−----------

void **mb_platform_math_matrix_times_vector_3x1**(
double **A*,
double **b*,
double **Ab*);
void **mb_platform_math_matrix_times_matrix_3x3**(
double **A*,
double **B*,
double **AB*);
void **mb_platform_math_matrix_transpose_3x3**(
double **R*,
double **R_T*);

The functions **mb_platform_math_matrix_times_vector_3x1**, **mb_platform_math_matrix_times_matrix_3x3**, and **mb_platform_math_matrix_transpose_3x3** are basic 3x3 matrix and 3-vector arithmetic helpers (matrix-vector product **Ab* = **A* times **b*, matrix product **AB* = **A* times **B*, and transpose **R_T* of **R*) used by the platform orientation calculations below.

−----------

void **mb_platform_math_rph2rot**(
double **rph*,
double **R*);
void **mb_platform_math_rot2rph**(
double **R*,
double **rph*);

The function **mb_platform_math_rph2rot** converts a roll/pitch/heading triple *rph* into the equivalent 3x3 rotation matrix *R*; **mb_platform_math_rot2rph** performs the inverse conversion.

−----------

int **mb_platform_math_attitude_offset**(
int *verbose*,
double *target_offset_roll*,

double *target_offset_pitch*,
double *target_offset_heading*,
double *source_offset_roll*,
double *source_offset_pitch*,
double *source_offset_heading*,
double **target2source_offset_roll*,
double **target2source_offset_pitch*,
double **target2source_offset_heading*,
int **error*);

The function **mb_platform_math_attitude_offset** computes the relative mounting angle offset (**target2source_offset_roll*, **target2source_offset_pitch*, **target2source_offset_heading*) between a target sensor mounted with offset (*target_offset_roll*, *target_offset_pitch*, *target_offset_heading*) and a source sensor mounted with offset (*source_offset_roll*, *source_offset_pitch*, *source_offset_heading*), both relative to the platform frame. This is a supporting calculation used by **mb_platform_orientation_offset** and related functions.

−----------

int **mb_platform_math_attitude_platform**(
int *verbose*,
double *nav_attitude_roll*,
double *nav_attitude_pitch*,
double *nav_attitude_heading*,
double *attitude_offset_roll*,
double *attitude_offset_pitch*,
double *attitude_offset_heading*,
double **platform_roll*,
double **platform_pitch*,
double **platform_heading*,
int **error*);

The function **mb_platform_math_attitude_platform** converts an attitude reading (*nav_attitude_roll*, *nav_attitude_pitch*, *nav_attitude_heading*) made by a sensor mounted with offset (*attitude_offset_roll*, *attitude_offset_pitch*, *attitude_offset_heading*) into the platform frame attitude (**platform_roll*, **platform_pitch*, **platform_heading*). This is a supporting calculation used by **mb_platform_orientation**.

−----------

int **mb_platform_math_attitude_target**(
int *verbose*,
double *source_attitude_roll*,
double *source_attitude_pitch*,
double *source_attitude_heading*,
double *target_offset_to_source_roll*,
double *target_offset_to_source_pitch*,
double *target_offset_to_source_heading*,
double **target_roll*,
double **target_pitch*,
double **target_heading*,
int **error*);

The function **mb_platform_math_attitude_target** converts an attitude (*source_attitude_roll*, *source_attitude_pitch*, *source_attitude_heading*) known in the source sensor's frame into the corresponding attitude (**target_roll*, **target_pitch*, **target_heading*) in the target sensor's frame, given the mounting offset of the target relative to the source (*target_offset_to_source_roll*, *target_offset_to_source_pitch*,

target_offset_to_source_heading). This is a supporting calculation used by **mb_platform_orientation_target**.

−----------

int **mb_platform_math_attitude_offset_corrected_by_nav**(
int *verbose*,
double *prev_attitude_roll*,
double *prev_attitude_pitch*,
double *prev_attitude_heading*,
double *target_offset_to_source_roll*,
double *target_offset_to_source_pitch*,
double *target_offset_to_source_heading*,
double *new_attitude_roll*,
double *new_attitude_pitch*,
double *new_attitude_heading*,
double **corrected_offset_roll*,
double **corrected_offset_pitch*,
double **corrected_offset_heading*,
int **error*);

The function **mb_platform_math_attitude_offset_corrected_by_nav** refines a previously estimated mounting angle offset (*target_offset_to_source_roll*, *target_offset_to_source_pitch*, *target_offset_to_source_heading*) using a change in navigation attitude from (*prev_attitude_roll*, *prev_attitude_pitch*, *prev_attitude_heading*) to (*new_attitude_roll*, *new_attitude_pitch*, *new_attitude_heading*), returning the corrected offset in (**corrected_offset_roll*, **corrected_offset_pitch*, **corrected_offset_heading*). This is a supporting calculation used by patch-test style sensor alignment calibration tools.

−----------

int **mb_platform_math_attitude_rotate_beam**(
int *verbose*,
double *beam_acrosstrack*,
double *beam_alongtrack*,
double *beam_bath*,
double *attitude_roll*,
double *attitude_pitch*,
double *attitude_heading*,
double **newbeam_easting*,
double **newbeam_northing*,
double **newbeam_bath*,
int **error*);

The function **mb_platform_math_attitude_rotate_beam** rotates a single bathymetry beam position (*beam_acrosstrack*, *beam_alongtrack*, *beam_bath*) by the attitude (*attitude_roll*, *attitude_pitch*, *attitude_heading*) into georeferenced easting, northing, and depth (**newbeam_easting*, **newbeam_northing*, **newbeam_bath*).

−----------

int **mb_double_compare**(
const void **a*,
const void **b*);

The function **mb_double_compare** is used with the **qsort** function to sort arrays of *double* values. This function returns 1 if a > b and −1 if a <= b.

−----------

int **mb_int_compare**(
const void **a*,
const void **b*);

The function **mb_int_compare** is used with the **qsort** function to sort arrays of *int* values. This function returns 1 if a > b and −1 if a <= b.

−----------

int **mb_edit_compare**(
const void **a*,
const void **b*);

The function **mb_edit_compare** is used with the **qsort** function to sort arrays of *struct mb_edit_struct* beam edit event records (as used in edit save files - see the **mbedit** and **mbclean** manual pages) by time and beam number. Two edit events whose times differ by less than a small tolerance are considered simultaneous and are then ordered by beam number.

−----------

int **mb_edit_compare_coarse**(
const void **a*,
const void **b*);

The function **mb_edit_compare_coarse** is used with the **qsort** function to sort arrays of *struct mb_edit_struct* beam edit event records in the same manner as **mb_edit_compare**, except that a coarser (larger) time tolerance is used in judging two edit events to be simultaneous.

−----------

int **mb_absorption**(
int *verbose*,
double *frequency*,
double *temperature*,
double *salinity*,
double *depth*,
double *ph*,
double *soundspeed*,
double **absorption*,
int **error*);

The function **mb_absorption** calculates the sound absorption coefficient **absorption* (dB/km) of sea water for a sonar signal of *frequency* (kHz) given the water *temperature* (degrees C), *salinity* (per mil), *depth* (meters), *ph*, and *soundspeed* (m/sec), following the standard Francois-Garrison absorption model. This is used, for example, by **mbbackangle** and **mbsvpselect** when correcting backscatter for water column transmission losses.

−----------

int **mb_potential_temperature**(
int *verbose*,
double *temperature*,
double *salinity*,
double *pressure*,
double **potential_temperature*,
int **error*);

The function **mb_potential_temperature** calculates the potential temperature **potential_temperature* (degrees C) of sea water given its in-situ *temperature* (degrees C), *salinity* (per mil), and *pressure* (dbar).

−----------

int **mb_seabird_density**(
int *verbose*,
double *salinity*,
double *temperature*,
double *pressure*,
double **density*,
int **error*);

The function **mb_seabird_density** calculates the density **density* (kg/mˆ3) of sea water given its *salinity* (per mil), *temperature* (degrees C), and *pressure* (dbar), following the algorithms used by Sea-Bird Electronics CTD processing software.

−----------

int **mb_seabird_depth**(
int *verbose*,
double *pressure*,
double *latitude*,
double **depth*,
int **error*);

The function **mb_seabird_depth** calculates the depth **depth* (meters) below the sea surface corresponding to a CTD *pressure* (dbar) reading at the given *latitude*, following the algorithms used by Sea-Bird Electronics CTD processing software.

−----------

int **mb_seabird_salinity**(
int *verbose*,
double *conductivity*,
double *temperature*,
double *pressure*,
double **salinity*,
int **error*);

The function **mb_seabird_salinity** calculates the salinity **salinity* (per mil) of sea water given its *conductivity*, *temperature* (degrees C), and *pressure* (dbar), following the algorithms used by Sea-Bird Electronics CTD processing software.

−----------

int **mb_seabird_soundspeed**(
int *verbose*,
int *algorithm*,
double *salinity*,
double *temperature*,
double *pressure*,
double **soundspeed*,
int **error*);

The function **mb_seabird_soundspeed** calculates the sound speed **soundspeed* (m/sec) of sea water given its *salinity* (per mil), *temperature* (degrees C), and *pressure* (dbar), using the sound speed formula selected by

algorithm, following the algorithms used by Sea-Bird Electronics CTD processing software.

−----------

int **mb_rt_init**(
int *verbose*,
int *number_node*,
double **depth*,
double **velocity*,
void ***modelptr*,
int **error*);

The function **mb_rt_init** initializes a layered water sound velocity model for ray tracing, given *number_node* depth/velocity pairs in the arrays *depth* and *velocity*, and returns a pointer to the model in **modelptr* for use by **mb_rt**.

−----------

int **mb_rt_deall**(
int *verbose*,
void ***modelptr*,
int **error*);

The function **mb_rt_deall** deallocates a velocity model previously initialized by **mb_rt_init** and pointed to by **modelptr*.

−----------

int **mb_rt**(
int *verbose*,
void **modelptr*,
double *source_depth*,
double *source_angle*,
double *end_time*,
int *ssv_mode*,
double *surface_vel*,
double *null_angle*,
int *nplot_max*,
int **nplot*,
double **xplot*,
double **zplot*,
double **tplot*,
double **x*,
double **z*,
double **travel_time*,
int **ray_stat*,
int **error*);

The function **mb_rt** traces a single ray, launched from *source_depth* at takeoff angle *source_angle*, through the layered velocity model *modelptr* (initialized by **mb_rt_init**) until either the elapsed travel time reaches *end_time* or the ray exits the model (surfacing, in which case *ssv_mode* and *surface_vel* control how the ray reflects off the sea surface, and rays arriving within *null_angle* of vertical are treated specially). The ray path is returned as up to *nplot_max* plotting points in *xplot*/*zplot*/*tplot* (with the actual number of points returned in **nplot*), and the ray's final horizontal range **x*, depth **z*, and elapsed **travel_time* are returned along with a **ray_stat* code describing how the ray terminated. Internally **mb_rt** calls **mb_rt_get_depth** and the family of **mb_rt_quad1**, **mb_rt_quad2**, **mb_rt_quad3**, **mb_rt_quad4**, **mb_rt_circular**, **mb_rt_plot_circular**,

mb_rt_line, and **mb_rt_vertical** functions below to trace the ray through each layer of the model according to the local velocity gradient and ray geometry; these are implementation details of the ray tracing algorithm and are not normally called directly by application programs.

−----------

int **mb_rt_get_depth**(
int *verbose*,
void **modelptr*,
double *beta*,
int *dir_sign*,
int *turn_sign*,
double **depth*,
int **error*);

The function **mb_rt_get_depth** returns the depth **depth* in the current layer of the velocity model *modelptr* corresponding to ray parameter *beta*, given the ray's current vertical travel direction *dir_sign* and turning state *turn_sign*. This is a supporting calculation used by **mb_rt**.

−----------

int **mb_rt_quad1**(
int *verbose*,
void **modelptr*,
int **error*);
int **mb_rt_quad2**(
int *verbose*,
void **modelptr*,
int **error*);
int **mb_rt_quad3**(
int *verbose*,
void **modelptr*,
int **error*);
int **mb_rt_quad4**(
int *verbose*,
void **modelptr*,
int **error*);

The functions **mb_rt_quad1**, **mb_rt_quad2**, **mb_rt_quad3**, and **mb_rt_quad4** each advance the ray being traced through the velocity model *modelptr* across one quadrant of curvature, handling the four combinations of upward or downward ray travel with increasing or decreasing velocity gradient. These are supporting calculations used internally by **mb_rt** and are not normally called directly.

−----------

int **mb_rt_circular**(
int *verbose*,
void **modelptr*,
int **error*);

The function **mb_rt_circular** advances the ray being traced through the velocity model *modelptr* along a circular arc appropriate to a layer of constant velocity gradient. This is a supporting calculation used internally by **mb_rt**.

−----------

int **mb_rt_plot_circular**(

int *verbose*,
void **modelptr*,
int **error*);

The function **mb_rt_plot_circular** generates the plotting points recording the circular ray path segment computed by **mb_rt_circular**. This is a supporting calculation used internally by **mb_rt**.

−----------

int **mb_rt_line**(
int *verbose*,
void **modelptr*,
int **error*);

The function **mb_rt_line** advances the ray being traced through the velocity model *modelptr* along a straight line segment appropriate to a layer of constant velocity. This is a supporting calculation used internally by **mb_rt**.

−----------

int **mb_rt_vertical**(
int *verbose*,
void **modelptr*,
int **error*);

The function **mb_rt_vertical** advances the ray being traced through the velocity model *modelptr* for the special case of a vertically traveling ray. This is a supporting calculation used internally by **mb_rt**.

COORDINATE SYSTEMS USED IN MB-SYSTEM

I. Introduction

The coordinate systems described below are used within **MB-System** for calculations involving the location in space of depth, amplitude, or sidescan data. In all cases the origin of the coordinate system is at the center of the sonar transducers.

II. Cartesian Coordinates

The cartesian coordinate system used in **MB-System** is a bit odd because it is left-handed, as opposed to the right-handed x-y-z space conventionally used in most circumstances. With respect to the sonar (or the ship on which the sonar is mounted), the x-axis is athwartships with positive to starboard (to the right if facing forward), the y-axis is fore-aft with positive forward, and the z-axis is positive down.

III. Spherical Coordinates

There are two non-traditional spherical coordinate systems used in **MB-System**. The first, referred to here as takeoff angle coordinates, is useful for raytracing. The second, referred to here as roll-pitch coordinates, is useful for taking account of corrections to roll and pitch angles.

III.1. Takeoff Angle Coordinates

The three parameters are r, theta, and phi, where r is the distance from the origin, theta is the angle from vertical down (that is, from the positive z-axis), and phi is the angle from acrosstrack (the positive x-axis) in the x-y plane. Note that theta is always positive; the direction in the x-y plane is given by phi. Raytracing is simple in these coordinates because the ray takeoff angle is just theta. However, applying roll or pitch corrections is complicated because roll and pitch have components in both theta and phi.

0 <= theta <= PI/2
-PI/2 <= phi <= 3*PI/2

x = rSIN(theta)COS(phi)
y = rSIN(theta)SIN(phi)
z = rCOS(theta)

theta = 0 −--> vertical, along positive z-axis
theta = PI/2 −--> horizontal, in x-y plane
phi = −PI/2 −--> aft, in y-z plane with y negative
phi = 0 −--> port, in x-z plane with x positive
phi = PI/2 −--> forward, in y-z plane with y positive
phi = PI −--> starboard, in x-z plane with x negative
phi = 3*PI/2 −--> aft, in y-z plane with y negative

III.2. Roll-Pitch Coordinates

The three parameters are r, alpha, and beta, where r is the distance from the origin, alpha is the angle forward (effectively pitch angle), and beta is the angle from horizontal in the x-z plane (effectively roll angle). Applying a roll or pitch correction is simple in these coordinates because pitch is just alpha and roll is just beta. However, raytracing is complicated because deflection from vertical has components in both alpha and beta.

-PI/2 <= alpha <= PI/2
0 <= beta <= PI

x = rCOS(alpha)COS(beta)
y = rSIN(alpha)
z = rCOS(alpha)SIN(beta)

alpha = −PI/2 −--> horizontal, in x-y plane with y negative
alpha = 0 −--> ship level, zero pitch, in x-z plane
alpha = PI/2 −--> horizontal, in x-y plane with y positive
beta = 0 −--> starboard, along positive x-axis
beta = PI/2 −--> in y-z plane rotated by alpha
beta = PI −--> port, along negative x-axis

IV. SeaBeam Coordinates

The per-beam parameters in the SB2100 data format include angle-from-vertical and angle-forward. Angle-from-vertical is the same as theta except that it is signed based on the acrosstrack direction (positive to starboard, negative to port). The angle-forward values are also defined slightly differently from phi, in that angle-forward is signed differently on the port and starboard sides. The SeaBeam 2100 External Interface Specifications document includes both discussion and figures illustrating the angle-forward value. To summarize:

Port:

theta = absolute value of angle-from-vertical

-PI/2 <= phi <= PI/2
is equivalent to
-PI/2 <= angle-forward <= PI/2

phi = −PI/2 −--> angle-forward = −PI/2 (aft)
phi = 0 −--> angle-forward = 0 (starboard)
phi = PI/2 −--> angle-forward = PI/2 (forward)

Starboard:

theta = angle-from-vertical

PI/2 <= phi <= 3*PI/2
is equivalent to
-PI/2 <= angle-forward <= PI/2

phi = PI/2 −--> angle-forward = −PI/2 (forward)
phi = PI −--> angle-forward = 0 (port)
phi = 3*PI/2 −--> angle-forward = PI/2 (aft)

V. Usage of Coordinate Systems in **MB-System**

Some sonar data formats provide angle values along with travel times. The angles are converted to takoff-angle coordinates regardless of the storage form of the particular data format. Currently, most data formats do not contain an alongtrack component to the position values; in these cases the conversion is trivial since phi = beta = 0 and theta = alpha. The angle and travel time values can be accessed using the **MBIO** function **mb_ttimes**. All angle values passed by **MB-System** functions are in degrees rather than radians.

The programs **mbbath** and **mbvelocitytool** use angles in take-off angle coordinates to do the raytracing. If roll and/or pitch corrections are to be made, the angles are converted to roll-pitch coordinates, corrected, and then converted back prior to raytracing.

BEAM FLAGS USED IN MB-SYSTEM

MB-System uses arrays of 1-byte "beamflag" values to indicate beam data quality. Each beamflag value is actually an eight bit mask allowing fairly complicated information to be stored regarding each bathymetry value. In particular, beams may be flagged as bad, they may be selected as being of special interest, and one or more reasons for flagging or selection may be indicated. This scheme is very similar to the convention used in the HMPS hydrographic data processing package and the SAIC Hydrobat package. The beam selection mechanism is not currently used by any **MB-System** programs.

The flag and select bits:
xxxxxx00 => This beam is neither flagged nor selected.
xxxxxx01 => This beam is flagged as bad and should be ignored.
xxxxxx10 => This beam has been selected.

Flagging modes:
00000001 => Flagged because no detection was made by the sonar.
xxxxx101 => Flagged by manual editing.
xxxx1x01 => Flagged by automatic filter.
xxx1xx01 => Flagged by automatic filter in the current program.
xx1xxx01 => Flagged because this is a secondary bottom pick.
x1xxxx01 => Flagged because this is an interpolated rather than
observed sounding.
1xxxxx01 => Flagged as unreliable using original quality values
from sonar.
(The bits at xxx1xx01, xx1xxx01, and x1xxxx01 originally meant, respectively, that the uncertainty exceeded 1 X or 2 X the IHO standard, or that the footprint was too large; those original meanings are deprecated.)

Selection modes:
00000010 => Selected, no reason specified.

xxxxx110 => Selected as least depth.
xxxx1x10 => Selected as average depth.
xxx1xx10 => Selected as maximum depth.
xx1xxx10 => Selected as location of sidescan contact.
x1xxxx10 => Selected, spare.
1xxxxx10 => Selected, spare.

SEE ALSO

mbsystem(l), **mbformat**(l)

BUGS

What could go wrong in a mere 374,852 lines of C code?
Let us know...