

NAME

mbauvnavusbl – Adjusts inertial navigation of a submerged platform/vehicle to be consistent with more accurate but less precise surface tracking (USBL) navigation.

VERSION

Version 5.0

SYNOPSIS

mbauvnavusbl *-Inavfile -Oonavfile -Uusblfile [-A -Fnavformat -Llonflip -Musblformat -V -H]*

DESCRIPTION

MBauvnavusbl reads a primary navigation file (usually from a submerged platform swath survey) and also reads secondary navigation (e.g. USBL fixes). The program calculates position offsets between the raw survey navigation and the secondary navigation every 3600 seconds (10 minutes), and then linearly interpolates and applies this adjustment vector for each primary navigation position.

The inertial navigation is read in format 166 and the USBL navigation is read from format 165 files. The adjusted navigation is output in format 166.

MB-SYSTEM AUTHORSHIP

David W. Caress
 Monterey Bay Aquarium Research Institute
 Dale N. Chayes
 Center for Coastal and Ocean Mapping
 University of New Hampshire
 Christian do Santos Ferreira
 MARUM - Center for Marine Environmental Sciences
 University of Bremen

OPTIONS

- A** Causes **mbauvnavusbl** to use the average calculated position offset over the whole dataset, rather than interpolating a time-varying offset, when adjusting the primary navigation.
- F** *navformat*
 Accepted but currently unused: the input primary navigation file is always parsed as whitespace-delimited ASCII text regardless of this value. Default: *navformat* = 9.
- H** This "help" flag cause the program to print out a description of its operation and then exit immediately.
- I** *inavfile*
 Sets the input navigation filename. The navigation data must be in format 166.
- L** *lonflip*
 Sets the range of the longitude values used. If *lonflip*=-1 then the longitude values will be in the range from -360 to 0 degrees. If *lonflip*=0 then the longitude values will be in the range from -180 to 180 degrees. If *lonflip*=1 then the longitude values will be in the range from 0 to 360 degrees. Default: **mbauvnavusbl** uses the user default *lonflip* set using **mbdefaults**.
- M** *usblformat*
 Accepted but currently unused: the input USBL navigation file is always parsed as whitespace-delimited ASCII text regardless of this value. Default: *usblformat* = 165.

- O** *onavfile*
Sets the output navigation filename. The navigation data will be in format 166.
- U** *usblfile*
Sets the input usbl navigation filename. The usbl navigation data must be in format 165.
- V** The **-V** option causes the program to be verbose.

EXAMPLE

Coming...

SEE ALSO

mbsystem(1)

BUGS

Da.