

SONiX 32-Bit Cortex-M0 Micro-Controller

DMA UARTtoSPI Example Code

SONiX reserves the right to make change without further notice to any products herein to improve reliability, function or design. SONiX does not assume any liability arising out of the application or use of any product or circuit described herein; neither does it convey any license under its patent rights nor the rights of others. SONiX products are not designed, intended, or authorized for use as components in systems intended, for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the SONiX product could create a situation where personal injury or death may occur. Should Buyer purchase or use SONiX products for any such unintended or unauthorized application, Buyer shall indemnify and hold SONiX and its officers, employees, subsidiaries, affiliates and distributors harmless against all claims, cost, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use even if such claim alleges that SONiX was negligent regarding the design or manufacture of the part.

AMENDENT HISTORY

Version	Date	Description
1.0	2024/11/29	1. First version.

Table of Content

1	OVERVIEW.....	4
2	FEATURE	4
3	HW	4
4	EXAMPLE CODE.....	5
4.1	INITIALIZATION	5
4.2	DMA FUNCTION ENABLE	6
5	RESULT	7

1 OVERVIEW

This document provides our customers the C program examples of DMA peripheral(UART) to peripheral(SPI) mode.

2 FEATURE

- DMA UART to SPI mode.
- Use ARM-compiler V6.12

3 HW

- The starter kit board of vendor desired MCU.
- Connect UART0 TX to UART0 RX, SPI0 MISO to SPI0 MOSI.

4 EXAMPLE CODE

4.1 Initialization

Initial UART, SPI and DMA function. User can modify the settings of UART, SPI and DMA in these function.

```
76 // Initial UART & SPI
77 UART0_Init();
78 SPI0_Init();
79
80 //Auto-SEL enable
81 SN_SPI0->CTRL0_b.SELDIS = SPI_SELDIS_EN;
82
83 // Disable UART ISR when using DMA UART & SPI
84 NVIC_DisableIRQ(UART0_IRQn);
85 NVIC_DisableIRQ(SPI0_IRQn);
86
87 // Init DMA
88 DMAUartToSpiInit();
89 // DMA SPI RX to SRAM for data check
90 DMASpiToSramInit();
```

UART will transmit 32 bytes of data from 0x00 to 0x1F.

```
99 for(i = 0; i<DMA_TEST_SIZE ;i++)
100 {
101     // UART0 TX data
102     UART0_SendByte(i);
103 }
```

4.2 DMA function enable

After DMA function enable. DMA request will be issued when the SPI TX FIFO is less than the threshold and UART RX is not empty.


```
92 // Start DMA UART TX transfer & DMA SPI
93 UART0_DMASizeSet(DMA_TEST_SIZE);
94 UART0_DMAEnable();
95 SPI0_DMAEnable(mskSPI_TX_DMA_EN|mskSPI_RX_DMA_EN, DMA_TEST_SIZE);
96 DMASpiToSramStart();
97 DMAUartToSpiStart();
```

The DMA TC flag and interrupt will be set when all data transfers are completed.


```
105 // Wait for DMA TC interrupt flag
106 while(stDMA0IntFlag[eDMA_CH0].Flag.bits.TC != 1);
107 while(stDMA0IntFlag[eDMA_CH1].Flag.bits.TC != 1);
```

5 RESULT

The data sent or received can be observed on UART and SPI bus.



The results can be observed through Watch window or Memory window.



SONiX reserves the right to make change without further notice to any products herein to improve reliability, function or design. SONiX does not assume any liability arising out of the application or use of any product or circuit described herein; neither does it convey any license under its patent rights nor the rights of others. SONiX products are not designed, intended, or authorized for use as components in systems intended, for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the SONiX product could create a situation where personal injury or death may occur. Should Buyer purchase or use SONiX products for any such unintended or unauthorized application. Buyer shall indemnify and hold SONiX and its officers, employees, subsidiaries, affiliates and distributors harmless against all claims, cost, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use even if such claim alleges that SONiX was negligent regarding the design or manufacture of the part.

Main Office:

Address: 10F-1, NO. 36, Taiyuan Street., Chupei City, Hsinchu, Taiwan R.O.C.
Tel: 886-3-5600 888
Fax: 886-3-5600 889

Taipei Office:

Address: 15F-2, NO. 171, Song Ted Road, Taipei, Taiwan R.O.C.
Tel: 886-2-2759 1980
Fax: 886-2-2759 8180

Hong Kong Office:

Unit No.705,Level 7 Tower 1,Grand Central Plaza 138 Shatin Rural Committee Road, Shatin, New Territories, Hong Kong.
Tel: 852-2723-8086
Fax: 852-2723-9179

Technical Support by Email:

Sn8fae@sonix.com.tw