

Delete/Esc为进入BIOS键 F4为保存键 F7为快捷启动键


AC启动



Aptio Setup Utility – Copyright (C) 2020 American




风扇调速步骤



Aptio Setup Utility – Copyright (C) 2020 American Advanced

Smart	Fan	function setting 1 Mode Tempterature 1 Tempterature 2 Tempterature 3 Tempterature 4 Critical Tempterature PWM 1 PWM 2 PWM 3 PWM 4 2 Mode Tempterature 1 Tempterature 2 Tempterature 2 Tempterature 3 Tempterature 4 Critical Tempterature PWM 1 PWM 2 PWM 3 PWM 4	30 40 50 60 60 130 170 200 255	DMatic Mode] 风扇温控设置界面/ 根据不同风扇的转速/ 自定设置合适的数值 matic Mode]	+: 11: Ente +/-: F1: F2: F3: UF4: S
					ESC:

主板网络唤醒设置



Aptio Setup Utility – Copyright (C) 2020 American Mega

Network Stack Lan Wake up Control

[Disabled] [Enabled]

Lan

将此选项设置为Enabied

→+: Sel ↑↓: Sel

Enter: +/-: Ch

F1: Gen


F2: Pre

F3: Opt: F4: Save


ESC: Exi

Version 2 17 1240

主板网卡启动



Aptio Setup Utility – Copyright (C) 2020 American Mega



Vencion o

Aptio Setup Utility – Copyright (C) 2020 American Main Advanced IntelRCSetup Security Boot Save & Exit

RC Revision

04.04.00

- Processor Configuration <
- Advanced Power Management Configuratio 超线程第一步设置选项
- Common RefCode Configuration
- QPI Configuration
- Memory Configuration
- IIO Configuration
- ► PCH Configuration
- Miscellaneous Configuration
- Server ME Debug Configuration
- Server ME Configuration
- Runtime Error Logging
- Reserve Memory

Setup Warning:

Setting items on this Screen to incorrect values may cause system to malfunction!

Aptio Setup Utility – Copyright (C) 2020 American IntelRCSetup

Internesetup	
Microcode Revision L1 Cache RAM L2 Cache RAM L3 Cache RAM Processor O Version Processor 1 Version 关闭	00000043 N/A 768KB N/A 3072KB N/A 30720KB N/A Intel(R) Xeon(R) CPU E5 -2678 v3 @ 2.50GHz Not Present
Hyper-Threading [ALL] Check CPU BIST Result Monitor/Mwait Execute Disable Bit Enable Intel TXT Support VMX	[Enable] — Hyper-Threading [ALL] — Disable Enable
Enable SMX Lock Chipset MSR Lock Control PPIN Control DEBUG INTERFACE Hardware Prefetcher Adjacent Cache Prefetch DCU Streamer Prefetcher DCU IP Prefetcher DCU Mode	[Disable] [Enable] [Unlock/Enable] [Disable] [Enable] [Enable] [Enable] [Enable] [Enable] [Enable] [S2KB 8Way Without ECC]

内存频率

Aptio Setup Utility – Copyright (C) 2020 America Main Advanced IntelRCSetup Security Boot Save & Exit 04.04.00 RC Revision Processor Configuration Advanced Power Management Configuration Common RefCode Configuration QPI Configuration Memory Configuration —— 内存频率设置第一步选项 IIO Configuration ▶ PCH Configuration ▶ Miscellaneous Configuration Server ME Debug Configuration Server ME Configuration Runtime Error Logging Reserve Memory Setup Warning: Setting items on this Screen to incorrect values may cause system to malfunction!

Aptio Setup Utility – Copyright (C) 2020 American IntelRCSetup



PCIE拆分

Aptio Setup Utility - Copyright (C) 2020 American Main Advanced IntelRCSetup Security Boot Save & Exit RC Revision 04.04.00 Processor Configuration Advanced Power Management Configuration Common RefCode Configuration QPI Configuration Memory Configuration 设置PCIE 拆分第一步 IIO Configuration PCH Configuration ▶ Miscellaneous Configuration Server ME Debug Configuration Server ME Configuration Runtime Error Logging Reserve Memory Setup Warning: Setting items on this Screen to incorrect values may cause system to malfunction!

PCIe Train by BIOS
PCIe Hot Plug
PCIe ACPI Hot Plug
EV DFX Features
IIO0 Configuration Cpu1 控制2,3显卡槽
IIO1 Configuration Cpu2 控制1显卡槽

IOAT Configuration

▶ IIO General Configuration

▶ Intel VT for Directed I/O (VT-d)

PCI Express Global Options

TX EQ WA [Enable] DMI Vc1 Control [Disable] DMI Vcp Control [Disable] DMI Vcm Control [Disable] VCO No-Snoop Configuration [Disable] Gen3 Phase3 Loop Count [16] Skip Halt On DMI Degradation [Disable] Power down unused ports [yes] SLD WA Revision [Auto] Rx Clock WA [Disable] PCI-E ASPM (Global) [L1 Only]

```
IOU2 (IIO PCIe Port 1)
IOU0 (IIO PCIe Port 2)
IOU1 (IIO PCIe Port 3)
No PCIe port active ECO
Socket O PcieDOOFO - Port O/DMI
Socket O PcieDO1FO - Port 1A
Socket O PcieDO1F1 - Port 1B
Socket O PcieDO2FO - Port 2A
Socket O PcieDO3FO - Port 3A
IOUO Non-Posted Prefetch
IOU1 Non-Posted Prefetch
```

```
[x4x4]
[x16]
[x16]
[PCU Squelch exit ig
```

[Disable]
[Disable]
[Disable]

VT-D设置

RC Revision → Processor Configuration → Advanced Power Management Configuration	nation	Displays and provides option to change the IIO Settings
► Memory Configuration ► PCH Configuration ► OverClocking Feature ► Miscellaneous Configuration ► Server ME Configuration	第一步	
Setup Warning: Setting items on this Screen to may cause system to malfunction!	incorrect values	**: Select Screen **: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Aptio Setup Utility - Copyright (C) 2018 American Megatrends, Inc. IntelRCSetup

IIO Configuration PCIe Train by BIOS [ues] PCIE Hot Plug TDIsable! PCIe ACPI Hot Plug ID isable! EV DFX Features [Disable] IIOO Configuration IDAT Configuration IIO General Configuration PCI Express Global Options (Enable) TX ED WA [Enable] DMT Voi Control [Enable] DMI Vcp Control [Enable] DMI Vem Control [Disable] VCO No-Snoop Configuration [16] Gen3 Phase3 Loop Count [Disable] Skip Halt On DMI Degradation IDisable Unused Port... Power down unused ports [Auto] SLD WA Revision [Disable]

Rox Clock WA

PCI-E ASPM Support (Global)

PCIE Stop & Scream Support

▲ Press (Entero to bring up the Intel VT for Directed I/D (VT-d) Configuration menu.

++: Select Screen T1: Select Item Enter: Select +/-: Change Opt. FI: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: EWit


IL1 Only

[Disable]

硬盘热插拔

RC Revision Processor Configuration Advanced Power Management Configuration Common RefCode Configuration QPI Configuration Memory Configuration IIO Configuration PCH Configuration <--Miscellaneous Configuration Server ME Debug Configuration Server ME Configuration Runtime Error Logging Reserve Memory Setup Warning: Setting items on this Screen to incorrect values may cause system to malfunction!

PCH Configuration [Enabled] Onboard Lan1 [Enabled] Onboard Lan2 [Auto] Onboard Azalia PCH Devices PCI Express Configuration PCH sSATA Configuration PCH SATA Configuration < ▶ USB Configuration Security Configuration Azalia Configuration Platform Thermal Configuration



定时开机

KC Kevision 04.04.00 Processor Configuration Advanced Power Management Configuration Common RefCode Configuration QPI Configuration Memory Configuration IIO Configuration PCH Configuration Miscellaneous Configuration Server ME Debug Configuration Server ME Configuration Runtime Error Logging Reserve Memory Setup Warning: Setting items on this Screen to incorrect values may cause system to malfunction!

Version o

Miscellaneous Configuration Fan PWM Offset [4096B] PCIe Max Read Request Size PCIe Latency Tolerance Reporting [Enable] PCI Minimum Secondary Bus Number PCIe Extended Tag Enable [Enable] PCIe AtomicOp Request Support [Disable] Breakpoint Type [None] BIOS Guard [Disabled] Serial Debug Message Level [Maximum] Trace Messages [Disabled] Training Messages [Disabled] RC Promote Warnings [Enabled] RC Promote MRC Warnings [Enabled] Active Video [Offboard Device] Target VGA Vga From CPU O RTC Wake system from S5 [Enable]← 开启 Wake up hour Wake up minute Wake up second WatchDog OS Timer [Disable] BIOS Timer [Disable]

[Disable]