

Guitar Tap

User Manual

Version 1.0.2

iOS/iPadOS · macOS · Windows · Linux

Acoustic resonance analysis for luthiers and tonewood researchers.

Copyright © 2026 David W. Smith dba Dolce Sfogato.
All rights reserved.

Contents

Chapter 1 — Introduction

1.1 What Guitar Tap Does

1.2 What You Need

1.3 How This Manual Is Organised

Chapter 2 — Getting Started

2.1 Installing the App

2.2 Granting Microphone Permission

2.3 Selecting Your Audio Input

2.4 Importing a Microphone Calibration File

2.5 Choosing a Measurement Type

2.6 Setting the Threshold — Finding Your Tap Level

2.7 Setting Peak Min — Filtering the Peak List (Guitar Mode)

2.8 Your First Tap — Guitar Mode Walkthrough

Chapter 3 — Guitar Mode

3.1 Mode Labels and Classification

3.2 Setting Up for Guitar Mode

3.3 Microphone Placement

3.4 Single Tap Measurement

3.5 Multi-Tap Averaging

3.6 Inspecting and Adjusting Peak Selections

3.7 Overriding Mode Classification

3.8 Reading the Results Panel

3.9 Comparing Guitar Measurements

Chapter 4 — Plate Mode

4.1 Overview of Plate Material Measurements

4.2 Preparing the Sample

4.3 Entering Dimensions in Settings

4.4 The 22% Suspension Technique

4.5 The Accept / Redo Review Flow

4.6 Tap 1 — Longitudinal

4.7 Tap 2 — Cross-Grain

4.8 Tap 3 — FLC (Optional)

4.9 Reading Plate Results

Detected Peaks

Gore Target Thickness

Plate Properties

Plate Process Instructions

4.10 Interpreting Plate Results

Chapter 5 — Brace Mode

5.1 Overview

5.2 Setting Up Brace Dimensions

5.3 Technique

5.4 Reading Brace Results

Detected Peaks

Brace Properties

Brace Process Instructions

5.5 Using Brace Mode to Compare Stock

Chapter 6 — Working with the Spectrum

6.1 Live vs. Frozen Spectrum

6.2 Zooming and Panning — iOS and iPadOS

6.3 Zooming and Panning — macOS, Windows, and Linux Desktop

6.4 Auto dB

6.5 The Crosshair (iOS and iPadOS)

6.6 Peak Labels

6.7 Annotation Modes

6.8 Saving the Current View as Default

Chapter 7 — Saving, Exporting, and Sharing Measurements

7.1 Saving a Measurement

7.2 Viewing Saved Measurements

7.3 Loading a Measurement into the View

7.4 Viewing Measurement Details

7.5 Editing Name and Notes

7.6 Exporting a Spectrum Image

7.7 Exporting a PDF Report

7.8 Exporting a Measurement

7.9 Importing a Measurement

7.10 Exporting or Backing Up the Whole Library

7.11 Sharing Between Devices

7.12 Deleting Measurements

Chapter 8 — Settings Reference

8.1 Opening Settings

8.2 Audio Input & Calibration

Capture sample rate

8.3 Measurement Type

8.4 Advanced — Display Settings

8.5 Advanced — Analysis Settings

8.6 About & Help

Chapter 9 — Controls Reference

9.1 Toolbar — iOS iPhone (Portrait)

9.2 Toolbar — iOS iPhone (Landscape)

9.3 Toolbar — iOS iPad

9.4 Menu Bar — Desktop

9.5 Individual Controls

9.6 Tap Controls

9.7 Status Bar

9.8 Spectrum Chart Interactions

Chapter 10 — Tips, Technique, and Troubleshooting

10.1 Tap Technique

10.2 Consistent Microphone Position

10.3 Dealing with Background Noise

10.4 Decoupling the Top from the Air Mode

10.5 Ring-Out and Decay Time

10.6 Multi-Tap Averaging Strategy

10.7 Common Problems

Chapter 11 — Glossary

Appendix A — Keyboard Shortcuts

Application menu

File menu

View menu

Help menu

Appendix B — File Formats

Measurement files (`.guitartap`)

File-level structure

Measurement object

UUID-keyed maps

SpectrumSnapshot

Spectrum data encoding

Peak

ComparisonEntry (when `comparisonEntries` is present)

TapEntry (when `tapEntries` is present)

Legacy compatibility (reader-only)

Calibration files (`.txt` / `.cal`)

Exported formats

Chapter 1 — Introduction

1.1 What Guitar Tap Does



Guitar Tap captures a tap, runs an FFT, and presents the resulting spectrum with annotated peaks and a results panel. The app is designed around the three measurements a luthier following the Gore methodology (or any similar tap-tone-based workflow) actually takes:

- **Guitar mode** — for a complete instrument body. Single or multi-tap averaging; identifies air, top, and back modes plus any other significant body resonances above the detection threshold.
- **Plate mode** — for a free plate. Walks you through a longitudinal tap, a cross-grain tap, and optionally a free-length-cross tap, with a review step between phases so you can accept or redo each one before continuing.
- **Brace mode** — for an individual brace. Captures a single longitudinal resonance.

In all three modes the tap is captured with onset alignment so the same physical tap reliably yields the same spectrum, regardless of where in the FFT frame the impulse happens to land. Measurements can be saved locally, exported as PDF or spectrum data, and shared as `.guitartap` files that round-trip between the iOS, macOS, and desktop builds.

1.2 What You Need

Hardware

- **A device.** Guitar Tap runs on iPhone or iPad (iOS 17 or later), Mac (macOS 14 Sonoma or later), and Windows or Linux desktops via the Python version of the app.
- **A microphone.** The built-in microphone of an iPhone, iPad, or modern Mac is good enough for relative comparisons (one plate against another, before and after a thickness change) even if absolute values may be slightly off. For repeatable absolute frequencies and clean spectra, a calibrated measurement microphone (such as a miniDSP UMIK-1) on a USB audio interface is the recommended setup. Microphone choice is discussed further in §2.3.
- **A tapping implement.** The recommended implement is a small bouncy ball on the end of a stick — it produces a short, clean impulse with low operator variability. A firm knuckle rap also works well, particularly for guitar-body measurements.
- **A quiet workspace.** A quieter room lets you set a lower detection threshold and capture softer taps cleanly.
- **The material to be measured.** A free plate, a brace, or a complete instrument.

Optional

- **A microphone calibration file** (`.txt` or `.cal`) for your measurement microphone. Importing it lets the app correct the spectrum for the microphone's frequency response. See §2.4.

1.3 How This Manual Is Organised

If you have just installed Guitar Tap and want to take your first measurement, start with **Chapter 2 — Getting Started**. It covers installation, microphone permission, audio-input selection, threshold and peak-min tuning, and a complete first guitar measurement.

If you already know the app and want a focused walk-through of a particular task — measuring a free plate, multi-tap sequences, export and share workflows — see the **Guided Use Cases (Chapters 3 through 8)**.

For complete details on a specific control, setting, or shortcut, see the **Reference chapters (9 through 11)** and the **Appendices**.

A **Glossary** at the end defines the acoustic-analysis terms used throughout the manual.

Chapter 2 — Getting Started

This chapter takes you from a fresh install to your first measurement. Sections 2.6 and 2.7 cover one-time tuning that any new microphone or room benefits from; the settings persist so you only do it once.

2.1 Installing the App

iOS / iPadOS. Search "Guitar Tap" in the App Store and install.

macOS (native). Search "Guitar Tap" in the Mac App Store and install.

macOS / Windows (Python desktop build). Run the installer for your platform from the project release page. The build is bundled with PyInstaller and ships with its own Python runtime — no separate Python installation is required.

Linux (Python desktop build). Download the AppImage from the project release page, mark it executable (`chmod +x GuitarTap-x.y.z.AppImage`), and run it directly. The AppImage includes everything required; no system packages need to be installed.

The native and Python builds share the `.guitartap` file format — measurements written on one can be opened on the other without loss.

2.2 Granting Microphone Permission

Guitar Tap cannot operate without microphone access. The grant procedure differs by platform.


iOS / iPadOS. A system dialog appears on first launch. Tap **Allow**. If you declined, re-enable in **Settings → Guitar Tap → Microphone**.

macOS. A system dialog appears on first launch. If you declined, or already declined for a previous build, open **System Settings → Privacy & Security → Microphone** and enable Guitar Tap.

Windows. Open **Settings → Privacy & Security → Microphone**. Ensure both "Microphone access" and "Let desktop apps access your microphone" are on.

Linux. PortAudio uses the system's PulseAudio or PipeWire permissions; there is no in-app dialog. If recording is silent, check the Recording tab of `pavucontrol` (or your equivalent mixer) while Guitar Tap is running.

2.3 Selecting Your Audio Input



Open Settings (gear icon, top toolbar) and use the **Audio Input** section to pick your microphone.

- Selecting a device takes effect immediately and persists across launches; you do not need to confirm or apply the change.
- The built-in microphone of a modern Mac, iPhone, or iPad is fine for relative comparisons.

- A USB measurement microphone (such as a miniDSP UMIK-1) on a USB audio interface gives lower noise, flatter response, and supports per-device calibration (§2.4).
- The currently selected input is shown in the analysis screen so you always know what is being captured.

2.4 Importing a Microphone Calibration File

A calibration file corrects the captured spectrum for the microphone's own frequency response. Without it, the spectrum includes whatever roll-off and bumps the microphone contributes.

Guitar Tap accepts `.txt` and `.cal` files in the standard two-column (frequency, dB) format that ships with most measurement microphones.

To import:

1. In **Settings** → **Audio Input**, with your measurement microphone selected, choose **Import Calibration File** and pick the file.
2. The calibration is bound to that input device. When you switch away from it and back again later, the calibration reloads automatically.
3. To remove all stored calibrations, use **Clear All Calibrations** in the same section.

The status area indicates when a calibration is active for the current input.

2.5 Choosing a Measurement Type

In Settings, the **Measurement Type** section determines what the analyzer is looking for:

- **Generic Guitar / Acoustic Guitar / Classical Guitar / Flamenco Guitar.** Guitar-body mode. The four sub-types differ in the expected frequency windows for the air, top, back, and dipole modes; pick the one closest to the instrument you are measuring. Generic uses the broadest windows.
- **Plate.** Free-plate measurement with the longitudinal, cross-grain, and optional free-length-cross phases.
- **Brace.** Single-tap longitudinal measurement on an individual brace.

The choice persists across launches. Changing it mid-sequence starts a new sequence in the new mode.

2.6 Setting the Threshold — Finding Your Tap Level



The Threshold slider sets the signal level a tap must exceed before the analyzer captures it. You will tune it once for your microphone, room, and tapping style; the value then persists.

The tuning procedure is the same in all three measurement modes:

1. Press **Pause**. The spectrum stays live, but no taps will register — you can experiment without triggering a measurement.
2. Make a representative tap and read the highest dB the live spectrum reaches.
3. Set Threshold roughly **6 to 10 dB below** that peak level. This leaves headroom for tap-to-tap variation while staying clear of ambient noise.
4. Press **Resume** and tap again. The spectrum should freeze and the **Tap Detected** indicator should appear.

If taps are missed, lower the threshold. If ambient noise triggers false captures, raise it.

2.7 Setting Peak Min — Filtering the Peak List (Guitar Mode)

Peak Min sets the minimum spectrum magnitude at which a peak is *shown* — annotated on the chart and listed in the Analysis Results. It is a pure display filter: moving it shows or hides peaks but never changes which peaks are selected, how they are classified, or the identified modes. It is a guitar-mode control: in Plate and Brace modes the per-phase capture uses its own adaptive noise floor, and there too Peak Min only affects which peaks are *drawn*.

Tune it from the same paused state used for Threshold:

1. Still paused (continuing from §2.6), make a few representative taps and watch the peaks appear on the live spectrum.
2. Raise Peak Min until noise peaks disappear. Lower it until the structural resonances you care about are visible.
3. Press **Resume** and take the real measurement.

Because Peak Min only hides and reveals peaks, a peak hidden then shown again returns exactly as it was — same selection, custom label, and annotation position.

The same works on a **loaded** measurement: a saved measurement keeps its full peak set (every detected peak, down to –100 dB), so lowering Peak Min reveals the quieter peaks exactly as on a live spectrum. (Measurements saved by versions before 1.0.2 stored only the peaks above the Peak Min in force when they were captured; on those, lowering Peak Min reveals nothing new — press **Re-analyze** (§9) to rebuild the peak set from the stored spectrum.)

Peak Min persists across launches.

2.8 Your First Tap — Guitar Mode Walkthrough

You now have everything you need.

1. Position the microphone 5 to 15 cm from the sound hole. (For top- or back-tap measurements, position it 5 to 10 cm from the tap point.)
2. The analyzer is already running on launch. Confirm Threshold and Peak Min are tuned per §2.6 and §2.7.
3. Press **Resume** if you paused during tuning. The detector is armed and the spectrum is live.
4. Tap the guitar — a knuckle rap on the bridge or a bouncy-ball strike on the back, depending on what you are measuring. The spectrum freezes when the tap registers.
5. Open the **Analysis Results** panel and review the identified modes, frequencies, ring-out time, and tap-tone ratio.
6. Press **Save** in the top toolbar to store the measurement so you can compare it to future taps.

That is a complete cycle. From here, see the use-case chapters for the workflow you actually want to run — guitar (Chapter 3), plate (Chapter 4), or brace (Chapter 5).

Chapter 3 — Guitar Mode

Guitar mode captures the body resonances of a completed instrument and presents them as a labelled peak list. This chapter assumes the microphone, calibration, threshold, and peak-min are already tuned as described in Chapter 2.

3.1 Mode Labels and Classification

Guitar Tap identifies and labels six classes of guitar-body modes: **Air**, **Top**, **Back**, **Dipole**, **Ring**, and **Upper Modes**. Classification is by frequency window: each guitar subtype (Generic, Acoustic, Classical, Flamenco) defines a range of frequencies in which a candidate for each mode is expected. The strongest peak inside a window is assigned to that mode; peaks outside every window are labelled **Unknown**.

Unknown peaks are shown on the chart by default so nothing in the spectrum is silently hidden. If you find them cluttering a chart that you intend to share or compare, turn them off via **Settings → Advanced → Analysis Settings → Show Unknown Modes**.

Generic is the recommended subtype for most measurement work. Its windows are wide enough to catch the air, top, and back modes of any of the common guitar archetypes, which is what you want when you simply need to see and label the resonances of the instrument in front of you. The other subtypes — Acoustic, Classical, Flamenco — are narrower and are most useful when:

- you want the **quality indicators** in the Results panel to reflect the typical frequency band for that style (the colour cues next to each mode and the tap-tone ratio are interpreted against the chosen subtype's expectations); or
- you are building or voicing to a **target frequency range** associated with a particular style and want the windows to exclude peaks that fall outside that target.

The frequency windows can be inspected in Settings → Measurement Type when a subtype is selected.

3.2 Setting Up for Guitar Mode

1. Open **Settings → Measurement Type** and choose **Generic Guitar** unless you have a specific reason (quality indicators or a target frequency range) to choose Acoustic, Classical, or Flamenco — see §3.1.
2. The frequency-window panel updates to show the ranges for the selected subtype. Confirm they bracket the modes you expect to find.

3. **Show Unknown Modes** is on by default. Leave it on unless you are preparing a chart for sharing and want to declutter.
4. Confirm Threshold and Peak Min are tuned for the current mic and room (see §2.6 and §2.7).

3.3 Microphone Placement

- **Distance:** 5 to 15 cm from the sound hole for body-cavity measurements; 5 to 10 cm from the tap point for top or back measurements.
- **Angle:** roughly perpendicular to the soundboard or back, but not so close that the diaphragm sees only one localized region.
- **Surroundings:** avoid hard surfaces within ~30 cm of the microphone. Reflections add spurious peaks and inflate the noise floor at the comb frequencies of the workbench geometry.
- **Reproducibility:** mark the mic position (a piece of tape on the bench is sufficient) if you intend to compare measurements across sessions on the same instrument. Small position changes shift the relative magnitudes of modes you may want to track build-to-build.

3.4 Single Tap Measurement

1. Press **New Tap** to arm the detector. The status area shows the analyzer is waiting for a tap.
2. Tap the instrument: a short, crisp knuckle or fingertip rap on the bridge, or a bouncy-ball strike on the back.
3. The **Tap Detected** indicator appears and the spectrum freezes automatically.
4. Read the annotated peaks on the frozen spectrum and the Analysis Results panel (see §3.8 for what each column means).

If the tap was missed or contaminated (a finger squeak, an ambient transient), press **New Tap** again to discard it and try once more.

If Threshold or Peak Min need adjusting before the live take, press **Pause** first — the spectrum stays live and no taps will register while you experiment. Move the sliders, tap freely, then press **Resume** when ready.

3.5 Multi-Tap Averaging

For tighter results, average several taps in one sequence.

1. Set the **Taps** stepper at the top of the toolbar to the number of taps you want (1 to 10). Five is a common choice.
2. Press **New Tap** as before. The status bar now shows progress — "Tap 1/5", "Tap 2/5", and so on.

3. Tap the instrument the required number of times. Each captured tap re-arms the detector after a short cooldown; the spectrum re-freezes only after the final tap.
4. When all taps are captured, the averaged spectrum is displayed with annotated peaks. Individual tap spectra are retained for comparison.

The Taps table. After a multi-tap sequence the Analysis Results header shows a **Taps** button that switches to a per-tap table: one row per tap plus an **Averaged** row, with Air / Top / Back columns. Each per-tap row reports that tap's own detected peak for the mode; the Averaged row reports the *definitive* peak — the one your selection and any mode overrides resolve to (§3.6) — so it matches the peak list and the PDF report. When you have overridden a mode, the Averaged value is shown in *italics with a trailing asterisk* (`*`) to flag that it came from your override rather than the automatic pick. Press Taps again to return to the averaged spectrum.

Pause between taps. Press Pause if you need to pause mid-sequence (to reset the instrument's position, for example). The captured taps so far are preserved; Resume continues from where you left off.

Cancel mid-sequence. Press **Cancel** to restart the sequence — it discards the captured taps and immediately re-arms for a fresh attempt, so you can tap again straight away (no need to press New Tap). **New Tap** itself is only available once a measurement is complete.

Starting a fresh measurement — New Tap, or Cancel-to-restart — begins from a clean slate: any peak selection, mode overrides, and moved annotation labels from the previous measurement are cleared.

3.6 Inspecting and Adjusting Peak Selections

Each peak in the frozen spectrum is shown with a label (mode name) and a coloured dot whose colour matches its row in the Analysis Results panel.

- **Toggle a peak's selection** by tapping its label on the chart. Selected peaks contribute to derived values such as the tap-tone ratio; deselected peaks remain visible but are excluded from the calculation.
- **Cycle the annotation set** using the Annotations button: *All* (every detected peak labelled), *Selected* (only currently selected peaks), or *None* (no labels on the chart). The default is *Selected*, which matches what most luthiers want to see.
- **Re-run automatic selection** by pressing the **wand** button in the Analysis Results header. It resets peak *selection* to the automatic choice — one peak per single-holder mode, chosen from the full peak set — replacing any manual selection you made. Your mode-name overrides are kept. The wand does not re-detect or re-classify; to rebuild the peak set from a saved measurement's stored spectrum, or to re-classify after changing the guitar type, use the separate **Re-analyze** button (§9).
- **Select None** clears the selection in one step. There is no "Select All": Air, Top, and Back are single-holder modes (below), so selecting everything is not a meaningful operation.

One peak per structural mode. Air, Top, and Back each resolve to exactly one *definitive* peak — the selected peak whose mode, after any override, is that mode. Selecting a second candidate as Top displaces the first, so the identity is never ambiguous. Dipole, Ring, and Upper Modes are clusters and may hold several peaks at once. The definitive peaks are what every derived value (§3.8) and export is computed from.

Selection changes are preserved when the measurement is saved.

3.7 Overriding Mode Classification


The automatic classifier occasionally picks the wrong peak — for example, when two candidates are close in magnitude and the wrong one falls inside the configured window. To correct it:

1. In the Analysis Results panel, tap the row of the peak whose label you want to change.
2. A mode picker appears with **Air**, **Top**, **Back**, **Dipole**, **Ring**, **Upper Modes**, **Unknown**, and a **Custom label** field for free-text annotations.
3. Pick the correct mode. The chart label updates immediately.

Overrides are saved with the measurement and reapplied when the measurement is loaded later. The wand (§3.6) resets selection but keeps your mode-name overrides.

Changing the guitar type clears overrides. If you change the guitar type in Settings, Guitar Tap re-classifies the peaks for the new type, clears your manual mode overrides, and returns selection to automatic — the identified modes always match the current type. (A display-only settings change — Peak Min or the display ranges — leaves peaks, modes, and selection untouched.)

3.8 Reading the Results Panel


Analysis Results
Classical
Umik-1 Gain: 18dB
Showing 75.0 Hz - 350.0 Hz
Air (Helmholtz)
95.0 Hz
F#2 (+46 ¢)
Q: 21.7 BW: 4.4 Hz
-54.3 dB
Unknown
130.4 Hz
C3 (-6 ¢)
Q: 0.6 BW: 206.5 Hz
-62.2 dB
Unknown
152.8 Hz
D#3 (-31 ¢)
Q: 2.0 BW: 76.9 Hz
-57.8 dB
Top
188.0 Hz
F#3 (+28 ¢)
Q: 28.6 BW: 6.6 Hz
-39.4 dB
Back
238.8 Hz
A#3 (+42 ¢)
Q: 21.7 BW: 11.0 Hz
-50.4 dB
Back
256.1 Hz
C4 (-37 ¢)
Q: 5.1 BW: 50.5 Hz
-56.6 dB
Unknown
287.2 Hz
Ring-Out
0.14s Very Short
–15 dB
Tap Ratio
1.98:1 Ideal
Ideal: 1.9–2.1
Analyzing
Export Spectrum
Export PDF

For each identified peak the Analysis Results panel shows:

- **Mode label** — Air, Top, Back, Dipole, Ring, Upper, or a custom override.
- **Frequency** — in Hz, to 0.1 Hz.
- **Magnitude** — in dB, relative to the spectrum's reference.
- **Q** — quality factor (centre frequency ÷ –3 dB bandwidth).
- **Bandwidth** — –3 dB bandwidth in Hz.
- **Pitch** — nearest equal-temperament note plus cents offset.

Below the peak list:

- **Ring-out** — decay time in seconds, computed from the magnitude envelope after the tap impulse. A structural-damping indicator.
- **Tap Tone Ratio** — f_Top ÷ f_Air, computed from the definitive (selected, override-aware) Air and Top peaks (§3.6), so the panel, the peak list, and the PDF report always agree. Typical values for a well-voiced guitar fall in the 1.8–2.4 range; the value is shown with a colour cue indicating whether it is in, near, or outside that band.

When a value is missing (a mode was not identified, or the ring-out could not be measured), the panel displays "—" rather than zero so the absence is unambiguous.

3.9 Comparing Guitar Measurements

Comparison overlays two to five saved guitar measurements on the same chart. Useful for any pair-or-more of measurements you want to see side by side — different build stages of the same instrument, different tap locations on the same body, different instruments you have built, or measurements of instruments built by someone else that you want to study or learn from.



Starting a comparison

1. Open the **Measurements** list.
2. Tap to select two to five saved guitar measurements. Plate and brace measurements are excluded — comparison is guitar-only.
3. Tap the **Compare** button that appears once two or more measurements are selected.

The chart switches to comparison view: each selected spectrum is drawn in a distinct colour with a legend. The Analysis Results panel switches to a comparison table with one column per spectrum (labelled with the colour dot from the legend) and rows for Air, Top, and Back frequencies. "—" appears where a mode was not identified.

What is available during comparison

Save, Export Spectrum, and Export PDF Report all remain active, but they operate on the overlay rather than on an individual measurement:

- **Save** stores the entire overlay as a single comparison in the Measurements list. The save sheet accepts an optional location label and notes. The saved comparison appears with a distinct badge and can be reloaded later to restore the overlay — every spectrum, its colour, and the Comparison Results table — exactly as it was. The comparison records which peak carries each mode (Air / Top / Back) for every spectrum, including any overrides in effect, so the reloaded table and its PDF match the originals; comparisons saved by earlier builds gain this information automatically when they are opened.

- **Export Spectrum** (⌘E on macOS; Ctrl+E on Windows / Linux) writes an overlay PNG with all curves, their colours, and the legend.
- **Export PDF Report** (⇧ ⌘E on macOS; Ctrl+Shift+E on Windows / Linux) writes a comparison PDF: a metadata header (number of spectra, labels, date), the overlay image, and an Air / Top / Back frequency table with one column per spectrum.

A saved comparison `.guitartap` file can be **imported** via **File → Import Measurement** (macOS / Python desktop) or the Import Measurement button in the Measurements list (iOS). The app detects the comparison on load and restores the overlay.

What is inactive during comparison

- **Annotations** button — each spectrum carries its own annotations set at capture time; there is nothing to cycle in the overlay.
- **Threshold** and **Peak Min** sliders — the comparison view is a static overlay of frozen measurements; live detection is not running.
- **Taps** stepper — no active capture sequence to configure.

Exiting comparison. Press **New Tap** to leave comparison mode and return to single-measurement operation.

Chapter 4 — Plate Mode

Plate mode captures the longitudinal, cross-grain, and (optionally) free-length-cross resonances of a rectangular tonewood blank and returns the moduli, specific modulus, radiation ratio, and Gore target thickness for the piece. This chapter assumes the microphone, calibration, threshold, and peak-min are already tuned as described in Chapter 2.

4.1 Overview of Plate Material Measurements

Plate mode runs a guided sequence of two or three taps on a rectangular blank suspended at its nodal points and computes the material properties used to evaluate a piece of tonewood:

- **Longitudinal (L)** — bending mode with grain. Yields E_L and c_L.
- **Cross-grain (C)** — bending mode across the grain. Yields E_C and c_C.
- **Free-length-cross (FLC)** — torsional mode, optional. Yields the shear modulus G_LC, which feeds the Gore target thickness calculation and tightens its result by roughly 5 to 7%.

From these the app derives ρ (from your dimensions and mass), specific modulus E_L/ρ, radiation ratio R, the E_C/E_L cross-to-long ratio, a quality rating against the spruce scale, and the Gore target thickness for the body dimensions and stiffness preset you have selected.

Plate mode is for raw blanks before bracing or cutting. For an individual brace, use Brace mode (Chapter 5); for a finished body, use Guitar mode (Chapter 3).

4.2 Preparing the Sample


The blank should be a clean rectangle with the grain parallel to one long axis. The numbers you enter into the app drive every derived quantity, so accuracy matters:

Field	Target accuracy
Length (along grain)	0.5 mm
Width (cross grain)	0.5 mm
Thickness	0.1 mm
Mass	0.1 g

A digital caliper handles the thickness measurement. Length and width are typically beyond the jaw span of a caliper for guitar-scale blanks; an accurate steel rule is the better tool there. A jeweller's scale or any 0.1 g kitchen scale handles mass.

Mass error dominates. Length and width errors scale linearly into the moduli; thickness scales as the cube. A 1% mass error and a 0.3% thickness error produce comparable changes in E.

4.3 Entering Dimensions in Settings



Open **Settings** → **Measurement Type** → **Plate**. Fill in:

- **Length** (mm) — along the grain.

- **Width** (mm) — across the grain.
- **Thickness** (mm).
- **Mass** (g).

A live **density preview** appears below the dimension fields. Use it as a sanity check on data entry. Spruce typically lands in the 0.35–0.45 g/cm³ band; a value below 0.30 or above 0.70 is almost always a transposed digit or a unit error somewhere in the four fields.

For the Gore target thickness, also enter:

- **Body Length** (mm) and **Lower Bout Width** (mm) — the dimensions of the instrument the plate is destined for.
- **Plate Stiffness Preset** — the target stiffness number the Gore thickness calculation solves for. The named presets are starting points calibrated to typical instrument styles:
  - **Steel String Top** (75)
  - **Steel String Back** (55)
  - **Classical** (50)
  - **Custom** — accepts any numeric target.

Custom is where you encode a successful build back into the calculation. The workflow has four steps:

1. Fully measure a plate — E_L, E_C, density, body dimensions — *before* you build it, and keep the measurements. Note the final plate thickness you settled on for the build (which may be the number from the Gore formula).
2. Build the instrument and live with it long enough to decide whether the result is what you want. If it is, you have a calibration point. If not, you need to adjust the plate stiffness preset on your next build to either stiffen the board or loosen it to adjust the sound.
3. The Gore formula run on that plate's measurements with a named preset would have predicted some recommended thickness. Your finished thickness is the thickness that actually produced the sound you liked. Scale the preset's stiffness number linearly so the formula, applied to that same plate's measurements, would output your finished thickness. Save the scaled number as your **Custom** value.
4. From this point on, run new plates with **Custom** selected. Each new board, with its own E_L, E_C, and ρ, yields a *different* recommended thickness — each one calculated to reproduce the calibration build's tonal outcome on that specific piece of wood.

The Custom number carries "this is the kind of plate that makes the instrument I want." The Gore procedure does not predict an objectively ideal thickness; it gives you a reproducible way to translate a tonal target across pieces of wood that differ in stiffness and density.

Measure FLC is a toggle in the same section. Turn it on if you intend to capture the FLC tap (§4.8). The sequence then runs in three phases instead of two.

4.4 The 22% Suspension Technique

The three taps share one principle: hold the blank at a nodal point of the mode you want to measure, and tap at an antinode.

For longitudinal and cross-grain there is a catch — **both modes are easy to excite at the same time**, and the hold point alone decides which one wins in the spectrum. A hold on a mode's nodal line suspends that mode (it can vibrate freely); a hold on a mode's antinode damps it. To get a clean reading the hold must sit **on the target mode's node *and* off the orthogonal mode's node.**

In all three orientations the **tap point is the centre of the plate face**.

- **Longitudinal.** Plate oriented with grain horizontal.
  - The longitudinal mode's nodal line runs cross-wise at 22% from each short end.
  - The cross-grain mode's nodal lines run length-wise at 22% from each long edge.
  - Hold between thumb and forefinger **22% in from one short end along the length, close to one long edge but not at 22% in from it.** The other end of the plate hangs free; tap at the centre.
- **Cross-grain.** Rotate the plate 90° so grain is now vertical. Same logic with the modes swapped: now the cross-grain mode's node is the one you want to be on, and the longitudinal mode's node is the one to avoid.
  - Hold **22% in from one long edge, close to one short end but not at 22% in from it.** Other end hangs free.
- **FLC.** One hand only. Hold at the **midpoint of one long edge**. Tap near the **opposite corner**, approximately 22% in from both the end and the side. The torsional mode FLC excites has its node along the centreline of the plate, so a single midpoint hold is enough.

Common errors: putting the hold on both modes' node lines at once (contamination — a longitudinal reading that looks like cross-grain or vice versa); holding too far in along the target axis (the support falls inside the mode shape and damps it); holding too firmly (adds damping regardless of position); and forgetting to rotate the plate between L and C — easy to do, easy to spot when C reads close to L.

4.5 The Accept / Redo Review Flow

Plate mode runs each phase as: arm, tap, freeze, review.

After a tap is captured the spectrum freezes and the detector pauses automatically. The tap controls re-label for the review state:

- The **Pause** button becomes **Accept** (green tint, checkmark icon). Pressing it locks in the current phase result and advances to the next phase. The next phase arms detection on its own — you do not need to press New Tap between phases.
- The **Cancel** button becomes **Redo** (orange, labelled **Redo L**, **Redo C**, or **Redo FLC** depending on which phase is being reviewed). Pressing it discards the current phase result and re-arms detection for the same phase.

During review the live spectrum is suppressed so the captured spectrum stays on screen for inspection. The status bar shows the current phase and tap count: **Phase 2/3 · Tap 1/1**, for example.

After every phase is accepted the Results panel updates with the complete plate calculations (§4.9).

Individual phase redo is only available **before** that phase is accepted. To restart the entire sequence — for example, you realise mid-FLC that the longitudinal tap was made before you'd entered the right dimensions — press **New Tap**; the captured phases are discarded and the sequence starts again from Longitudinal.

4.6 Tap 1 — Longitudinal

1. Orient the plate with the **grain running horizontally**.
2. Hold at 22% from each end along the length, near one long edge.
3. Press **New Tap**. The status bar shows **Capturing Longitudinal · Phase 1/2** (or **Phase 1/3** if Measure FLC is on).
4. Tap the centre of the plate face.
5. The spectrum freezes. Inspect the lowest peak — it should be the longitudinal bending mode for a free-free beam of your dimensions, typically in the low hundreds of Hz for a guitar top.
6. Press **Accept** to lock the phase in, or **Redo L** to re-capture if the tap was contaminated.

After Accept the sequence advances to Cross-grain automatically.

4.7 Tap 2 — Cross-Grain

1. **Rotate the plate 90°** so the grain now runs vertically.
2. Hold at 22% from each end along the width, near one short edge.
3. The status bar now reads **Capturing Cross-grain · Phase 2/2** (or **Phase 2/3**). Detection is already armed — do not press New Tap.
4. Tap the centre of the plate face.

5. Inspect the frozen spectrum, then **Accept** or **Redo C**.

After Accept, the sequence either advances to FLC (if Measure FLC is on) or marks the measurement complete.


4.8 Tap 3 — FLC (Optional)

FLC measures the flat long/cross torsional mode and yields the shear modulus G_LC. The Gore target thickness calculation uses G_LC for its shear correction; without it, the calculation substitutes a default that over-estimates target thickness by roughly 5 to 7%. For final plate thicknessing, capturing FLC is worth the extra tap.

1. Enable Measure FLC in Settings before starting the sequence if you have not already.
2. Hold one long edge at its **midpoint**, with one hand only.
3. The status bar reads **Capturing FLC · Phase 3/3**.
4. Tap near the **opposite corner**, approximately 22% in from the end and 22% in from the side.
5. **Accept** or **Redo FLC**.

After Accept the measurement is complete and the Results panel updates with Gore target thickness including the shear correction.

4.9 Reading Plate Results



For a completed plate measurement the Results panel scrolls through four sections, top to bottom.

Detected Peaks

One row per captured phase — two rows (L, C) for a two-tap sequence, three rows (L, C, FLC) when FLC is enabled. Each row shows a selection-indicator star, the peak frequency, the peak magnitude in dB, and a coloured phase badge identifying which mode the peak belongs to (blue L, orange C, purple FLC). The full detected-peak list and the Peak Min filter from guitar mode do not apply here; what you see is the auto-selected best peak from each phase capture.

Gore Target Thickness

The headline thickness for the body dimensions and stiffness preset entered in Settings, displayed prominently in mm. Below the number:

- **Shear Modulus (G_LC)** — the value used in the thickness calculation, shown when FLC was measured.
- **"G_LC assumed 0 — enable FLC tap for a more accurate result"** — shown when FLC was skipped. The thickness above is then approximate (roughly 5 to 7% over-estimate; see §4.8).

- **Body dimensions** and the **f_vs** value (with preset name, or a literal "custom" annotation when Custom is active) — the parameters that fed the calculation, exposed so you can cross-check Settings against the body the plate is destined for.

Plate Properties

Material characterisation of the wood:

- **Frequencies used** — fL, fC, and (if measured) fLC.
- **Speed of Sound** — c_L and c_C in m/s.
- **Young's Modulus (E)** — E_L and E_C in GPa. **G_LC** is appended to this block when FLC was measured; the row is absent when FLC was skipped.
- **Specific Modulus (E/ρ)** — the headline material number, in GPa/(g/cm³). Shown in large type for both Longitudinal and Cross-grain, each with a per-direction quality rating (Excellent / Very Good / Good / Fair / Poor against the spruce scale) and a colour cue matching that rating.
- **Radiation Ratio (R)** — reported for both directions.
- **Cross/Long Ratio** — E_C / E_L. Typical spruce 0.04 to 0.08; the typical band is shown beside the value.
- **Long/Cross Ratio** — the reciprocal. Typical spruce 12 to 25; the typical band is shown beside the value.
- **Overall Quality** — a separate row at the bottom of the section combining both directions into a single rating (Excellent / Very Good / Good / Fair / Poor) with the matching colour cue.

The quality scales are calibrated for spruce; readings on cedar, redwood, or other top woods read as a point of comparison rather than an absolute grade.

Plate Process Instructions

A reference card describing the two-tap (or three-tap, if FLC is enabled) measurement procedure. Useful as an in-place refresher when you come back to plate mode after a break and want the hold and tap positions without leaving the results panel.

4.10 Interpreting Plate Results

Specific modulus and radiation ratio capture what Young's modulus alone misses: how stiff a plate is **per unit of weight it is asking the player to drive**. Two blanks with identical E_L can sit in very different quality bands when their densities differ. Sort by E_L/ρ, not E_L, when triaging a stack of blanks.

Gore target thickness is a starting point for thicknessing, not a specification. Reproduce it on the bench, then voice from there with hands-on tap-tone evaluation; the final number lives at the intersection of your wood, your bracing pattern, and the instrument design you are building toward.

For tracking measurements across multiple blanks: enter a brief identifier (board number, supplier, billet) into the Notes field on the Save sheet so the saved measurement carries its provenance. Plate measurements can be saved, reloaded, and exported the same way guitar measurements can (Chapter 7); the comparison overlay described in §3.9 is guitar-only.

Chapter 5 — Brace Mode

Brace mode is a fast, single-tap longitudinal measurement for an individual brace strip. It reports the moduli, specific modulus, and quality rating in one capture; cross-grain, shear, and Gore thickness are all skipped. This chapter assumes the microphone, calibration, threshold, and peak-min are already tuned as in Chapter 2.

5.1 Overview


Brace mode runs a single longitudinal tap on a brace strip and returns the wood's stiffness and quality. Compared to Plate mode:

- **No cross-grain tap.** E_C is not measured.
- **No FLC tap.** G_LC is not measured.
- **No Cross/Long ratio.**
- **No Gore target thickness.** Brace mode is for stock evaluation, not for thicknessing.

What you get: E_L, c_L, specific modulus E_L/ρ with a per-direction quality rating against the spruce scale, and radiation ratio R.

Brace mode is intended for batch-evaluating brace strips before selecting stock for a build. For a free plate, use Plate mode (Chapter 4); for a complete instrument, use Guitar mode (Chapter 3).

5.2 Setting Up Brace Dimensions



Open **Settings** → **Measurement Type** → **Brace**. The Brace Dimensions section has four fields:

- **Length (along grain)** (mm) — the long axis of the strip.
- **Width (breadth)** (mm) — the brace's breadth lying flat.
- **Height (tap direction)** (mm) — the dimension perpendicular to the face you tap. This is the `t` in the Euler–Bernoulli stiffness formula, so it's the one that drives E_L most strongly. The Settings panel itself flags this with a helper line under the field; double-check it before tapping.
- **Mass** (g).

A **Calculated Density** line appears below the fields once all four are populated. Use it the same way as the plate-mode density preview — spruce should land in the 0.35–0.45 g/cm³ range, and a value well outside that is almost always a digit transposition.

5.3 Technique


A brace strip is a long thin beam — the same free-free fundamental applies, but the measurement is much simpler than plate because only one mode is in play.

1. Hold the strip between thumb and forefinger **22% in from one end along the length**. The other end hangs free.

2. Lay the strip flat (or mount it however you usually orient it on the bench) so the face you intend to tap is exposed. The `Height` value in Settings must match the dimension perpendicular to this face.
3. Press **New Tap**.
4. Tap the centre of the top face. The spectrum freezes when the tap registers.

The **Accept** / **Redo** review flow is the same as in Plate mode (see §4.5). Accept locks in the measurement; Redo discards it and re-arms the detector. There is no phase counter — Brace mode runs in a single phase, so the status bar shows just the current state.

5.4 Reading Brace Results



A completed brace measurement displays three sections in the Results panel.

Detected Peaks

A single row for the longitudinal peak. It shows a selection-indicator star, the peak frequency, the peak magnitude in dB, and a blue **L** phase badge.

Brace Properties

- **Frequency used** — fL in Hz.
- **Speed of Sound** — c_L in m/s.
- **Young's Modulus (E)** — in GPa.
- **Specific Modulus (E/ρ)** — the headline number, in GPa/(g/cm³), shown in large type. A quality rating (Excellent / Very Good / Good / Fair / Poor against the spruce scale) accompanies the value with a matching colour cue.
- **Radiation Ratio (R)** — in the same column.

There is no Cross/Long ratio or Overall Quality row — both are plate-only since they need cross-grain data.

Brace Process Instructions

A reference card describing the brace measurement procedure. Useful as an in-place refresher when you have come back to Brace mode after a break.

5.5 Using Brace Mode to Compare Stock

A practical workflow for evaluating a batch of brace strips:

1. Label each strip (a pencil mark on the end grain or a small sticky label works) so you can match measurements to physical pieces later.
2. Enter the strip's Length, Width, Height, and Mass in Settings. For a batch of strips with consistent stock dimensions you only have to change Mass between measurements; for variable stock all four fields need updating.
3. Tap the strip.
4. Record the result. The **Notes** field on the Save sheet is the right place for the strip's identifier — once saved, the saved measurement carries its provenance.
5. Move on to the next strip.

For sorting by stiffness alone, the longitudinal frequency at the same dimensions is a sufficient proxy — higher fL means stiffer stock. For triaging across different sizes, sort by specific modulus (E_L/ρ).

A practical limitation worth keeping in mind: with no cross-grain or shear data, brace-to-brace comparisons are one-dimensional. A strip that reads well in brace mode might still have anisotropy or grain runout that only shows up in a plate-style measurement on the parent billet.

Chapter 6 — Working with the Spectrum

The spectrum chart is the centrepiece of the analysis screen. This chapter covers the gestures, shortcuts, and settings that let you read it the way you want without disturbing the measurement itself.

6.1 Live vs. Frozen Spectrum

Before a tap registers, the spectrum is **live** — the chart redraws on every FFT frame, showing the current microphone input in real time. Use this state to monitor ambient noise, dial in Threshold and Peak Min while paused (§2.6, §2.7), or simply confirm the microphone is working.

When a tap registers, the spectrum **freezes** on the capture so you can inspect peaks, drag labels, and read the Analysis Results panel without the chart moving under you. The status bar shows "Tap Detected" when the freeze happens.

Pressing **New Tap** discards the frozen capture (or current sequence) and returns to live mode, arming the detector for the next tap.

6.2 Zooming and Panning — iOS and iPadOS

- **Pinch** anywhere over the plot area to zoom both axes.
- **Pinch over the frequency axis** (the bottom of the chart) to zoom the frequency axis only.
- **Pinch over the magnitude axis** (the left edge) to zoom the magnitude axis only.
- **Drag** over the plot area to pan both axes. Drag over a single axis to pan that axis only.

To reset the view, tap the **…** button in the upper-right corner of the spectrum chart. The **Chart Options** sheet opens with two sections, each offering a per-axis or both-axes choice:

- **Reset to Saved**
  - Reset Both Axes
  - Reset Frequency Axis
  - Reset Magnitude Axis

These return the chosen axis (or both) to the view stored as your default — see §6.8.


- **Reset to Defaults**
  - Reset Both Axes
  - Reset Frequency Axis
  - Reset Magnitude Axis

These return the chosen axis (or both) to the app's built-in starting range.

The same sheet also exposes **Reset Labels** when any peak labels have been dragged from their auto-positions; that control is covered in §6.6.

6.3 Zooming and Panning — macOS, Windows, and Linux Desktop

Desktop interaction follows the same pattern as iOS/iPadOS but uses the scroll wheel and modifier keys. The chart is divided into three hover zones, each with its own scroll behaviour:



- **Scroll over the plot area** to zoom both axes simultaneously.
- **Scroll over the frequency axis** (the bottom of the chart) to zoom the frequency axis only.
- **Scroll over the magnitude axis** (the left edge) to zoom the magnitude axis only.
- **Drag** in any of the three zones to pan with the same axis-sensitivity rules.

Modifier keys augment scrolling without changing which zone you are in:

Modifier	Scroll effect
⇧ Shift	Pan the frequency axis
⌥ Option (macOS) / Alt (Windows / Linux)	Pan the magnitude axis
⌘ Command (macOS) / Ctrl (Windows / Linux)	Zoom both axes

On a trackpad, two-finger **pinch** works the same as scroll-wheel zoom — over the plot area for both axes, over an axis for that axis only.

To reset the view, click the **…** (Chart Options) button in the upper-right corner of the chart and choose a Reset option, or **right-click** anywhere in the chart area for the same menu.

Two icons sit in the upper-right corner of the spectrum window: the **…** Chart Options button (axis/label resets, above) and the **?** icon, which opens a Zoom & Pan Controls popover that summarises all the gestures and modifier keys for the current platform.

6.4 Auto dB

Auto dB scales the magnitude axis to fit the current signal: the floor moves to just below the lowest visible value and the ceiling to just above the highest. It is the fastest way to land on a sensible magnitude range after a measurement, especially when the captured tap was much louder or quieter than the live signal that preceded it.

A button in the toolbar invokes Auto dB. The keyboard shortcut is **⌘0** on macOS; **Ctrl+0** on Windows and Linux.

Use Auto dB after each measurement, or any time the spectrum clips or sits flat against the magnitude floor.

6.5 The Crosshair (iOS and iPadOS)

The crosshair is a touch-based readout for inspecting frequency and magnitude at any point on the chart.

1. Tap the crosshair icon in the toolbar to enable it. The icon switches to while crosshair mode is active.
2. Touch and drag anywhere on the chart. A vertical and horizontal line follow your finger; a small readout shows the frequency (Hz) and magnitude (dB) under the crosshair.
3. Tap the icon again to disable.

The crosshair is a read-only tool — it does not change the selected peaks, the spectrum, or any saved state. On desktop there is no toggle; the crosshair follows the mouse pointer continuously whenever the pointer is over the chart, showing the frequency and magnitude under the cursor in real time.

6.6 Peak Labels

Each annotated peak carries a label showing the mode name, frequency (and pitch with cents offset in guitar mode). Labels are positioned automatically to minimise overlap, but you can move any label to a position you prefer.

- **Drag** a label to reposition it. The new position is saved with the measurement and restored when the measurement is reloaded.
- **Reset an individual label** — double-tap on iOS / iPadOS; right-click and choose **Reset Position** on desktop.
- **Reset all labels** — open the **…** menu in the upper-right corner of the spectrum chart and choose **Reset Labels** on iOS / iPadOS; right-click an empty area of the chart and choose **Reset Labels** on desktop.

6.7 Annotation Modes

The **Annotations** button cycles through three states that control which peaks are labelled on the chart:

- **All** — every detected peak is labelled. Useful for surveying a spectrum where you have not yet decided which peaks matter.
- **Selected** (default) — only peaks currently selected for analysis are labelled. Matches what most luthiers want during normal use.
- **None** — no labels. Useful for clean export images or for reading the bare spectrum shape without distractions.

In **plate** and **brace** mode there is no per-peak selection — the identified Longitudinal, Cross, and (when measured) FLC peaks *are* the measurement, not a subset you choose (see §4.9). So **All** and **Selected** label the same set — all of them — and only **None** clears the labels. Guitar mode is the only place Selected differs from All (§3.6).

Cycle via the Annotations button, or with the keyboard shortcut ⌘`** on macOS / **Ctrl+` on Windows and Linux.

Annotation mode applies to the current view only — it is not saved with the measurement, and does not affect which peaks contribute to derived values (selection does that, see §3.6).

6.8 Saving the Current View as Default

Once you have zoomed and panned to a view you want as your starting point for every new measurement, save it:

Settings → Advanced → Display Settings → Save Current View

What is saved: the **frequency range** (low and high Hz) and the **magnitude range** (low and high dB) of the current chart. The saved view becomes the target of **Reset to Saved** (§6.2) and of right-click → Reset Axes (§6.3) on subsequent launches.

The default view is a single global setting, not per measurement mode. If you work in plate mode and guitar mode at different ranges, pick the view that suits the work you do most often and zoom from there for the other.

Chapter 7 — Saving, Exporting, and Sharing Measurements

This chapter is a complete reference for everything you can do with a measurement after capture: store it, review it, send it elsewhere, and bring it back later.

7.1 Saving a Measurement

Press **Save** in the toolbar to store the current measurement. Save is enabled whenever there is a finished measurement on screen — a frozen single tap, a complete plate or brace multi-phase capture, or an active comparison overlay — and disabled when the spectrum is live or no peaks have been identified. Hiding peaks with Peak Min (or the None annotation mode) is only a display choice and never disables Save — the full peak set is stored regardless of what is currently shown.

The Save sheet has two fields:

- **Name** *(required)* — a short label identifying what you measured. For a guitar measurement this is typically the luthier's name for the instrument (a serial number, a project name, a working title). For a plate or brace it is the identifier for that specific piece (a board number, supplier code, billet label). Save stays disabled until you enter a name; when you re-save a measurement you loaded, the field starts filled with its existing name.
- **Notes** *(optional)* — free text. Use it to record provenance, build-stage context, dimensions you measured by hand, or anything else you want to carry alongside the data.


What is stored depends on the type of measurement:

- **Guitar / plate / brace** — the spectrum (or 2–3 spectra for a plate measurement, one per phase), detected peaks and selections, settings active at capture time (subtype, plate dimensions, threshold, peak min, and so on), annotation positions, and mode overrides.
- **Comparison** — the constituent spectra (one per measurement that was being compared) and their colours, plus the Comparison Results table. Saving a comparison does not consume the individual measurements that were combined; they remain in the list as separate entries.

Keyboard shortcut: **⌘S** on macOS; **Ctrl+S** on Windows and Linux.

After Save, the measurement appears at the top of the Measurements list (§7.2).

7.2 Viewing Saved Measurements



Open the Measurements list with the toolbar **Measurements** button , or with **⌘L** on macOS / **Ctrl+L** on Windows and Linux.

Each row carries up to three lines plus a trailing column:

- **Line 1** — the **name** (bold; "Measurement" or "Comparison" as a fallback when no name has been set), and on the right a waveform indicator ∼ for guitar measurements that have a captured spectrum, a chart indicator for saved comparisons, the **date and time** of capture, and a chevron.
- **Line 2** — for guitar measurements: peak count, tap-tone ratio (if available), and decay time (if available). For comparisons: "*N* spectra compared". For plate / brace: peak count and the headline material values.
- **Line 3** — the notes you entered on Save, if any.

The list is shown in the order the measurements were saved — newest entries appear at the bottom — not sorted by date or name.

7.3 Loading a Measurement into the View

Either **double-click** the measurement row, or open the popup menu on the row (click the row's **…** button or right-click on desktop, or long-press on iOS / iPadOS) and choose **Load into View**.

What is restored on load:

- The frozen spectrum and its peaks
- Annotation positions
- Mode overrides
- The settings that were active at capture time

Loading a measurement replaces the analyzer's **current** settings — threshold, Peak Min, Taps, measurement type, and so on — with the values that were active when the measurement was captured. Your **saved** Settings values are untouched.

The status bar shows a **"loaded settings"** notice while this is in effect. The notice matters because pressing **New Tap** with the loaded settings active will capture using the loaded measurement's values, not the ones you had configured before. If that is not what you want, change Settings (or load a different measurement whose settings you do want) before tapping.

Loading a saved comparison restores all constituent spectra as the overlay, brings up the Comparison Results table, and switches the view into comparison mode.

7.4 Viewing Measurement Details

Open the popup menu on a measurement row (click the row's **…** button or right-click on desktop, or long-press on iOS / iPadOS) and choose **View Details**, or tap the row directly.

The detail view is read-only. It contains:

- The peak table (mode, frequency, magnitude, Q, bandwidth, pitch for guitar mode; the equivalent fields for plate / brace)
- The analysis summary (decay time and Tap Tone Ratio for guitar; E_L, E_C, specific modulus, quality rating, Gore thickness for plate / brace)
- The name and notes

For a comparison, the detail view shows the list of constituent spectra and the Air / Top / Back frequency table.

Load, Edit Name & Notes, and the export actions are reached from the popup menu on the row in the Measurements list, not from this view.

To dismiss the detail view: click the window's close button on macOS, press **Close** in the Python desktop build, or tap anywhere outside the dialog on iOS / iPadOS.

7.5 Editing Name and Notes

You can change a measurement's name or notes at any time after it has been saved.

Open the popup menu on the measurement row (click the row's **…** button or right-click on desktop, or long-press on iOS / iPadOS) and choose **Edit Name & Notes**. The edit sheet has the same two fields as Save. Tapping Save in the sheet commits the change immediately — there is no separate confirm step and no undo.

7.6 Exporting a Spectrum Image

Produces a PNG of the chart at display resolution. The image reflects whatever the measurement contains: a single tap is exported as one frozen spectrum with annotations, a plate measurement is exported with all of its phase spectra, and a comparison is exported as the overlay with every coloured curve, its label, and the legend.

Two ways to invoke it:

- For a measurement on screen — press the **Export Spectrum** button at the bottom of the Analysis Results window. Keyboard shortcut: **⌘E** on macOS; **Ctrl+E** on Windows and Linux.
- For a saved measurement — open the popup menu on its row in the Measurements list and choose **Export Spectrum**.

7.7 Exporting a PDF Report

Bundles the chart, the data, and the metadata into a single shareable PDF. Like the spectrum image export, this works on any measurement; the PDF contents follow the measurement type:

- **Guitar** — spectrum image, peak frequency table (mode, frequency, magnitude, Q, bandwidth, pitch), and the analysis summary (decay time and Tap Tone Ratio).
- **Plate / brace** — spectrum image(s) for the captured phases, the peak table, and the material properties (E_L, E_C, specific modulus, radiation ratio, quality rating, and Gore thickness for plate).
- **Comparison** — a header listing the constituent measurements, the overlay spectrum image, and the Air / Top / Back frequency table with one column per constituent.

Every PDF carries a metadata header with the date, name, and notes.

Two ways to invoke it:

- For a measurement on screen — press the **Export PDF Report** button at the bottom of the Analysis Results window. Keyboard shortcut: ⇧**⌘E** on macOS; **Ctrl+Shift+E** on Windows and Linux.

- For a saved measurement — open the popup menu on its row in the Measurements list and choose **Export PDF Report**.

7.8 Exporting a Measurement

The native portable container is the `.guitartap` file — a self-contained snapshot of a saved measurement that can be moved to any other device and re-opened without loss.


What it contains: the peaks (with selections and mode overrides), the full spectrum data (Base64-encoded little-endian float32 arrays for frequency and magnitude), annotation positions, and the settings active at capture time. For a measurement that holds more than one spectrum — a plate measurement with its 2 or 3 phase captures, or a comparison with its constituent waveforms — every spectrum is embedded, so the file is larger but stays fully self-contained.

Which popup-menu item to use depends on platform:

- **iOS / iPadOS: Export Measurement** → system share sheet (AirDrop, Mail, Files, etc.).
- **macOS (native build):** either **Export Measurement** (system share sheet) or **Save Measurement to Disk…** (file-save dialog).
- **Python build (Windows / Linux / macOS Python): Export Measurement** → file-save dialog. There is no share sheet on these platforms, so the action behaves the same way as Swift macOS's Save Measurement to Disk…

The file extension is `.guitartap` on every platform, and the format is interchangeable across iOS, iPadOS, macOS, Windows, and Linux builds.

7.9 Importing a Measurement



The access path differs between platforms:

- **iOS / iPadOS:** open the Saved Measurements dialog, tap the ⋯ menu in the upper-right corner, and choose **Import Measurement**. (The same menu also hosts **Delete All**.) The Files picker opens; select a `.guitartap` to import.
- **Desktop (macOS native and Python builds): File → Import Measurement** opens a file picker. Drag-and-drop onto the Saved Measurements window also works.

The imported measurement appears in the list regardless of its type — guitar, plate, brace, or comparison.

If the input device named in the imported file is not available on the current system, the import still succeeds and the imported data is unchanged. A warning is shown **after** the import completes, letting you know that further capture will use a fallback input device until the original is reconnected.

7.10 Exporting or Backing Up the Whole Library

Where §7.8 exports a single measurement, **Export All** writes your **entire** saved-measurement library to one `.guitartap` file. Its purpose is to back up the complete collection or to move it in a single step — from one platform to another (macOS ↔ iPad ↔ Windows / Linux), or, on the web build, from one browser to another.

The action lives in the Saved Measurements list:

- **iOS / iPadOS, web, and Python (Windows / Linux / macOS Python): Export All**.
- **macOS (native build): Export All…** (opens the share sheet — AirDrop, Mail, Files) or **Save All to Disk…** (a file-save dialog that writes the library file to a folder you choose).

The result is a single `.guitartap` file containing every saved measurement — guitar, plate, brace, and comparison. Re-import it on any platform with **Import Measurement** (§7.9); the measurements are merged back into the list. The file is interchangeable across all builds, so Export All on one platform followed by Import on another is the supported way to carry a whole library across.

Web build — why the backup matters. In a browser the library is stored *in that browser*, and the browser can clear it — Safari deletes a site's stored data after roughly seven days without a visit, on both macOS and iOS. Installing the app (**Add to Home Screen** on iOS, **Add to Dock** on desktop) promotes the storage to durable; keeping an **Export All** file elsewhere is the portable backup. The app shows this reminder in the Saved Measurements panel on affected browsers:

Your library is stored in this browser and can be cleared by the browser (Safari deletes it after about 7 days without a visit, on macOS and iOS). Install the app (Add to Home Screen / Add to Dock) for durable storage, and use Export All to keep a backup.

7.11 Sharing Between Devices

Anything you can export — measurements (§7.8), spectrum images (§7.6), or PDF reports (§7.7) — can be shared between devices. Which action to use depends on where the file is going.

Apple ecosystem (iOS, iPadOS, macOS native build). Use the **Export Measurement**, **Export Spectrum**, or **Export PDF Report** popup-menu actions. Each opens the system share sheet, from which:

- **AirDrop** sends directly to a nearby Apple device.
- **iCloud Drive / Files** stores the file to iCloud; the receiver opens it from Files on their device.
- **Mail / Messages** attaches the file; the recipient taps the attachment to open it.

Non-Apple devices and archival. Use **Save Measurement to Disk…** (macOS popup menu) — which is the file-save path, not a share-sheet path — to write a `.guitartap` directly to a folder of your choice. On Python desktop builds (Windows, Linux, and macOS Python) the **Export Measurement** action opens the same kind of save dialog, since no system share sheet exists on Windows or Linux. From disk the file can travel via any cross-platform channel — Dropbox, Google Drive, email, USB drive, network share — and the receiver imports it with §7.9. This same disk-save path is the right choice when you simply want a permanent file copy outside the app's library.

Cross-platform example. Export from a Windows or Linux build with the **Export Measurement** action — which opens a save dialog on those platforms — transfer the resulting `.guitartap` file to an iPhone or iPad (via Files, email, Dropbox, etc.), and import it on the receiving Apple device via §7.9. The `.guitartap` format is identical on every platform, so no conversion is needed regardless of direction.

7.12 Deleting Measurements

- **Desktop:** popup menu → **Delete**.
- **iOS / iPadOS:** swipe-to-delete on the row.

A confirmation prompt appears before deletion so an accidental click or swipe does not lose data. Deleting a measurement removes it and any data embedded in it; nothing else in the list is affected. Because a comparison embeds copies of its constituent spectra at save time, deleting an individual measurement that was previously combined into a comparison leaves that comparison intact, and deleting a comparison leaves its source measurements intact.

Chapter 8 — Settings Reference

The Settings sheet collects every persisted configuration the analyzer uses: audio input, measurement-type-specific inputs (mode frequency windows for guitar, dimensions for plate / brace), and the Advanced display- and analysis-tuning values.

This chapter is the reference for every field. Workflow context for the most-used ones — choosing a measurement type, tuning threshold and peak min, importing a calibration — lives in Chapter 2.

8.1 Opening Settings

- **iOS / iPadOS:** tap the **Settings** ⚙ icon in the main toolbar.
- **macOS (native build): Guitar Tap → Settings…** in the application menu, or **⌘,**.
- **Python desktop (macOS Python): Guitar Tap → Settings…** in the application menu, or **⌘,**, or the **Settings** button in the toolbar.
- **Python desktop (Windows / Linux): File → Settings…**, or **Ctrl+,**, or the **Settings** button in the toolbar.

Changes apply immediately (no Apply step) and persist across launches.

8.2 Audio Input & Calibration

- **Input device** — picker listing the microphones available on the current system. Selecting a device makes it the active input.
- **Calibration** — shows the calibration file currently associated with the active input device, or "None".
- **Import Calibration File** — opens a file picker; accepts `.txt` and `.cal` two-column (frequency, dB) files. The selected file is bound to the currently active device and reloads automatically when you next select that device.
- **Clear All Calibrations** — removes every stored calibration across all devices. Use when you want a clean baseline.

See §2.3 and §2.4 for the workflow.

Capture sample rate

GuitarTap captures at whatever sample rate the operating system provides for the selected input device — it does not override it. The rate is set outside the app:

- **macOS:** *Audio MIDI Setup* (in `/Applications/Utilities`). Select the input device and choose a Format rate. Because the app's audio context follows the default **output** device, set both the input and the output device to the same rate (e.g. 48 000 Hz) to avoid resampling.
- **Windows:** *Sound settings* → *Device properties* → *Advanced* (Default Format). **Linux:** your audio server's configuration (e.g. PipeWire/JACK).

Why it matters: the analysis frequency resolution and the captured spectrum are tied to the rate, so the same instrument measured at a different rate will read slightly differently. The rate in effect is **recorded with each measurement** (see Appendix B) so that loading a measurement can warn you if your current setup differs — see §10.7.

8.3 Measurement Type

The Measurement Type section adapts to the type you select.

Guitar subtype — pick one of:

- **Generic Guitar** — broad frequency windows; recommended default.
- **Acoustic Guitar** — narrower windows tuned for steel-string flat-tops.
- **Classical Guitar** — windows for classical builds.
- **Flamenco Guitar** — windows for flamenco builds.

Below the subtype picker, **Mode Frequency Ranges** displays the windows the analyzer uses to classify air, top, back, dipole, ring, and upper modes for the chosen subtype. The display is read-only — the windows are a property of the subtype, not a user-tunable value.

Plate — the section reveals the plate inputs (described in detail in §4.3):

- **Length** (mm) — along the grain.
- **Width** (mm) — across the grain.
- **Thickness** (mm).
- **Mass** (g).
- **Calculated Density** — live preview computed from the four values above; sanity-check against the expected range for the wood (spruce: 0.35–0.45 g/cm³).
- **Body Length** (mm) and **Lower Bout Width** (mm) — used by the Gore target thickness calculation.
- **Plate Stiffness Preset** — Steel String Top (75), Steel String Back (55), Classical (50), or Custom. See §4.3 for the Custom calibration workflow.

- **Measure FLC** — when on, the sequence runs in three phases (L, C, FLC) instead of two (L, C).

Brace — the section reveals the brace inputs (described in detail in §5.2):


- **Length (along grain)** (mm).
- **Width (breadth)** (mm).
- **Height (tap direction)** (mm) — the `t` dimension in the stiffness formula. The Settings panel includes a helper line below the field to flag this.
- **Mass** (g).
- **Calculated Density** — same live preview as the plate section.

8.4 Advanced — Display Settings

Tap **Advanced** to reveal these.

- **Frequency Range** — min and max Hz shown on the spectrum chart. Defaults are wide enough to cover guitar / plate / brace ranges; narrow them when you want a closer look at a specific band.
- **Magnitude Range** — min and max dB shown on the chart.
- **Save Current View** — saves the *current* chart axes (frequency and magnitude ranges) as your default. Reset to Saved in the chart's **…** menu (§6.2) returns to this view.
- **Reset to Defaults** — restores the built-in starting ranges.

8.5 Advanced — Analysis Settings



- **Show Unknown Modes** (guitar only) — when on, peaks that do not fall within any classified mode window are still annotated on the chart. On by default; turn off to declutter a chart intended for sharing. (Cross-ref §3.1.)
- **Peak Detection Minimum** (guitar only) — the same Peak Min value as the toolbar slider (§2.7); the Settings field accepts a precise numeric value. Sets the minimum magnitude (dB) a

peak must reach to be *shown* — annotated on the chart and listed in the results. It is a display filter only: it does not re-detect peaks, or change which are selected or classified. A saved guitar measurement retains its full peak set, so Peak Min can be lowered later on a loaded measurement to reveal quieter peaks (§2.7). Typical range: –60 to –40 dB. Disabled in plate / brace mode (the per-phase capture uses its own adaptive noise floor).

- **Dump Capture Audio** — when on, each measurement's captured audio is saved as one continuous mono 32-bit-float WAV file. Useful as an archive of a measurement, or for debugging; leave off if you don't need it.

When enabled, a **folder row** appears beneath the setting showing where the files are saved, with buttons to work with that folder: - **macOS:** *Show in Finder* opens the folder; *Change…* lets you pick any folder (the app remembers your choice across launches); *Use Default* returns to the app's own storage. The default is inside the app's container; use *Change…* to send dumps to, for example, `~/Documents/GuitarTap`. - **Desktop (Python build — macOS / Windows / Linux):** the same *Open Folder* / *Change…* / *Use Default* controls. The default is your **Documents** folder + `GuitarTap` (your real Documents location, including a redirected or OneDrive Documents). - **iPhone / iPad:** the app's Documents directory (not settable), reachable via **Files** → **On My iPhone/iPad** → **Guitar Tap**. - **Browser (web build):** files download to your browser's **Downloads** folder (not settable — the browser controls where downloads go).

The folder is expected to stay where you put it: if you **rename, move, delete, or trash** it (or it's on a drive that isn't mounted), Guitar Tap can no longer reach it. When that happens — on **New Tap**, and also at launch, since Guitar Tap arms for a tap automatically when it opens — it asks you to **Change Location**, **Turn Off Saving**, or **Cancel** before the measurement starts, so a recording is never lost to a missing folder. **Cancel** leaves the detector idle; press **New Tap** again when you're ready.

File names are timestamped and prefixed by the originating build — `swift_<label>_<timestamp>.wav`, `python_<label>_<timestamp>.wav`, or `web_<label>_<timestamp>.wav` — so dumps from cross-platform comparison runs are easy to tell apart. - **Reset Analysis Settings** — restores the analysis defaults.

8.6 About & Help


The final section of the Settings sheet carries three items:

- **Version** — the running build's version string.
- **Copyright** — the copyright line from the app's bundle metadata.
- **Quick Start Guide** ⓘ — opens the in-app Quick-Start Guide. The content matches the printable Quick-Start PDF that ships with the app.
- **User Manual** — opens the full User Manual (this document) in the system default browser. Requires an internet connection; the manual is hosted at dolcesfogato.com.

Chapter 9 — Controls Reference

A scannable reference for every button, control, and gesture. For the workflows that exercise them, see Chapters 3–7. For the chart-interaction details, see Chapter 6.

9.1 Toolbar — iOS iPhone (Portrait)



Vertical layout with three stacked control rows above the chart.

Top — navigation toolbar:

- **Leading (left):** Results, Play File, Auto dB.
- **Trailing (right):** Metrics, Settings.


Middle — secondary icon row (just below the toolbar):

- Crosshair, Annotations, Save, Measurements.

Bottom — Tap Controls panel (§9.6):

Taps stepper, Threshold slider, Peak Min slider, and the action buttons New Tap / Pause-Resume-Accept / Cancel-Redo.

9.2 Toolbar — iOS iPhone (Landscape)



Horizontal split layout with the **Tap Controls** in a vertical panel on the left and the spectrum chart filling the right side. The navigation toolbar runs across the top of the screen.

- **Leading:** Results, Play File, Auto dB, Crosshair, Annotations.
- **Trailing:** Save, Measurements, Metrics, Settings, Help.

The Tap Controls panel scrolls vertically when there is not enough height to show every control at once.

9.3 Toolbar — iOS iPad



iPad uses a single layout in both portrait and landscape (the horizontal size class is `.regular` in either orientation, so the same inline three-pane arrangement applies). The Analysis Results panel is shown inline alongside the chart — like the desktop layout — so the toolbar does **not** include a Results button.

- **Leading:** Play File, Auto dB, Crosshair, Annotations.
- **Trailing:** Save, Measurements, Metrics, Settings, Help.

The full Tap Controls panel is visible above the chart in both orientations.

9.4 Menu Bar — Desktop



Both the Swift native macOS build and the Python desktop build (Windows, Linux, macOS Python) expose the same operations through a menu bar. The placement and shortcuts differ per platform following the host OS conventions.

Application menu (macOS — both native and Python; on Windows and Linux these items move into the File and Help menus per the notes below):

Item	macOS shortcut
About Guitar Tap	(system default)
Settings…	⌘,
Quit Guitar Tap	⌘Q

File menu:

Item	macOS shortcut	Windows / Linux shortcut
Close (macOS only)	⌘W	—
Play Audio File…	⌘⌥O	Ctrl+Alt+O
Save Measurement…	⌘S	Ctrl+S
Export Spectrum Image…	⌘E	Ctrl+E
Export PDF Report…	⇧⌘E	Ctrl+Shift+E
Settings… (Win / Linux Python only)	—	Ctrl+,
Exit / Quit (Win / Linux Python only)	—	(system default)

View menu:

Item	macOS shortcut	Windows / Linux shortcut
Auto dB	⌘0	Ctrl+0
Cycle Annotations	⌘`	Ctrl+`
Show Metrics	⌘M	Ctrl+M
Show Measurements	⌘L	Ctrl+L

Help menu:

Item	macOS shortcut	Windows / Linux shortcut
Quick Start Guide	⌘?	F1
User Manual	—	—
About Guitar Tap… (Win / Linux Python only)	—	(no default)

9.5 Individual Controls

Each entry: icon, name, what it does, and any platform notes. Keyboard shortcuts are given in macOS form first followed by Windows / Linux where they differ.

New Tap — Arms the tap detector, clears the frozen spectrum, and returns to the live view. Also exits comparison mode when a comparison is active. Enabled except while a measurement is actively being captured (and when detection is unavailable).

Play File — Opens a file picker; the selected audio file is fed through the analysis pipeline as if it were live microphone input. Useful for analyzing captured WAVs or running the analyzer against a reference recording. The icon tints orange while a file is playing. Also reached from the desktop menu bar (**File** → **Play Audio File…**, **⌘⌥O** macOS / **Ctrl+Alt+O** Windows / Linux).

Pause / **Resume** / **Accept** — A single button whose label and icon change with state. **Pause** suspends tap detection while keeping the spectrum live — use it to tune Threshold and Peak Min freely (§2.6, §2.7). **Resume** re-arms detection. **Accept** (green) replaces the pair during plate / brace review phases (§4.5) and locks in the current phase result before advancing.

Cancel / **Redo** — A single button whose label and icon change with state. **Cancel** discards the active sequence and returns to the live view. During a plate / brace review phase it becomes **Redo L**, **Redo C**, or **Redo FLC** (orange) and re-arms detection for that phase only (§4.5).

Results (iPhone only) — Opens the Analysis Results sheet.

Re-analyze — In the Analysis Results header, next to the microphone name. Re-runs peak detection on the frozen spectrum of any completed guitar measurement — live or loaded — re-classifies the modes from scratch, and returns peak selection to automatic. Custom mode names you have assigned are kept, though the peak carrying one may end up deselected. Useful for trying a different guitar type without re-tapping, or for a clean classification after manual changes. It does not disable itself after one press, and does not apply to plate / brace measurements.

Auto dB — Scales the magnitude axis to fit the current signal (§6.4). Shortcut: **⌘0** / **Ctrl+0**.

Annotations / / — Cycles through the annotation display modes: **All** → **Selected** → **None** → **All …** (§6.7). The icon shows which state is currently active. Shortcut: **⌘`** / **Ctrl+`**.

Save — Opens the Save Measurement sheet (§7.1). Enabled whenever there is a finished measurement on screen — single tap, plate / brace multi-phase capture, or active comparison overlay. Shortcut: **⌘S** / **Ctrl+S**.

Measurements — Opens or closes the Measurements list (§7.2). Shortcut: **⌘L** / **Ctrl+L**.

Metrics — Opens or closes the FFT Diagnostics panel (frame rate, FFT size, input level, and so on). Shortcut: **⌘M** / **Ctrl+M**.

Crosshair / (iOS / iPadOS only) — Toggles the touch-readout crosshair (§6.5). On desktop there is no toggle; the crosshair follows the mouse pointer whenever the pointer is over the chart, showing the frequency and magnitude under the cursor in real time.

Chart Options ⋯ (iOS / iPadOS only) — Opens the **Chart Options** sheet from the upper-right corner of the spectrum chart. Hosts the Reset to Saved and Reset to Defaults groups, plus Reset Labels when there are dragged labels to reset (§6.2, §6.6). On desktop the same actions are reached by right-clicking the chart.

Zoom & Pan Help ⓘ (desktop only) — Shows a summary popover of the scroll, modifier-key, and trackpad gestures for axis zoom and pan (§6.3).

Settings ⚙ — Opens the Settings sheet (Chapter 8). Shortcut: **⌘,** / **Ctrl+,**.

Help ? — Opens a small menu with two items: **Quick Start Guide** (the in-app help content; also reachable directly via **⌘?** on macOS or **F1** on Windows / Linux) and **User Manual** (opens the published manual in the system browser). On iOS and iPadOS the menu lives behind the toolbar **?** button; on desktop the same two items appear in the **Help** menu bar.

9.6 Tap Controls

The Tap Controls panel groups the per-measurement settings and action buttons. Its placement varies by platform — see §9.1 (iPhone portrait), §9.2 (iPhone landscape), §9.3 (iPad), and §9.4 (desktop) for where it sits on each layout. The contents themselves are the same everywhere:

- **Taps stepper (1 – 10)** — number of taps to capture in each guitar-mode sequence, or per phase in plate / brace mode (e.g. 3 means three taps for Longitudinal, three for Cross-grain, and three for FLC if enabled). Disabled while a sequence is in progress and during comparison mode.
- **Threshold slider** — signal level (dB) that triggers tap detection (§2.6). The current value is shown next to the slider; the **reset arrow** restores the factory default. Range: –80 dB to –20 dB. Disabled during comparison mode.
- **Peak Min slider** — minimum spectrum magnitude (dB) at which a peak is *shown* — annotated on the chart and listed in the results (§2.7, §8.5). A display filter only: it never re-detects peaks or changes which are selected or classified. The current value is shown next to the slider; the **reset arrow** restores the factory default. Range: –100 dB to –20 dB. In plate / brace mode the slider affects only what is drawn on the chart — the selected peak for each phase comes from the capture algorithm and is not changed by Peak Min. Disabled during comparison mode and during plate / brace measurements.

9.7 Status Bar

A thin status bar runs below the spectrum chart on every platform and orientation. It is a read-only feedback area that reflects the current state of the analyzer; the contents change with state.

Normal tap-detection (default). Left to right:

- A circle indicator — green when a tap has been captured (label: **Tap Detected!**), grey while waiting (**Waiting for tap…**).
- The current input level in dB.
- During a multi-tap guitar sequence or a plate / brace sequence: a counter such as **Tap 2/3** or **Phase 1/2 · Tap 1/3**, plus a thin progress bar.
- **Peak: *X.X* dB @ *Y.Y* Hz** — the loudest spectrum bin in the current view, shown on the right side.
- A pause-fill glyph when the spectrum has frozen on a completed measurement.
- A small circle indicating audio-engine state — green for running, red for stopped.

Loaded-settings warning. After a saved measurement is loaded (see §7.3) the bar shows an orange triangle and the message **Loaded settings — Threshold: *X dB · Taps: N***. The notice remains visible until you change Settings or start a fresh capture.

Comparison mode. A waveform glyph and a one-line description of the comparison — **Comparing *N* measurements** for a saved comparison, or **Tap comparison — *N* taps + averaged** for the multi-tap comparison view — plus a hint about how to exit the mode (press **Taps** or **New Tap**).

The iPhone layout uses a single-line condensed version of this bar; the iPad and desktop layouts use a slightly taller version that stacks the warning above the tap-state row when both apply at once.

9.8 Spectrum Chart Interactions

See Chapter 6 for a complete reference covering live and frozen state, zoom / pan gestures and shortcuts, the **?** popover, the crosshair, peak-label dragging and reset, and the Annotation modes cycle.

Chapter 10 — Tips, Technique, and Troubleshooting

Practical advice for tighter results, plus a table of common problems and their fixes.

10.1 Tap Technique

The cleanest impulse comes from a **small bouncy ball on the end of a stick**. Short contact time, clean impulse, low operator variability, and reproducible day to day. Works for all three modes (guitar, plate, brace).

A **firm knuckle or fingertip rap** is the day-to-day alternative for guitar-body surveys and works well there. It is less ideal for plate and brace measurements because contact time varies more.

Contact time matters. A long slow push excites fewer overtones and muddies the spectrum; the shorter the contact, the better the high-frequency content. If the spectrum looks smeared-out around the peaks you care about, suspect contact time before suspecting the mic or the room.

Tap location:

- **Guitar body** — on the bridge centered, on each wing of the bridge, below the bridge centered, on each side. The decision comes from experience and which node excitation is desired.
- **Plate or brace** — centre of the face. Off-centre taps bias the result; the centre is at the antinode of every mode the measurement is designed to capture.

Force. The tap does not have to be loud — it just has to clear Threshold (§2.6). An unnecessarily hard tap is more likely to trigger double-detection or saturate the input than a deliberate, medium tap.

10.2 Consistent Microphone Position

The wood's resonant *frequencies* are fixed; only the *magnitude* the microphone sees depends on where the mic is sitting. Position therefore matters for any comparison you make over time — across build stages, across thinning passes, across instruments.

Mark the position with a piece of tape or a chalk line on the bench. When you come back tomorrow, set up against the same mark.

Distance: 5–15 cm is a useful range. Closer than 5 cm risks off-axis rejection from a directional mic; further than ~20 cm gives away signal-to-noise without much benefit.

10.3 Dealing with Background Noise

The Threshold slider is the first line of defence. Move it **higher** (closer to 0 dB) to reject ambient noise; **lower** (more negative) to catch quieter taps. The goal is to put Threshold comfortably above the noise floor and comfortably below your tap peak.

The detector also applies a **3 dB hysteresis margin**: after a tap fires, the signal must drop 3 dB below Threshold before the detector re-arms. This prevents the ring-out tail from re-triggering as a second tap. The 3 dB value is fixed and is appropriate for typical rooms.

Practical target. Keep your noise floor at least 10 dB below Threshold; if it is closer, false triggers become likely.

Plate and brace track the noise floor for you. In Plate and Brace modes Threshold is not used as a fixed level. The analyzer measures the room's noise floor continuously and fires only on signals rising at least 10 dB above it, with Threshold acting as the upper bound. Material taps are quiet, and this is what keeps them detectable in a room whose noise floor drifts — where a fixed level would either sit under the noise (triggering constantly) or over the tap (detecting nothing). Guitar mode is unchanged: Threshold is an absolute level.

The floor is measured from the audio in the half-second **before** detection begins, which is why the analyzer ignores taps struck the instant you press New Tap: it is listening to the room first. Give it that moment.

Pausing to measure the noise floor. Press **Pause** (§2.6), leave the analyzer running, and watch the live spectrum for a few seconds. Sustained noise peaks tell you where the noise floor sits; pick Threshold a comfortable margin above them.

Worst offenders. HVAC fans, refrigerator compressors, traffic, and computer fans. Plate and brace measurements that need to compare cleanly across days are worth either silencing or moving away from these sources.

Plate/brace audio files need half a second before the first tap. Because the plate and brace detectors measure the room from the audio ahead of the first tap (above), a file played back in those modes must actually contain that audio — at least half a second of room tone before the first strike. Recordings made by Guitar Tap always do, so replaying a session you captured here always works. A file recorded elsewhere may not: if its first tap falls inside that opening half-second, the tap is treated as part of the settling period, is not detected, and nothing is captured. Re-record with a moment of silence in front of the first tap. Guitar files are unaffected — guitar detection uses the absolute Threshold and needs no lead-in.

10.4 Decoupling the Top from the Air Mode

A normal tap of the guitar body excites the air (Helmholtz) mode and the top mode together, and the two are coupled — the displayed top frequency is pulled away from the wood's true value by the coupling.

To read the top resonance without that bias, block the air cavity before tapping: **stuff a rag, foam, or other soft fill into the sound hole** so air cannot pump in and out. With the cavity blocked the Helmholtz resonance disappears from the spectrum, and the top peak shifts to the position it would have without air coupling.

Tap, capture, and read the top frequency. Remove the fill before returning to normal use.

10.5 Ring-Out and Decay Time

Ring-out (decay time) is the time, in seconds, for the tap's amplitude envelope to fall to 1/e (~37%) of its peak. It is a direct read on structural damping.

- **Higher decay time** → lower damping → more sustain.
- **Lower decay time** → more damping → energy is being absorbed faster.

Typical soundboard ranges:

- **> 1.5 s** — excellent.
- **1.0–1.5 s** — good.
- **< 0.8 s** — worth investigating; may indicate over-drying or excessive internal friction.

Before-and-after. A top plate before bracing typically has a higher decay time than after bracing. Measuring at each stage quantifies how much the bracing is damping the resonance — a useful data point for tracking your own bracing pattern's behaviour over multiple builds.

Decay time is computed from the tap capture. In a multi-tap sequence the averaged-capture decay is reported.

10.6 Multi-Tap Averaging Strategy

The right tap count depends on what you are measuring:

- **Guitar body survey** — 1–3 taps. The body resonances are stable; averaging mainly reduces the impact of an occasional noisy or missed tap.
- **Plate or brace material measurement** — 3–5 taps. Averaging reduces variance from finger noise and small position differences, which matters for the absolute E_L value.

- **FLC tap (plate mode)** — 1–3 taps. The FLC resonance is weaker, so position consistency matters more than averaging. Tapping the FLC repeatedly with imperfect positioning can *increase* variance rather than reduce it.

When averaging helps least. Very quiet room, experienced tapper, firm bouncy-ball implement: single-tap is usually sufficient.

Sanity check. For a new piece of stock or a new technique, take a single tap and a 5-tap average of the same blank and compare the frequencies. If they agree to within 1 Hz you can trust single-tap measurements for that piece going forward.

Pause within a sequence. Press Pause after any captured tap to reposition your hand or settle the room; Resume re-arms the detector for the next tap.

10.7 Common Problems

Problem	Likely cause	Fix
No tap detected	Threshold too high	Lower the Threshold slider (§2.6).
Plate / brace: playing an audio file recorded elsewhere detects nothing	The file has less than half a second of room tone before the first tap, so the tap falls inside the noise-floor settling period	Re-record with a moment of silence before the first tap (§10.3). Files recorded by Guitar Tap always contain it.
False detections	Threshold too low, or noisy room	Raise Threshold; verify the noise floor with Pause (§10.3).
Peaks missing on the chart	Peak Min too high	Lower the Peak Min slider (§2.7).
Unknown peaks everywhere	Modes fall outside the standard windows, or Show Unknown Modes is on	Pick the guitar type whose windows fit your instrument (§3.1); turn off **Show Unknown Modes** (§8.5) to hide the rest, or assign modes manually (§3.7).
Spectrum doesn't update	Microphone permission not granted	iOS / iPadOS: Settings → Guitar Tap → Microphone. macOS: System Settings → Privacy & Security → Microphone. Windows: Settings → Privacy & Security → Microphone. Linux: check `pavucontrol` (§2.2).
Plate calculation missing	Dimensions not entered	Settings → Measurement Type → Plate; fill in Length / Width / Thickness / Mass (§4.3, §8.3).
Gore thickness shows "G_LC assumed 0"	FLC tap not captured	Enable **Measure FLC** in Settings and re-run the plate sequence (§4.8).
Analysis Results panel not visible (desktop)	Window too narrow	Widen the window.
Plate / brace stuck waiting for next phase	Accept not pressed	Look for **Accept** (green checkmark) in the tap controls — it replaces

Problem	Likely cause	Fix
		Pause during the review phase (§4.5).
Plate / brace: need to redo a phase already accepted	Phase locked in	Press **New Tap** to restart the whole sequence. Per-phase redo is only available before that phase is accepted.
Compare button does not appear	Fewer than 2, more than 5, or a plate / brace measurement is in the selection	Select 2–5 guitar measurements only (§3.9).
Threshold / Taps differ from your Settings after loading a measurement	Loaded measurement's settings are active	The status bar shows a **Loaded settings** notice (§7.3 and §9.7). Change Settings, or press **New Tap** to start fresh with your own values.
Imported file: input device warning after import	Mic named in the file isn't on this system	The import succeeded; a fallback device is in use. Reconnect the original mic, or pick a current one in Settings → Audio Input (§7.9).
Loaded measurement: warning about a different calibration and/or sample rate	The recorded microphone matches, but the active calibration or the OS sample rate differs from when the measurement was made	Informational only — the saved data is unaffected. A **newly captured** tap will not match the saved one until they agree. Match the sample rate in your OS audio settings (§8.2) and reselect the calibration in Settings → Audio Input.
A fresh tap of the same instrument doesn't match a saved measurement	Microphone, calibration, or sample rate changed since the measurement was saved	These determine the captured spectrum. Reproduce the original microphone, calibration, and sample rate (§8.2); the load-time warning tells you which one differs.

Chapter 11 — Glossary

Air (Helmholtz) mode — The resonance of the air cavity inside the instrument body, excited by the motion of air through the sound hole. Also called the Helmholtz resonance.

Bandwidth (–3 dB) — The width of a spectral peak measured at 3 dB below its maximum. Narrower bandwidth (higher Q) indicates lower damping.

Cross/Long ratio — The ratio of cross-grain Young's modulus to longitudinal Young's modulus (E_C / E_L). For spruce, typically 0.04–0.08.

Decay time — The time (in seconds) for a tap response to decay to 1/e of its peak amplitude. A measure of structural damping; higher values indicate lower damping.

Dipole mode — A bending mode of the guitar top plate where the upper and lower bouts move in opposite phase.

E_C (Young's modulus, cross-grain) — Stiffness of the wood measured perpendicular to the grain direction (radial or tangential). Expressed in GPa.

E_L (Young's modulus, longitudinal) — Stiffness of the wood measured along the grain direction. Expressed in GPa. The primary stiffness parameter for tonewood selection.

FFT (Fast Fourier Transform) — The algorithm used to convert the time-domain microphone signal into the frequency-domain spectrum displayed by the app.

FLC tap — A third tap measurement (Free-Length-Cross) used in Plate mode to estimate the shear modulus G_LC, which feeds the Gore target thickness calculation. Optional — when omitted the Gore thickness is reported with the message "G_LC assumed 0" and carries an over-estimate of roughly 5–7% (§4.8).

Free-free beam — A beam suspended at its bending-mode nodal points (22% from each end), leaving it free to vibrate without damping at the supports. The standard suspension assumption for Plate and Brace material measurements. In practice a single hold at one of the two nodal points is sufficient — see §4.4.

Free-Length-Cross (FLC) mode — The torsional mode excited by the FLC tap; its frequency feeds the shear-modulus calculation. See FLC tap.

G_LC (shear modulus) — The shear modulus of the plate, derived from the FLC tap frequency. Required by the full Gore target thickness formula; substituted with zero when FLC is not measured.

Gore target thickness — The recommended final thickness for a guitar top or back plate, calculated from the plate dimensions, Young's moduli, and a stiffness target, following the method described by Trevor Gore.

Q factor — Quality factor; the ratio of a resonant peak's centre frequency to its –3 dB bandwidth. $Q = f_0 / \Delta f$. Higher Q indicates lower damping.

Radiation ratio (R) — A figure of merit for tonewood; $R = c_L / \sqrt{\rho} = \sqrt{(E_L/\rho^3)}$. Higher values indicate a lighter, stiffer wood that radiates sound more efficiently.

Ring mode — A symmetric bending mode of the guitar top plate involving the rim of the lower bout.

Specific modulus (E/ρ) — Young's modulus divided by density. Also written as c^2 (where c is the speed of sound in the material). A key predictor of tap tone quality.

Speed of sound (c) — The speed at which a longitudinal stress wave travels through the wood: $c_L = \sqrt{(E_L / \rho)}$. Expressed in m/s.

Tap Tone Ratio — The ratio of the top mode frequency to the air mode frequency (f_{top} / f_{air}). Typical range for a well-voiced guitar: 1.8–2.4.

Top / Back mode — The fundamental bending mode of the guitar top plate or back plate, respectively; often the strongest peak in a guitar tap spectrum.

Unknown mode — A detected spectral peak that does not fall within any defined frequency window for the selected guitar subtype. Shown on the chart by default; can be hidden with **Settings → Advanced → Analysis Settings → Show Unknown Modes** (§3.1, §8.5). An Unknown peak can be re-identified by tapping its row in the Analysis Results panel and assigning a standard mode (Air, Top, Back, Dipole, Ring, Upper Modes) or a custom label (§3.7).

Upper modes — Resonant modes above the main top and back modes; their significance increases with frequency and build stage.

Appendix A — Keyboard Shortcuts

Desktop keyboard shortcuts for every action with one assigned in Guitar Tap, grouped by the menu where the action appears. The same shortcuts are listed in §9.4 alongside the menu items themselves; this appendix is the lookup table.

The Swift native macOS build and the Python desktop build (Windows, Linux, macOS Python) follow the host OS conventions — ⌘ shortcuts on macOS, Ctrl shortcuts on Windows and Linux.

Application menu

Action	macOS	Windows / Linux
Settings	⌘,	Ctrl+,
Quit	⌘Q	(system default)

File menu

Action	macOS	Windows / Linux
Close	⌘W	—
Play Audio File	⌘⌥O	Ctrl+Alt+O
Save Measurement	⌘S	Ctrl+S
Export Spectrum Image	⌘E	Ctrl+E
Export PDF Report	⇧⌘E	Ctrl+Shift+E

View menu

Action	macOS	Windows / Linux
Auto dB	⌘0	Ctrl+0
Cycle Annotations	⌘`	Ctrl+`
Show Metrics	⌘M	Ctrl+M
Show Measurements	⌘L	Ctrl+L

Help menu

Action	macOS	Windows / Linux
Quick Start Guide	⌘?	F1

iOS and iPadOS do not expose menu items or keyboard shortcuts in Guitar Tap; everything on those platforms is reached through the toolbar (Chapter 9) or the popup menu in the Measurements list (§7.2).

Appendix B — File Formats

Measurement files (`.guitartap`)

The native portable measurement container. UTF-8 JSON, self-contained, and identical across every platform Guitar Tap runs on (iOS, iPadOS, macOS native, and the Python build on Windows / Linux / macOS Python). A file written on any platform opens on any other without conversion. The export and import workflows are documented in §7.8 and §7.9.

The remainder of this section is a structural reference for anyone parsing or generating `.guitartap` files outside the app.

File-level structure

The file is pretty-printed JSON. The top-level value is an **array** containing exactly one measurement object — the array wrapping is part of the format and parsers must accept it even when only one measurement is present.

```
[
  {
    "id": "…",
    "timestamp": "…",
    ...
  }
]
```

Dates are ISO-8601 strings (`YYYY-MM-DDTHH:MM:SSZ`). UUIDs are RFC 4122 strings.

Number precision. Most numeric fields are single-precision (`float32`): they are written as the shortest decimal that round-trips to the stored value, and integral values carry no decimal point (`-100`, not `-100.0`). Treat them as accurate to about 7 significant digits, no more. A few fields are full double-precision and are written at full precision — `pitchCents`, `pitchFrequency`, `sampleRate`, the four `colorComponents`, and the `absFreqHz` / `absDB` annotation offsets. Per-spectrum arrays do not use JSON numbers at all; they use the compact binary encoding described below.

Key order and whitespace are not significant. Current writers sort object keys alphabetically and indent two spaces, but a parser must not depend on either — always read by key name.

Optional fields are omitted, never `null`. A field that is not set is left out of the object entirely. Treat a missing field and an explicit `null` the same way on read.

Measurement object

Required fields:

Field	Type	Notes
`id`	UUID	Stable identifier.
`timestamp`	ISO-8601	When the measurement was saved.
`peaks`	array of Peak	All detected peaks (empty for a saved comparison).

Optional fields — populated depending on measurement type and on what the user did at save time:

Field	Type	Notes
`measurementName`	string	User-entered name (§7.1).
`notes`	string	User notes.
`decayTime`	float	Seconds; guitar only.
`spectrumSnapshot`	SpectrumSnapshot	Averaged guitar spectrum.
`longitudinalSnapshot`, `crossSnapshot`, `flcSnapshot`	SpectrumSnapshot	Plate / brace per-phase spectra.
`selectedLongitudinalPeakID`, `selectedCrossPeakID`, `selectedFlcPeakID`	UUID	The peak chosen as L / C / FLC.
`selectedPeakIDs`	array of UUID	Currently-selected peaks (guitar).
`selectedPeakFrequencies`	array of float	Frequencies (Hz) parallel to the IDs; a stable fallback for re-matching selection to peaks when a re-analysis regenerates UUIDs. (Peak Min itself never re-detects or regenerates peaks.)
`userModifiedSelection`	bool	Guitar only. `true` once the user has changed peak selection away from the automatic default, so a loaded measurement keeps that selection instead of re-deriving it. Omitted on material measurements and on files saved before 1.0.2; a missing value is read as `true`.
`peakAnnotationOffsets`	array	UUID-keyed map of custom label positions, encoded as a flat array (see "UUID-keyed maps"). Each value is

Field	Type	Notes
		`{ "absFreqHz": <freq Hz>, "absDB": <magnitude dB> }`.
`annotationVisibilityMode`	string	Enum: `all` / `selected` / `none`.
`tapDetectionThreshold`	float	Threshold (dB) at save time.
`numberOfTaps`	int	Taps stepper value at save time.
`peakMinThreshold`	float	Peak Min (dB) at save time.
`peakModeOverrides`	array	UUID-keyed map of per-peak mode overrides, encoded as a flat array (see "UUID-keyed maps"). Each value is `{ "type": "assigned", "label": <mode> }`.
`microphoneName`, `microphoneUID`	string	Input device provenance.
`calibrationName`	string	Active calibration profile, if any.
`sampleRate`	float	Capture sample rate (Hz) in effect when recorded. Omitted in files saved before this field existed; absence is treated as "unknown" (no warning).
`comparisonEntries`	array of ComparisonEntry	Present **only** for saved comparisons.
`tapEntries`	array of TapEntry	Per-tap data for multi-tap guitar.
`measurementType`, `guitarType`	string	Convenience copies for external consumers; mirror `spectrumSnapshot` fields.

UUID-keyed maps

`peakAnnotationOffsets` and `peakModeOverrides` are logically maps from a peak UUID to a value. Because a UUID is not a JSON string key, both are encoded as a **flat array** of alternating key/value elements — the array form produced by the platform's JSON encoder. A parser must read element 0 as a UUID string, element 1 as its value, element 2 as the next UUID, and so on:

```
"peakModeOverrides": [
  "5E2A8C7D-…",
  { "type": "assigned", "label": "Top" },
  "9F31B0A4-…",
  { "type": "auto" }
]
```

A mode value is `{ "type": "auto" }` or `{ "type": "assigned", "label": "<string>" }`; a peak with no entry (or a `"type": "auto"` entry) uses automatic classification. `peakAnnotationOffsets` uses the same alternating layout with values of `{ "absFreqHz": <Hz>, "absDB": <dB> }`.

Compatibility note. Some files written by early Guitar Tap Python 1.0.x builds encode `peakModeOverrides` as a JSON *object* (`{ "<uuid>": { "type": …, "label": … } }`) instead of the flat array. Robust parsers should accept both shapes; current builds always write the flat array.

SpectrumSnapshot

Required fields:

Field	Type	Notes
`frequenciesData`	Base64 string	See "Spectrum data encoding" below.
`magnitudesData`	Base64 string	Same length as `frequenciesData`.
`minFreq`, `maxFreq`	float	Chart frequency range (Hz).
`minDB`, `maxDB`	float	Chart magnitude range (dB).
`isLogarithmic`	bool	Axis scale.

Optional measurement-type fields:

Field	Type	Notes
`showUnknownModes`	bool	Mirrors the Settings toggle.
`guitarType`	string	One of `Generic`, `Acoustic`, `Classical`, `Flamenco`.
`measurementType`	string	One of `Generic Guitar`, `Acoustic Guitar`, `Classical Guitar`, `Flamenco Guitar`, `Material (Plate)`, `Material (Brace)`.
`plateLength`, `plateWidth`, `plateThickness`, `plateMass`	float	Plate dimensions in mm / g.
`guitarBodyLength`, `guitarBodyWidth`	float	Body inputs for Gore thickness (mm).
`plateStiffnessPreset`	string	One of `Steel String Top`, `Steel String Back`, `Classical Top`, `Classical Back`, `Custom`.
`customPlateStiffness`	float	Value when `plateStiffnessPreset` is `Custom`.
`measureFlc`	bool	Whether the FLC phase was captured.
`braceLength`, `braceWidth`, `braceThickness`, `braceMass`	float	Brace dimensions in mm / g.

Spectrum data encoding

`frequenciesData` and `magnitudesData` are Base64-encoded byte strings. After Base64 decoding the bytes are a contiguous little-endian IEEE-754 single-precision (`float32`) array — 4 bytes per value, length implicit (`byteCount / 4`). The two arrays are the same length and are parallel: element *i* of `magnitudesData` is the magnitude (dB) at the frequency (Hz) given by element *i* of `frequenciesData`.

Reference decoder (Python):

```
import base64, struct
b = base64.b64decode(snapshot["frequenciesData"])
freqs = list(struct.unpack(f"<{len(b)//4}f", b))
```

Peak

Field	Type	Notes
`id`	UUID	Stable identifier within the measurement.
`frequency`	float	Hz.
`magnitude`	float	dB.
`quality`	float	Q factor.
`bandwidth`	float	–3 dB bandwidth, Hz.
`timestamp`	ISO-8601	When the peak was detected.
`pitchNote`	string	Nearest equal-temperament note, e.g. `"D4"`. Optional.
`pitchCents`	number	Cents offset from `pitchNote` (double precision). Optional.
`pitchFrequency`	number	Frequency of `pitchNote` in Hz (double precision). Optional.
`modeLabel`	string	Resolved mode label — see note below. Top-level peaks only.

`pitchNote`, `pitchCents`, and `pitchFrequency` are present only when pitch detection produced a result; otherwise all three are omitted together.

`modeLabel` is a convenience the writer adds to each peak in the **top-level** `peaks` array: the resolved guitar mode name (e.g. `"Air (Helmholtz)"`, `"Top"`), the user's assigned override if any, or — for plate / brace — the peak's role (`"Longitudinal"`, `"Cross-grain"`, `"FLC"`, or `"Peak"`). It is derived from the other fields and the measurement settings, so a reader can use it directly or ignore it and reclassify. It is **not** written on peaks nested inside `tapEntries` or `comparisonEntries`.

ComparisonEntry (when `comparisonEntries` is present)

Field	Type	Notes
`id`	UUID	Identifier for the overlay entry.
`label`	string	Display label shown in the legend.
`colorComponents`	array of 4 floats	RGBA, each 0.0 – 1.0.
`snapshot`	SpectrumSnapshot	Full spectrum data for this overlay curve.
`peaks`	array of Peak	Peaks for this overlay's source measurement.
`guitarType`	string	For mode classification.
`modePeakIDs`	object	Maps each identified mode name (`air`, `top`, `back`, …) to the UUID of the peak that carries it in this overlay — computed override-aware when the comparison was saved, so the entry is self-describing and a reader need not re-classify. A plain JSON object with string keys (not a flat UUID-map). Omitted by builds before this field existed; such files are upgraded on open by re-deriving the map.
`sourceMeasurementID`	UUID	The measurement this entry was created from, if known.

When `comparisonEntries` is non-null the measurement is a saved comparison: the top-level `peaks`, `spectrumSnapshot`, `decayTime`, and similar fields are not meaningful and should not be read.

TapEntry (when `tapEntries` is present)

Present only for guitar multi-tap measurements (`numberOfTaps > 1`). Each entry preserves the raw spectrum and peaks for one tap so the multi-tap comparison view can be reconstructed:

Field	Type	Notes
`id`	UUID	
`tapIndex`	int	1-based display index.
`snapshot`	SpectrumSnapshot	Raw single-tap spectrum.
`peaks`	array of Peak	Peaks detected in this single tap.
`selectedPeakIDs`	array of UUID	Auto-selected modes for this tap.

Legacy compatibility (reader-only)

Everything above describes what current builds **write**. Files saved by older versions of Guitar Tap may differ in the ways listed here. If you are parsing `.guitartap` files you are likely to meet some of these in the wild, so a robust reader should accept them all; a writer should emit only the current forms.

You may encounter	Read it as	Why
`peakThreshold`	`peakMinThreshold`	The field was renamed; older files use the old name. If both are present, prefer `peakMinThreshold`.
`tapLocation`	`measurementName`	Renamed.
`frequencies` / `magnitudes` (plain arrays of float)	`frequenciesData` / `magnitudesData`	The spectrum arrays predate the compact Base64 binary encoding and were stored as ordinary JSON float arrays.
`peakModeOverrides` as a JSON **object** (`{ "<uuid>": { … } }`)	the flat alternating array	Early Python 1.0.x builds. See "UUID-keyed maps" above.
Annotation offsets as `{ "hzOffset": …, "dbOffset": … }`	*(drop them)*	An old delta-based label-position format that cannot be converted reliably; affected labels simply revert to their default position.
Any field not documented here (e.g. `hysteresisMargin`, `maxPeaks`)	*(ignore it)*	The format is additive. Skip unknown keys rather than rejecting the file.

Two absences are themselves meaningful: a missing `sampleRate` means the capture rate was not recorded (treated as "unknown", no warning), and a missing `selectedPeakIDs` means every peak is considered selected.

Calibration files (`.txt` / `.cal`)

Frequency-response compensation data for a measurement microphone. Plain text; each data line carries a frequency and a magnitude correction, separated by **tab, space, or comma**. Either of the two common vendor formats works directly — UMIK-1 `.txt` files and Room EQ Wizard `.cal` files are both accepted:

```
"Sens Factor =-1.2 dB, SERNO 7123456"
"Frequency (Hz)   Magnitude (dB)"
20.0      -1.2
50.0      -0.4
```

```
100.0       0.0
...
20000.0    -3.1
```

Header and comment lines begin with `"` (UMIK-1) or `*` (REW) and are skipped. Only frequencies in the range **1 Hz to 24,000 Hz** are used; values outside that range are ignored.

The app applies the inverse of this curve to the incoming spectrum so that the displayed result reflects the wood, not the microphone. Calibrations bind per-input-device — see §2.4 for the import workflow.

Exported formats

The export actions described in §7.6 – §7.8 produce these file types:

Action	Extension	Contents
Export Measurement / Save Measurement to Disk	`.guitartap`	Full measurement — peaks, spectrum data, settings, metadata (see above).
Export Spectrum Image	`.png`	Chart as rendered on screen — frozen spectrum with peak annotations for a single measurement, or the overlay with all coloured curves and legend for a comparison.
Export PDF Report	`.pdf`	Spectrum image + peak table + analysis summary + metadata header. Contents vary by measurement type; see §7.7 for the per-type breakdown.