

REPLACEMENT PARTS




MODEL A120 SERIES MIXER

(INCLUDES MOTOR PARTS) ML-104865


Table of Contents

Page	Description
3	Switch and Timer Unit
5	Planetary and Attachment Hub Unit
7	Base Unit
9	Pedestal And Bowl Unit
11	Transmission Case and Shifter Unit
13	Motor Parts
15	Transmission Gear Unit
16	Agitators



SWITCH AND TIMER UNIT


ILLUS. PL-55563	PART NO.	NAME OF PART	AMT
1	00-294650-004-1	Timer Assy. (115 V., 60 Hz.)	1
2	00-294650-004-4	Timer Assy. (220 V., 50 Hz.)	
3	00-291746	Insulator – Switch	1
4	00-120388	Switch & Label Assy.	1
5	00-873115-00001	Switch Plate & Pin Assy.	1
6	SC-013-07	Mach. Screw 5-40 x ¹ / ₄ Flat Hd.	2
7	00-123109	Screw 6-32 x 3/8 Serrated Hd.	2
8	SC-027-28	Mach. Screw 8-32 x ¹ / ₄ Rd. Hd. (Grounding Screw)	1
9	WL-011-01	Lockwasher #8 Internal Shakeproof (Grounding Screw) (1 Ph.)	2
10	NS-010-11	Mach. Nut 8-32 Hex (Ground Screw) (1 Ph.)	
11	00-291748	Knob – Timer	



PLANETARY AND ATTACHMENT HUB UNIT

PLANETARY AND ATTACHMENT HUB UNIT

ILLUS. PL-55559	PART NO.	NAME OF PART	AMT
1	00-114824-00001	Plug – Attachment Hub	1
2	00-435047-00004	Hub – Attachment (Painted)	1
3	00-435065-00002	Bevel Drive Gear & Seal Assy.	1
4	RR-004-18	Retaining Ring	1
5	00-012430-00048	Key ³ / ₁₆ x ³ / ₁₆ x 4	1
6	00-012683	Pinion – Beater (17T)	
7	BB-018-17	Ball Bearing – N.D. #7503	1
8	00-007094	Spring	
9	BA-002-09	Ball 1/4 Dia	2
10	00-113953	Planetary (Painted)	1
11	BB-018-17	Ball Bearing – N.D. #7503	1
12	00-121814	Seal – Oil (1" I.D.)	1
13	00-113949	Agitator Shaft Assy. (Incls. Item 14)	
14	00-065062-00002	Pin – Dowel	1
15	SC-040-08	Cap Screw 1/4-20 x 1 Fil. Hd	6
16	WL-003-35	Lockwasher 1/4 Helical	6
17	00-012682	Internal Gear (63T) (Incls. Items 8 & 9)	1
18	00-012746-00019	Washer - Thrust (0.115)	
19	00-012746-00005	Washer - Thrust (0.080)	AR
20	00-012746-00006	Washer - Thrust (0.106)	
21	00-012746-00007	Washer - Thrust (0.092)	AR
22	00-012746-00008	Washer - Thrust (0.086)	AR
23	00-012746-00009	Washer - Thrust (0.098)	AR
24	00-012746-00010	Washer - Thrust (0.112)	AR
25	00-012746-00012	Washer – Thrust (0.119)	AR
26	00-012746-00013	Washer - Thrust (0.121)	AR
27	00-012746-00016	Washer - Thrust (0.129)	AR
28	00-108197-00001	Thumb Screw	1
29	WL-019-79	Lockwasher	4
30	SC-119-07	Mach. Screw 12-24 x 3/4 Flat Hd. (Painted)	4
	00-113954	Planetary Assy. (Painted) (Incls. Items 4 thru 7 & 10 thru 13)	1




PL-55481

BASE UNIT

BASE UNIT

ILLUS. PL-55481	PART NO.	NAME OF PART	АМТ
1	00-873229-00003	Base (Painted)	1
2	00-108159	Screen – Air	1
3	WS-018-19	Washer	4
4	SC-097-53	Cap Screw 3/8-16 x 21/4 Hex Hd.	
5	00-110717-00001	Plug – Base (Plug for Foot Pads) (Packed 8)	1

- 7 -




PL-55561

PEDESTAL AND BOWL UNIT

PEDESTAL AND BOWL UNIT


ILLUS. PL-55561	PART NO.	NAME OF PART	AMT
1	00-438078	Splash Cover & Bowl Extension (12 Qt.)	1
2	00-023438	Bowl Assy. (12 Qt.) (SST)	1
3	WL-006-22	Lockwasher 5/16 Light	
4	SC-041-13	Cap Screw 5/16-18 x 1 Hex Hd. (SST)	2
5	00-270776	Dowel	
6	WL-006-22	Lockwasher 5/16 Light	2
7	SC-011-95	Mach. Screw 5/16-18 x 1 Fil. Hd.	2
8	00-078634-00002	Pedestal	
9	00-070641-00011	Thumb Screw 8-32 Special	2
10	00-078506	Shield – Upper Splash	1
11	PC-003-55	Cotter Pin 1/8 x 3/4	1
12	PS-004-15	Spiral Pin 1/4 Dia. x 11/8 Lg	1
13	00-114432	Arm – Bowl Lift	
14	WS-009-11	Washer (STL)	AR
15	WS-009-13	Washer (Fiber)	AR
16	00-114432	Lift Handle Assy	1
17	00-012714	Bowl - Lift Rod	1
18	WS-006-33	Washer	2
19	PC-003-55	Cotter Pin 1/8 x 3/4	1
20	00-012745	Washer - Special	
21	00-012782	Spring	1
22	WS-006-26	Washer	
23	NS-036-15	Stop Nut 3/8-24 Hex Special	1
24	SC-022-20	Mach. Screw 10-24 x 5/8 Flat Hd.	8
25	00-012715	Gib – Bowl Support	2
26	00-016388-00001	Shim – Bowl Support (0.003" Thk.)	AR
27	00-016388-00004	Shim – Bowl Support (0.009" Thk.)	AR
28	00-016388-00005	Shim – Bowl Support (0.005" Thk.)	AR
29	00-016388-00006	Shim – Bowl Support (0.007" Thk.)	AR
30	00-016388-00007	Shim – Bowl Support (0.015" Thk.)	AR
31	00-121625	Set Screw - Special	
32	SC-060-56	Mach. Screw 10-32 x 5/16 Rd Hd	2
33	00-078505	Shield - Lower Splash	1
34	00-478582	Pin – Bowl Locating	2
35	00-024870	Bowl Support Assy. (Incls. Item 31)	
36	00-291444-00001	Clamp – Bowl (LH)	1
37	00-291444-00002	Clamp - Bowl (RH, Shown)	1
38	00-291263	Washer – Belleville	6
39	00-274614	Screw - Pivot	2
40	00-087711-252-1	Switch - Reed	1



TRANSMISSION CASE AND SHIFTER UNIT

TRANSMISSION CASE AND SHIFTER UNIT


ILLUS. PL-55562	PART NO.	NAME OF PART	АМТ
1	00-018231-00003	Cover – Transmission Case (Painted)	1
2	SC-016-17	Mach. Screw 12-24 x 1 ¹ / ₄ Oval Hd	1
3	SC-015-57	Mach. Screw 12-24 x 11/2 Oval Hd	1
4	00-012708	Retainer – Twin Bearing	1
5	00-020394-00001	Cap – Bearing Retainer	
6	00-020395	Retainer – Bearing	1
7	00-011800-00061	Dowel	2
8	00-012735	Rod – Shifter Guide	1
9	00-873802-00005	Cover – Back (Painted)	1
10	WL-003-28	Lockwasher #12 Light	
11	SC-127-85	Mach. Screw 12-24 x 21/2 Pan Hd	4
12	SC-009-49	Mach. Screw 6-32 x 3/8 Rd. Hd	2
13	00-115231-00002	Cover - Conduit	1
14	FE-022-84	Strain Relief 1/2 NPT	1
15	00-117542-00081	Cord & Plug Assy. (3 Cnd., Under 150 V.)	1
16	00-117542-00080	Cord Assy. (I.E.C.)	
17	00-077401	Knob – Shifter Handle	
18	00-875241	Handle – Shifter (Incls. Item 17)	1
19	SC-015-34	Mach. Screw 10-24 x ¹ / ₂	
20	00-290115-00001	Plate – Shifter Index	
21	00-023946	Gasket – Shifter Index Plate	1
22	PS-003-08	Spiral Pin 1/8 Dia. x 3/4 Lg.	1
23	BA-002-09	Ball 1/4 Dia.	
24	00-111170	Spring – Detent	2
25	NS-013-22	Nut ³ / ₈ -16 Hex	
26	WL-004-06	Lockwasher 3/8 Medium	
27	00-013160	Yoke – Shifter	
28	00-873504	Cam – Gear Shifter	
29	00-012733	Plunger – Shifter Yoke	
30	00-012734	Spring – Shifter Yoke	
31	00-012732	Retainer – Shifter Yoke Spring	
32	00-873140-00001	Case – Transmission (Incls. Items 7 & 33)	
33	00-011800-00116	Dowel	
34	WL-003-28	Lockwasher #12 Light	
35	SC-119-07	Mach. Screw 12-24 x ³ / ₄ Hex Hd	
36	00-067750	Transmission Shaft Support & Screw Assy. (Incls. Items 37 & 38)	
37	NS-009-36	Mach. Nut 12-24 Hex	
38	SC-008-56	Mach. Screw 12-24 x 1/2 Rd. Hd.	
39	00-064871	Plug – Friction	
40	WL-003-28	Lockwasher #12 Light	
41	SC-008-48	Mach, Screw 12-24 x ½ Rd. Hd.	
42	WL-003-22	Lockwasher #10 Light	
43	SC-018-01	Mach. Screw 10-24 x 3/8 Pan Hd.	
44	NS-009-36	Mach. Nut 12-24 Hex	
• •	00-875249	Shifter Assy. (Incls. Items 18, 20, 22, 23, 24, & 28)	
		, , , -, ,,	



MOTOR PARTS

MOTOR PARTS


ILLUS. PL-55560	PART NO.	NAME OF PART	АМТ
1	NS-032-23	Lock Nut	1
2	00-012430-00004	Key ¹ / ₈ x ¹ / ₈ x ¹ / ₄	1
3	00-291221	Gear – Worm (60 Cycle)	
4	00-070407	Gear - Worm (50 Cycle)	
5	00-012754	Washer	1
6	00-012757	Spring – Shock Absorber	1
7	00-873057	Deflector – Grease	
8	SD-015-38	Self-Tapping Screw 6-32 x 3/8 Phil. Pan Hd., Type TT	2
9	00-271612-00002	Switch - Electronic Start (50/60 Hz.)	1
10	00-873203-00002	Block – Terminal	
11	SD-015-38	Self-Tapping Screw 6-32 x 3/8 Phil. Pan Hd., Type TT	1
12	00-873125	Bracket - Component Mounting	
13	SD-015-39	Self-Tapping Screw 8-32 x 1/4 Phil. Pan Hd., Type TT	2
14	WL-008-07	Lockwasher #8 Internal Shakeproof	
15	00-087714-042-1	Relay (2 Pole) (115 V.)	1
16	00-087714-042-3	Relay (2 Pole) (240 V.)	1
17	SD-015-38	Self-Tapping Screw 6-32 x 3/8 Phil. Pan Hd., Type TT	2
18	00-873061-00001	Motor Assy. (60 Hz.)	1
19	00-837061-00003	Motor Assy. (50 Hz.)	
20	00-113703	Cable Tie	
21	00-070487-00025	Capacitor – Motor Start	1




TRANSMISSION GEAR UNIT

TRANSMISSION GEAR UNIT

ILLUS. PL-55483	PART NO.	NAME OF PART	АМТ
1	NS-032-29	Stop Nut 1/2-20 Flexloc	1
2	WS-008-13	Washer - Retaining	
3	BB-020-18	Ball Bearing – N.D. #77503	1
4	WS-010-18	Washer - Bearing Shim (0.002" Thk.)	AR
5	WS-010-19	Washer - Bearing Shim (0.003" Thk.)	AR
6	WS-010-20	Washer - Bearing Shim (0.010" Thk.)	AR
7	00-107145	Spacer - Planetary Shaft	1
8	00-124730	Sleeve – Roller Clutch Drive	1
9	00-109070-00002	Key	
10	00-124729	Clutch – Roller	10
11	00-124732	Spring – Roller	10
12	00-124752	Gear - Slow Speed (46T)	
13	00-124733-00002	Gear - Bevel (46T)	1
14	00-124744	Gear - Clutch (29T)	1
15	00-012695	Bearing - Clutch Gear	1
16	00-012430-00059	Key – Clutch Sleeve	2
17	00-070035-00001	Sleeve - Clutch	1
18	00-012695	Bearing – Clutch Gear	1
19	00-124743	Gear - Lower Clutch (38T)	
20	00-012723	Spacer - Lower	
21	BB-020-06	Ball Bearing – N.D. #7504	1
22	00-012430-00017	Key	
23	00-124734	Shaft - Planetary	1
24	00-437342	Spacer – Bearing	1
25	00-114695	Seal – Oil	
26	00-124946	Washer - Fiber	
27	WS-030-83	Washer - Retaining (STL)	
28	00-010928-00002	Nut – Special	
29	00-024715-00003	Acorn Nut 1/2-20	
30	00-012710	Nut – Retaining	
31	WS-006-36	Washer - Retaining	
32	BB-005-02	Ball Bearing – N.D. #7500	
33	00-012744	Spacer – Upper	
34	00-291236	Shaft – Transmission (15T)	
35	00-124736	Gear (32T)	1
36	00-435297	Key	
37	00-012697	Spacer – Lower	
38	00-435297	Key	1
39	00-124760	Gear (23T)	1
40	RR-004-18	Retaining Ring	
41	BB-005-01	Ball Bearing – N.D.#3200	
42	SL-002-08	Spring – Preloading N.D. #S-10-B	
43	00-012710	Nut – Retaining	
44	WS-006-36	Washer – Retaining	
45	BB-005-02	Ball Bearing - N.D. #7500	1
46	00-124745	Washer	1
47	00-124765-00001	Spacer - Gear	1
48	00-124748	Gear (15T)	
49	00-012430-00004	Key	
50	00-124751-00003	Worm Wheel & Bushing Assy. (60 Hz.)	
51	00-124749-00002	Worm Wheel & Bushing Assy. (50 Hz.)	
52	00-291128	Shaft – Worm Wheel	
53	BB-005-01	Ball Bearing – N.D. #3200	
54	SL-002-08	Spring – Preloading N.D. #S-10-B	
	00-292799-00002	Planetary Shaft Assy. (Incls. Items 7, 8, 9, 12 thru 20, & 23)	
	00-292800	Transmission Shaft Assy. (Incls. Items 33 thru 40)	
	00-292798-00001	Worm Wheel Shaft Assy. (60 Hz.) (Incls. Items 46 thru 50, & 52)	
	00-292798-00002	Worm Wheel Shaft Assy. (50 Hz.) (Incls. Items 46 thru 49, 51, & 52)	





PL-55564

AGITATORS

ILLUS. PL-55564	PART NO.	NAME OF PART	AMT
1	00-275549	"B" Flat Beater	1
2	00-275551	"B" Flat Beater (SST)	1
3	00-295166	"C" Wing Whip	1
4	00-275895	"D" Wire Whip (SST)	
5	00-315692	"P" Pastry Knife	1