
 Bit R12-address I/O/I+ Usage

0	>0000	I/O	0: I/O mode 1: timer mode
1	>0002	I+	0: A peripheral interrupt occurred
2	>0004	I+	0: a VDP interrupt occurred
3	>0006	I	= . , M N / fire1 fire2
4	>0008	I	Space L K J H ; left1 left2
5	>000A	I	enter 0 I U Y P right1 right2
6	>000C	I	(none) 9 8 7 6 0 down1 down2
7	>000E	I	fctn 2 3 4 5 1 up1 up2
8	>0010	I	shift S D F G A
9	>0012	I	ctrl W E R T Q
10	>0014	I	(none) X C V B Z
11	>0016	-	(see bit 27)
12	>0018	I/I+	Pull up 10K to +5V
13	>001A	-	(see bit 25)
14	>001C	-	(see bit 24)
15	>001E	-	(see bit 23)
16	>0020	I/O	n.c.
17	>0022	I/O	n.c.
18	>0024	0	Select keyboard column (or joystick)
19	>0026	0	Select keyboard column (or joystick)
20	>0028	0	Select keyboard column (or joystick)
21	>002A	0	Set alpha-lock key
22	>002C	0	1: turn CS1 motor on
23	>002E	0	1: turn CS2 motor on
24	>0030	0	Audio gate
25	>0032	0	Output to cassette mike jack
26	>0034	-	(see bit 18)
27	>0036	I	Input from cassette headphone jack
28	>0038	-	(see bit 10: keyboard mirror)
29	>003A	-	(see bit 9)
30	>003C	-	(see bit 8)
31	>003E	-	(see bit 7)
