

SAMS MAPPER

The SAMS card has tons of documents as to its function and use. So to re-explain these docs would be pointless. Read the docs or find some, sorry but the RXB package is already huge.

In PASS mode the mapper register setup is equivalent to:

mapper address		mapper	page num		address range
-----		-----	-----		-----
HEX	Dec		HEX	Dec	memory area
---	---		---	---	-----
>4004	= 16388	is MR02	= >02	= 02	points to >2000 - >2FFF range
>4006	= 16390	is MR03	= >03	= 03	points to >3000 - >3FFF range
>4014	= 16404	is MR10	= >0A	= 10	points to >A000 - >AFFF range
>4016	= 16406	is MR11	= >0B	= 11	points to >B000 - >BFFF range
>4018	= 16408	is MR12	= >0C	= 12	points to >C000 - >CFFF range
>401A	= 16410	is MR13	= >0D	= 13	points to >D000 - >DFFF range
>401C	= 16412	is MR14	= >0E	= 14	points to >E000 - >EFFF range
>401E	= 16414	is MR15	= >0F	= 15	points to >F000 - >FFFF range

(MR=Mapper Register)

In MAP mode the mapper register setup is equivalent to: EXAMPLE1

mapper address		mapper	page num		address range
-----		-----	-----		-----
HEX	Dec		HEX	Dec	memory area
---	---		---	---	-----
>4004	= 16388	is MR02	= >10	= 16	points to >2000 - >2FFF range
>4006	= 16390	is MR03	= >11	= 17	points to >3000 - >3FFF range
>4014	= 16404	is MR10	= >12	= 18	points to >A000 - >AFFF range
>4016	= 16406	is MR11	= >13	= 19	points to >B000 - >BFFF range
>4018	= 16408	is MR12	= >14	= 20	points to >C000 - >CFFF range
>401A	= 16410	is MR13	= >15	= 21	points to >D000 - >DFFF range
>401C	= 16412	is MR14	= >16	= 22	points to >E000 - >EFFF range
>401E	= 16414	is MR15	= >17	= 23	points to >F000 - >FFFF range

(MR=Mapper Register)