Pilot Tone Trigger

Quick reference — controls & first-run setup

Watches an audio input carrying a continuous pilot tone. While the tone is present the primary source is considered healthy; if the tone drops, the app sends MIDI to the dLive to switch to the backup — an **Action** (Control Change), a **Scene** recall (Program Change), or both. The app can also generate the tone itself (see Tone Generator). Typical tone-drop → MIDI latency with default settings: ≈150–250 ms.

Menu bar icon

Click	Show / hide the control panel.
Right-click	Quit the app (there's no Dock icon or app menu — this is the only way to quit).
Icon colour	The sine-wave mark: grey = stopped. Blue = running, tone present. Red = tone lost — failover sent. Amber = tone restored but latched on backup (press Reset). Purple = level fine but the tone looks corrupted (Signal Integrity). **Amber, pulsing** = running but not reaching the console: MIDI Bridge or the console isn't there (the same amber MIDI Bridge shows while it connects; a steady amber is latched).

Connection

The link line proves the console is reachable, not the console-side mapping — verify that end-to-end once.

MIDI Bridge	Pilot Tone reaches the console through the free **MIDI Bridge**, which holds the one connection to the MixRack for all your dylanmaudio apps. Set the console's IP address (the **MixRack's**, never the Surface's) and base MIDI channel there, once; this app uses them, and shows as “Pilot Tone Trigger” in its MIDI Monitor.
The link line	Says whether the console is reached. **Green**: connected, and to which console. **Amber**: MIDI Bridge is running but not connected to the console — check the console IP and network in MIDI Bridge. **Red**: MIDI Bridge isn't running (**Open MIDI Bridge**) or isn't installed (**Get MIDI Bridge**).
Direct TCP / Existing MIDI Port	Kept in this version only, for setups that already use them: the panel says so, with **Move to MIDI Bridge**. They will be removed in the next version. A setup already on MIDI Bridge's MIDI port moves over by itself.

Audio Input

Device	The audio interface carrying the pilot tone.
Channel	Which input channel on that device to listen to.

Tone Generator

If Signal Integrity (below) is on, it's only as reliable as this reference tone: an EXTERNAL tone generator can drift a little in frequency or carry more inherent distortion than this app's own synthesized sine, which eats into how tight the Purity Threshold can be set before it false-trips on a perfectly healthy signal.

What it's for	The app can be both ends of the chain: generate the pilot tone to an output, route it through the system under watch (e.g. out to the console and back), and loop it into the Audio Input. If the loop breaks anywhere along the path, the tone disappears and the failover fires.
Output Device	Which audio output carries the generated tone.
Output Channel	Which channel of that device gets the tone — the other channels stay silent. Changing it, or the Output Device, moves a playing tone straight away.
Frequency (1000 Hz)	Sine frequency, 20–20 000 Hz. Retunes live, click-free.
Level (–20 dBFS)	Output level. Changes ramp smoothly.
Start / Stop Tone	Independent of the detection engine — the tone keeps running across detection Start/Stop. It never auto-starts on launch; starting it is always a deliberate click.
If the Mac's audio resets	Installing an audio driver, or sleep/wake, resets the Mac's audio system. The app notices within about 2 seconds and reopens the tone and the input on the devices you chose (Latch kept, nothing sent), and says so. A tone that stops for another reason is reopened within 3 seconds, retried every 10.

MIDI Output

What each state change sends. Columns in the app: Signal Lost (red, left) and Signal OK (green, right) — each state has its own settings.

Action (CC)	Sends a Control Change per state — its own CC number and value. On the dLive an incoming CC triggers an **ACTION**, e.g. setting a group of channels to Preamp A/B/C/D, toggling an insert on/off, and so on. The console must be told what that CC means: map it under **Surface** → **Control** → **Actions** → **MIDI Recall**, matching the CC number and value set here and the base MIDI channel set in MIDI Bridge. An Action fires only on its **exact value**, so map two: one on the tone-lost value, one on the tone-back value. New installs default to **CC 85** — Pilot Tone Trigger's own number in the dylanmaudio suite, value **127** for tone present and **0** for tone lost. Existing configs keep whatever number they already had.
Scene (PC)	Sends a Program Change (with Bank Select) per state — recalls a **SCENE** directly, no mapping needed. Scene numbers 1–500, as shown on the console's Scenes screen.
Both	Fires the Action first, then the Scene, on every state change (and on Reset).

Important — a Scene recall changes everything the Scene stores, not just what you intend. Set each Scene's Recall Filter to allow only the items the failover should touch. For Actions, nothing happens at all until the matching MIDI Recall mapping exists on the console.

Failback

Automatic	When the tone returns, the Signal OK output fires by itself and the system is back on primary. Switching from Latch to Automatic releases an armed latch — and fires the Signal OK output immediately if the tone is already back.
Latch until Reset	After a dropout the app stays on backup even when the tone returns — no automatic flap back onto a source that just failed. While latched, further drop/restore cycles send nothing at all (the console is already on backup) until Reset or a switch to Automatic releases it. Recommended for shows.
Primary / Backup	The bar under Start / Stop shows which side the console is on while the app runs: **On Primary (A)** in blue, **On Backup (B)** in red — the side the last output that reached the console put it on. Right after Start it reads "not switched since Start": Start sends nothing, so the console is wherever it was left until the first switch.
Don't fail over for a Mac audio reset	Off by default. When on, a dropout is held only if macOS reports its audio system restarting (an audio driver install, sleep/wake) just before it — never on silence alone, so a broken loop always fails over at once. Ends when the tone returns (nothing sent); fails over once the audio is back without the tone, or after 5 s at most.
Reset button	The same bar turns amber and becomes **Reset to Primary** once the tone is back while latched. Sends the Signal OK output and re-arms. Refuses if the tone is still below threshold.
Start / Stop Tone (top)	Beside Flip A/B: the tone generator's on/off, same as the button in the Tone Generator section (its settings are there).
Send failover now	If a failover can't reach the console (MIDI Bridge or the console away), it's sent as soon as the connection is back, within **10 seconds**. After that it's held: the tile reads **Failover not delivered** and this bar becomes **Send failover now**, so you decide whether the console should still switch. Nothing is sent later on its own. Signal OK works the same way.
After an outage	A side the console already has is never sent again, so an Action set to toggle can't be switched back by mistake — e.g. the tone dropped and returned while MIDI Bridge restarted.
Long messages	Hover over the status message to read all of it.
Flip A/B button	Manual override — sends the opposite of the side shown above it, any time the app is running; a Flip to B shows as **Held on Backup** until Reset or Flip. Sends regardless of what Level or Signal Integrity currently think. Flipping to backup engages the same latch a real dropout would (so a healthy reading can't quietly flip it back); flipping to primary clears it, like Reset.

Level meter

Amber line	Threshold — the level must be above this to count as tone present (recover point).
Red line	Trip point (Threshold − Hysteresis) — the level must fall below this to count as tone lost.
Between the lines	State holds; the status caption reads “In hysteresis band” and shows the exact trip level.

Sensitivity

Defaults are tuned for a continuous pilot tone.

Threshold (–45 dB)	Set below the tone level. Raising it closer to the tone speeds up detection.
Dropout Hold (50 ms)	Time below the trip point required before failing over (rides out single glitched audio blocks).
Hysteresis (6 dB)	Gap between recover and trip lines — prevents flapping at the threshold.
Min Retrigger (200 ms)	Minimum time between consecutive switches, even if the level keeps crossing.
Env Release (30 ms)	How fast the level reading falls — the main latency lever. Shorter = faster detection.

Important — watching programme material instead of a tone? Raise Dropout Hold above the material's longest natural silence and lengthen Env Release (~300 ms), or quiet passages will trip a failover.

Signal Integrity (optional)

Off by default. Only meaningful watching a tone this app generated, or an external source at a precisely known, stable frequency — see the Tone Generator note above.

What it's for	Level alone can't tell a healthy tone from noise or a garbled signal at the same volume. This checks how much of the incoming audio actually sits at the tone's own frequency — clicks, dropouts, noise, clipping and a wrong/garbled tone all show up the same way, as energy that doesn't belong there.
Purity Threshold / Hysteresis / Hold / Min Retrigger	Same shape as Sensitivity above, against a 0–1 purity ratio instead of dB. The starting values are a deliberately conservative placeholder, not a validated default — every interface and signal chain has its own noise floor. Tune to your own rig.
Warn only	Reports Degraded and counts it. Sends nothing — the console keeps running on whatever it's already on.
Also fail over	Additionally fires the same Signal Lost / Signal OK outputs a real dropout would, while still showing Degraded (not Lost) so it's clear why. Recovers on its own once purity clears — no Reset needed, and independent of Failback mode/Latch.

Important — this is not a clone of any hardware vendor's proprietary integrity signal. It's a from-scratch check built for a tone that has to survive an analogue stage and gain changes, unlike some hardware digital-integrity signals which explicitly cannot.

Running it

Start / Stop	Opens (or closes) the audio input and begins (or stops) watching the level. The app arms assuming the tone is present — a feed that is already dead trips the failover after Dropout Hold. Start doesn't wait for the console: if MIDI Bridge isn't connected yet, it arms, says so in red, and sends as soon as it connects.
Status tile	Stopped / Signal Present / Signal Lost / Restored — Latched / Signal Degraded (violet, Signal Integrity only). Mirrors the menu bar icon colour. A red “Start Failed” tile names the failing subsystem (console / audio input) in full.
First launch	macOS will prompt for microphone access the first time you click Start — allow it, or the app won't receive any audio.
Settings	Persist to ~/Library/Application Support/Pilot Tone Trigger/config.json.

Bitfocus Companion

Loopback only, port 8772, no setup needed on this side — add this app in the dylanmaudio Companion module.

What it controls	Run, Failback mode, Reset, and the tone generator — as Companion buttons, with this app's own state shown back on them (works from Companion even if the popover isn't open).
Allow Companion control	On by default. Off refuses every Companion press; Companion can still show why.
Lock show-critical controls	Off by default. On refuses Run-off and Failback mode from Companion — Reset and the tone generator are never locked.

If something goes wrong

Red: macOS audio stuck	Rare, after macOS's audio system resets (seen when forcing many resets in a row). A macOS Core Audio fault, not the app's. Nothing is sent while it lasts. Quit Pilot Tone Trigger and open it again.
Red: Not reaching the console	The line under it says what's missing: start MIDI Bridge, or check the console IP and network in MIDI Bridge. The Primary / Backup bar keeps showing the side the console was last actually switched to — so a failover that hasn't arrived shows as still On Primary.
Red: Failover not delivered	It couldn't be sent within 10 seconds. Press **Send failover now** in the Primary / Backup bar once MIDI Bridge is connected, if the console should still switch.
Export log	Click **Export log** in the panel footer. A diagnostics zip lands on your Desktop and opens in Finder — this session's log, the previous one, and your settings (licence details removed). Send that zip with your report; nothing leaves your Mac unless you send it.
What the log holds	Your settings at launch and each change, the audio and MIDI devices present, every Start and Stop, every failover and signal-OK sent to the console (and any that failed), the latch, each Reset and Flip, every error the panel showed you, your licence or trial state. Every launch is logged automatically.
The log folder	Right-click the menu bar icon and choose **Open Log Folder** (**~/Library/Logs/dylanmaudio/Pilot Tone Trigger/**, newest 20 launches kept).
Send feedback	Also in the footer — a short message straight to me, no email client needed.

On Windows

Install	Run **Pilot Tone Trigger Setup**: it installs for you alone, with no administrator prompt. Start menu → **dylanmaudio** holds the app, this guide and the uninstaller. An update installs over the old one; if Pilot Tone is running, Setup offers to close it first (say No if a show is running).
MIDI Bridge	Pilot Tone reaches the console through **MIDI Bridge for Windows** (1.4.5 or later, free). Direct TCP and Existing MIDI Port aren't offered on Windows.
Audio devices	Inputs and outputs are listed once each (WASAPI). A Dante Virtual Soundcard channel shows as **DVS Receive** / **DVS Transmit** with its channel numbers. Pilot Tone opens each device at the rate it is running at and never changes it; in Windows' Sound settings a device's **Default Format** must match the rate its driver runs at (Dante: the soundcard's rate), or the device won't open.
Microphone access	Settings → Privacy & security → Microphone must have **Let desktop apps access your microphone** on. If it's off, the input hears silence and Pilot Tone fails over.
Remote Desktop	Connecting to this PC with Remote Desktop, or coming back to its own screen, resets Windows audio for a moment: Pilot Tone reopens its tone and input by itself within a second or two. With **Don't fail over for a Windows audio reset** on (Failback), that moment is held instead of failing over. Turn it on if anyone may Remote Desktop into a show PC, and don't connect to one while a show is running.
The tray icon	Windows puts a new tray icon under the **^** by the clock. Drag it onto the taskbar to keep it in view. Click and right-click work as the menu bar icon does above. The first launch opens the panel for you.
Licence	The same licence as on the Mac: its two activations can be on either, or one of each.
Start at login	The same option in the panel. It also shows in Task Manager → Startup apps; switching it off there is respected.
Logs and settings	Logs: **%LOCALAPPDATA%\dylanmaudio\Logs\Pilot Tone Trigger** (Open Log Folder in the tray menu). Settings: **%APPDATA%\dylanmaudio\Pilot Tone Trigger**. Export log saves its zip to your Desktop and opens Explorer.
Uninstall	Start menu → dylanmaudio → Uninstall Pilot Tone Trigger, or Settings → Apps. It asks whether to remove your settings and logs too. Your licence stays activated either way.

What's new in v1.3.0

• New: Pilot Tone Trigger for Windows 10 and 11 (64-bit), in the system tray, with MIDI Bridge for Windows (1.4.5 or later). Your licence's two activations can be on a Mac or a PC.
• New: Pilot Tone Trigger now reaches your console through MIDI Bridge (1.4.5 or later), which is free and holds the one connection to the console for all your dylanmaudio apps. The Connection section is a single line saying whether the console is reached, with Open MIDI Bridge (or Get MIDI Bridge, if it isn't installed). The console's IP address and base MIDI channel are set once, in MIDI Bridge.
• New: a failover that can't reach the console straight away, because MIDI Bridge or the console is briefly away, is sent as soon as the connection is back, if that is within 10 seconds.
• New: after 10 seconds it is held, not sent. The tile reads "Failover not delivered" and the Primary / Backup bar becomes Send failover now, so you decide whether the console should still switch. Nothing is sent later on its own. Signal OK works the same way.
• New: after an outage, a side the console already has is not sent again, so an Action set to toggle can't be switched back by mistake. If the tone drops and returns while MIDI Bridge restarts, nothing is sent.
• New: while running and not reaching the console, the status tile is red with the reason, and the menu bar icon pulses amber, the colour MIDI Bridge shows while it connects (a steady amber still means latched). On MIDI Bridge, Start doesn't wait for the console: it arms and watches the tone, and sends as soon as MIDI Bridge connects.