



Talk Light Trigger

Quick reference — controls & first-run setup

Listens to a talkback mic/bus input and fires a dLive Scene recall whenever the level crosses a threshold — one Scene while quiet, a different one while talkback is active. Point each Scene's Surface Illumination at a different colour and the console's lights flash with talkback.

Menu bar icon

Click	Show / hide the control panel.
Right-click	Quit the app (there's no Dock icon or app menu — this is the only way to quit).
Icon colour	Grey = stopped. Blue = running, listening (quiet). Bright = talkback active.

Connection

Choose one. Both reach the console the same way underneath — pick whichever needs less new software.

Direct TCP	Opens its own connection to the MixRack. Enter the console's IP (Host) — Port defaults to 51325.
Existing MIDI Port	Sends over a MIDI port already routed to the console — most easily the free dLive MIDI Bridge , or A&H's driver / loopMIDI / IAC. Pick it from the dropdown. When the port is dLive MIDI Bridge, this app identifies itself by name ("Talk Light Trigger") in the bridge's MIDI Monitor instead of showing as a generic connection.
Base MIDI Channel	Must match Utility → Control → MIDI on the console.

Audio Input

Device	The audio interface carrying the talkback signal.
Channel	Which input channel on that device to listen to.

Scenes

Quiet Scene #	Scene recalled while the input is below threshold.
Talkback Scene #	Scene recalled while talkback is active.

Important — on the console, save two Scenes with different dimmer values in Surface → Control → Dimmer. Both Scenes must have their Recall Filter restricted to Surface Illumination only. Without this, recalling either Scene changes the whole mix, not just the lights.

Sensitivity

Threshold	Level the input has to cross to count as "talking."
Attack Time	Time above Threshold required before it triggers (avoids brief noise/breath sounds).
Release	How far below Threshold the level must drop before counting as quiet again (avoids flicker at the edge).
Min Retrigger	Minimum time between Scene recalls, even if the level keeps crossing back and forth.



Talk-state signal (reference)

Informational only — this app still detects talk state from the Audio Input above and does not yet read this message. Documented here for a possible future signal path.

SoftKey → Custom MIDI	A console SoftKey assigned to Custom MIDI (string B0,7F,01 , comma-separated hex) sends a positive talk-state message to every connected MIDI client on the base MIDI channel — confirmed reaching the network on channel 1.
------------------------------	---

Running it

Start / Stop	Opens (or closes) the audio input and begins (or stops) watching the level.
Status tile	Stopped / Quiet / Active — mirrors the menu bar icon colour.
First launch	macOS will prompt for microphone access the first time you click Start — allow it, or the app won't receive any audio.

If something goes wrong

Export log	Click Export log in the panel footer. A copy of this session's log lands on your Desktop as a text file — send that with your report. Every launch is logged automatically to <code>~/Library/Logs/dylanmaudio/Talk Light Trigger/</code> ; nothing to switch on.
Send feedback	Also in the footer — a short message straight to me, no email client needed.

What's new in v1.0.5

- Improved: the app now opens just the one input channel you chose, with a large audio buffer, and never changes the interface's sample rate — so it costs the show's audio interface as little as a second app can. The channel, rate and buffer are written to the session log when the input opens.
- Clearer message when the chosen channel doesn't exist on the device, instead of a cryptic driver error.
- Fixed: if the audio input fails to open, the console connection is closed again instead of being left open behind the error.
- New: every session now writes a log, and a new Export log button in the footer saves a copy to your Desktop — so if something goes wrong at a show, there is evidence to send, without instructions.
- Quick Reference and README now document an optional console-side setup — a SoftKey sending a positive talk-state message over the network — for reference. Talk Light Trigger still detects talk state from the audio input by default; nothing changes unless you wire this up yourself.