



# Slocum Maintenance Schedule

This page organizes maintenance by **when** it needs doing, not by which component it touches — the detailed how-to for each item lives on the relevant [Glider Components](#) page or checklist; this is the index that tells you when to go read it.



## Source

Synthesized from facts already established across this site's Slocum component pages, the [Post-Recovery Maintenance Checklist](#), and the [Ballasting Procedure](#) — see those pages for sourcing and full detail.

## Before Every Deployment

| Item               | What to confirm                                                                 | Detail                                                 |
|--------------------|---------------------------------------------------------------------------------|--------------------------------------------------------|
| Vacuum             | $\geq 6$ in Hg (shallow) / $\geq 7$ in Hg (deep)<br>— never power up without it | <a href="#">One-Pager</a>                              |
| O-rings            | Inspect every hull O-ring and sealing surface; replace as needed                | <a href="#">O-Rings</a>                                |
| Desiccant          | Fresh pack installed for this deployment                                        | <a href="#">O-Rings</a>                                |
| Sacrificial anodes | Forward/aft continuity $< 10 \Omega$ ; replace if significantly consumed        | <a href="#">Post-Recovery Checklist</a>                |
| Battery            | Correct type installed and charged; coulomb counter reset if new pack           | <a href="#">Primary</a> · <a href="#">Rechargeable</a> |