


Config Tool Instruction


1 Connect sensor

Connect sensor to PC by a RS485 to USB converter




2 Read value

2.1 read ID





2.2 Read temperature or humidity



3 Set parameters

3.1 Set ID






3.2 Set BPS

0=2400, 1=4800, 2=9600



3.3 Set temperature or humidity calibration value



Output value=actual value + calibration value