Host Communication Documentation

SECS/GEM

- Chapter 2 -

ID Lists
Appendix

TOWA Corporation

▼ Contents

8. ID Lists 2
8-1. Variable Data 2
8-1-1 GEM Variables: 2
8-1-2 SECS States: 2
8-1-3 Process Program Change Data: 2
8-1-4 Machine Status: 3
8-1-5 Auto Mode: 4
8-1-6 Workpiece Position (HF1～HF4): 5
8-1-7 Workpiece Position (Other Module): 5
8-1-8 Module Variable Data(HF-1～ HF-4): 6
8-1-9 Module Variable Data(Other Module): 7
8-2. Equipment Alarm List 7
8-3. Collected Event Lists 8
8-3-1 SECS State Change Events: 8
8-3-2 Equipment Mode Change Events(Switch): 8
8-3-3 Equipment Mode Change Events(Auto Mode): 8
8-3-4 Equipment Mode Change Events(Primary HF1～HF4): 9
8-3-5 Equipment Mode Change Events(Primary Other Module): 9
8-3-6 Shot Count Events: 9
8-3-7 Variable Data Limit Events(HF1～HF4): 10
8-3-8 Variable Data Limit Events(Master Module): 10
8-3-9 Material Movement Events(HF1～HF4): 11
8-3-10 Material Movement Events(Master Module): 11
8-4. Host Command ID Lists 12
8-4-1 Remote Commands: 12
8-4-2 Command Parameters: 12
8-5. Equipment Constant 12
8-6. EQUIPMENT TERMINAL ID 12
8-7. EQUIPMENT MODEL TYPE 13
8-8. SOFTWARE REVISION CODE 13
8-9. SPOOLING CONDITION 13
8-10. TRACE CONDITION 13
9. Appendix 14
9-1. Range allowed and resolution for each parameter 14

0. Documentation History

Revision	Date	History	Author
0.0	07/07/06	Chapter1-3 for Y-Series	
1.0	12/02/01	Chapter4-9 for YPM	
1.1	15/02/17	Correction	

Copyright(c)2007-2015, TOWA Corporation.

8. ID Lists

8-1. Variable Data

8-1-1 GEM Variables:

VID	Format	Description	Unit	Limit
120	ASC	CURRENT DATE TIME (format=YYYYMMDDhhmmss00)	-	-

8-1-2 SECS States:

VID	Format	Description	Unit	Limit
100	BOOL	EQUIPMENT LINE SW (0:OFF-LINE 1:ON-LINE)	-	-
101	BOOL	EQUIPMENT CONTROL SW (0:LOCAL 1:REMOTE)	-	-
102	U2	EQUIPMENT STATUS 0:DOWN 1:READY 2:IDLE 3:RUN 4:PAUSE 5:MAINTE 6:READY OFF	-	-

8-1-3 Process Program Change Data:

VID	Format	Description	Unit	Limit
110	U2	RECIPE NO	-	-
111	ASC	RECIPE ID	-	-
112	ASC	COMMENT	-	-

Copyright(c)2007-2015, TOWA Corporation.

8-1-4 Machine Status:

VID	Format	Description	Unit	Limit
1	U2	MACHINE No.	-	-
2	U2	SYSTEM SOFTWARE No.	-	-
3	U2	SYSTEM SOFTWARE Ver.	-	-
4	U2	NUMBER OF HF	-	-
10	BOOL	KEY SW OFF	-	-
11	BOOL	EMERGENCY STOP	-	-
12	BOOL	ERROR(DOWN)	-	-
13	BOOL	ERROR	-	-
14	BOOL	STOP	-	-
15	BOOL	ALARM	-	-
16	BOOL	DRY RUNNING	-	-
17	BOOL	HF AUTO	-	-
18	BOOL	PROCESS AUTO	-	-
19	BOOL	LINE AUTO	-	-
20	BOOL	MAINTENANCE	-	-
21	BOOL	READY ON	-	-
22	BOOL	HOST LOCK	-	-
30	BOOL	STANDBY FRAME LOADING	-	-
31	BOOL	STANDBY TAB LOADING	-	-
32	BOOL	STANDBY LOADING	-	-
33	BOOL	STANDBY UNLOADING	-	-
34	BOOL	STANDBY CLEANER	-	-
35	BOOL	STANDBY 1CYCLE	-	-
45	BOOL	STANDBY LINESTANDBY	-	-
46	BOOL	STANDBY MASTER MODULE	-	-
47	BOOL	STANDBY OUT MODULE	-	-
48	BOOL	STANDBY HF1	-	-
49	BOOL	STANDBY HF2	-	-
50	BOOL	STANDBY HF3	-	-
51	BOOL	STANDBY HF4	-	-
70	BOOL	COVER MASTER MODULE FRONT	-	-
71	BOOL	COVER MASTER MODULE BACK	-	-
72	BOOL	COVER MASTER MODULE LEFT(SUPPLY)	-	-
73	BOOL	COVER MASTER MODULE TAB FRONT LEFT	-	-
74	BOOL	COVER MASTER MODULE TAB FRONT RIGHT	-	-
75	BOOL	COVER MASTER MODULE TAB LEFT FRONT	-	-
76	BOOL	COVER MASTER MODULE TAB LEFT BACK	-	-
77	BOOL	COVER OUT MODULE FRONT	-	-
78	BOOL	COVER OUT MODULE FRONT(SMALL)	-	-
79	BOOL	COVER OUT MODULE BACK	-	-
80	BOOL	COVER OUT MODULE RIGHT FRONT	-	-
81	BOOL	COVER OUT MODULE RIGHT BACK	-	-
82	BOOL	COVER OUT MODULE FRONT	-	-

Copyright(c)2007-2015, TOWA Corporation.

8-1-5 Auto Mode:

VID	Format	Description		Unit	Limit
200	BOOL	AUTO FRAME LOADING	=0:MANUAL =1:AUTO	-	-
201	BOOL	AUTO TAB LOADING		-	-
202	BOOL	AUTO LOADING		-	-
203	BOOL	AUTO UNLOADING		-	-
204	BOOL	AUTO CLEANER		-	-
205	BOOL	AUTO 1CYCLE		-	-
215	BOOL	AUTO LINEAUTO		-	-
216	BOOL	AUTO MASTER MODULE		-	-
217	BOOL	AUTO OUT MODULE		-	-
218	BOOL	AUTO HF1		-	-
219	BOOL	AUTO HF2		-	-
220	BOOL	AUTO HF3		-	-
221	BOOL	AUTO HF4		-	-

Copyright(c)2007-2015, TOWA Corporation.

8-1-6 Workpiece Position (HF1～HF4):

VID				Format	Description		Unit	Limit
HF-1	HF-2	HF-3	HF-4					
580	680	780	880	U2	Frame(L)		-	-
581	681	781	881	U2	Frame(R)		-	-
584	684	784	884	U2	Product(L)		-	-
585	685	785	885	U2	Product(R)	=0:EMPTY	-	-
588	688	788	888	U2	Tab	<>0:EXIST	-	-
589	689	789	889	U2	Cull		-	-
592	692	792	892	U2	Cleaned Die		-	-
594	694	794	894	U2	Cleaned Plunger		-	-

8-1-7 Workpiece Position (Other Module):

VID	Format	Description		Unit	Limit
300	U2	MG CODE IMSL SUPPLY STAGE		-	-
301	U2	MG CODE IMSL ELEVATOR		-	-
302	U2	MG CODE IMSL DISCAHRGE STAGE		-	-
304	U2	MG CODE OMST1 ELEVATOR		-	-
305	U2	MG CODE OMST2 ELEVATOR		-	-
308	U2	MG CODE OMSL SUPPLY STAGE		-	-
309	U2	MG CODE OMSL ELEVATOR		-	-
310	U2	MG CODE OMSL DISCHARGE STARGE		-	-
311	U2	TABLET CODE LOADER		-	-
312	U2	TABLET CODE HOPPER		-	-
313	U2	TABLET CODE PARTS FEEDER		-	-
314	U2	TABLET CODE TAB LINE UP		-	-
315	U2	TABLET CODE TLF TAB CHUTE		-	-
320	U2	FRAME CODE IMSL SUPPLY STAGE		-	-
321	U2	FRAME CODE IMSL ELEVATOR		-	-
322	U2	FRAME CODE IMSL GATE		-	-
323	U2	FRAME CODE GRIP FEEDER		-	-
324	U2	FRAME CODE ALIGNMENT(L)	=0:EMPTY	-	-
325	U2	FRAME CODE ALIGNMENT(R)	<>0:EXIST	-	-
328	U2	FRAME CODE LOADER(L)		-	-
329	U2	FRAME CODE LOADER(R)		-	-
332	U2	PRODUCT CODE UNLOADER(L)		-	-
333	U2	PRODUCT CODE UNLOADER(R)		-	-
336	U2	PRODUCT CODE CARRIER(L)		-	-
337	U2	PRODUCT CODE CARRIER(R)		-	-
340	U2	PRODUCT CODE PPO(L)		-	-
341	U2	PRODUCT CODE PPO(R)		-	-
342	U2	PRODUCT CODE OMST1		-	-
343	U2	PRODUCT CODE OMST2		-	-
346	U2	PRODUCT CODE OMSL RAIL		-	-
347	U2	PRODUCT CODE OMSL ELEVATOR PRESENT STEP		-	-
348	U2	PRODUCT CODE OMSL ELEVATOR		-	-
349	U2	PRODUCT CODE OMSL DISCHARGE STAGE		-	-
354	U2	CULL CODE UNLOADER		-	-
356	U2	CULL CODE PPC		-	-
357	U2	CULL CODE CARRIER		-	-

Copyright(c)2007-2015, TOWA Corporation.

8-1-8 Module Variable Data(HF-1～ HF-4):

VID				Format	Description	Unit	Limit
HF-1	HF-2	HF-3	HF-4				
500	600	700	800	BOOL	USED	-	-
501	601	701	801	BOOL	LINEAUTO USED	-	-
502	602	702	802	BOOL	SERVO	-	-
503	603	703	803	BOOL	HEATER	-	-
506	606	706	806	BOOL	KEEP HEAT	-	-
507	607	707	807	BOOL	ILLUMINATION	-	-
508	608	708	808	BOOL	CHASE CHANGE	-	-
510	610	710	810	BOOL	CLEANING(NORMAL)	-	-
511	611	711	811	BOOL	CLEANING(DUMMY)	-	-
512	612	712	812	BOOL	CLEANING(CONDITION)	-	-
514	614	714	814	BOOL	COVER(F)	-	-
515	615	715	815	BOOL	COVER(B)	-	-
520	620	720	820	U4	Counter MONITOR 01 POWER ON TIME	hours	Yes
521	621	721	821	U4	Counter MONITOR 02 READY ON TIME	hours	Yes
522	622	722	822	U4	Counter MONITOR 03 SERVO ON TIME	hours	Yes
523	623	723	823	U4	Counter MONITOR 04 HEATER ON TIME	hours	Yes
524	624	724	824	U4	Counter MONITOR 05 Plunger Cleaning		
525	625	725	825	U4	Counter MONITOR 06 Pot&Plunger		
526	626	726	826	U4	Counter MONITOR 07		
527	627	727	827	U4	Counter MONITOR 08		
528	628	728	828	U4	Counter MONITOR 09		
529	629	729	829	U4	Counter MONITOR 10		
530	630	730	830	U4	Counter MONITOR 11		
531	631	731	831	U4	Counter MONITOR 12		
532	632	732	832	U4	Counter MONITOR 13		
533	633	733	833	U4	SHOT COUNT 1	shots	Yes
534	634	734	834	U4	SHOT COUNT 2	shots	Yes
535	635	735	835	U4	SHOT COUNT 3	shots	Yes
540	640	740	840	F4	CHASE TEMPERATURE U (PAR)	deg	
541	641	741	841	F4	CHASE TEMPERATURE D (PAR)	deg	
550	650	750	850	U4	INDEX TIME	Sec	
551	651	751	851	U4	MACHINE TIME	Sec	
552	652	752	852	U4	CURE TIME (SET)	Sec	
553	653	753	853	U4	CURE TIME (MON)	Sec	
554	654	754	854	U4	INJECTION TIME	Sec	
555	655	755	855	U4	PH TOTAL TIME	Sec	

Copyright(c)2007-2015, TOWA Corporation.

8-1-9 Module Variable Data(Other Module):

VID	Format	Description	Unit	Limit
400	U4	Counter MONITOR 01 POWER ON TIME	hours	Yes
401	U4	Counter MONITOR 02 READY ON TIME	hours	Yes
402	U4	Counter MONITOR 03 SERVO ON TIME	hours	Yes
403	U4	Counter MONITOR 04 LOADER PREHEATER ON TIME	hours	Yes
404	U4	Counter MONITOR 05 NG TAB BOX (TAB FEEDER)	-	-
405	U4	Counter MONITOR 06	-	-
406	U4	Counter MONITOR 07	-	-
407	U4	Counter MONITOR 08	-	-
408	U4	Counter MONITOR 09	-	-
409	U4	Counter MONITOR 10	-	-
410	U4	Counter MONITOR 11	-	-
411	U4	Counter MONITOR 12	-	-
412	U4	Counter MONITOR 13	-	-
413	U4	Counter MONITOR 14	-	-
414	U4	Counter MONITOR 15	-	-
415	U4	Counter MONITOR 16	-	-

8-2. Equipment Alarm List

ALID	CODE	ON-CEID	OFF-CEID
1XXYYZZ	Machine Alarm Code (AXX-YY-ZZ)	10000+XXYY	10000+XXYY
2UUSSNN	Machine Error Code (EUU-SS-NN)	20000+UUSS	20000+UUSS

Copyright(c)2007-2015, TOWA Corporation.

8-3. Collected Event Lists

8-3-1 SECS State Change Events:

CEID	DESCRIPTION
50	EQUIPMENT LINE MODE SWITCH ONLINE
51	EQUIPMENT LINE MODE SWITCH OFFLINE
52	EQUIPMENT CONTROL MODE REMOTE
53	EQUIPMENT CONTROL MODE LOCAL

8-3-2 Equipment Mode Change Events(Switch):

ON-CEID	OFF-CEID	DESCRIPTION
1	2	KEY SW OFF
3	4	EMERGENCY STOP
5	6	ERROR(DOWN)
7	8	ERROR
9	10	STOP
11	12	ALARM
13	14	DRY RUNNING
15	16	HF AUTO
17	18	PROCESS AUTO
19	20	LINE AUTO
21	22	MAINTENANCE
23	24	READY ON
25	26	HOST LOCK

8-3-3 Equipment Mode Change Events(Auto Mode):

ON-CEID	OFF-CEID	DESCRIPTION
200	201	AUTO FRAME LOADING
202	203	AUTO TAB LOADING
204	205	AUTO LOADING
206	207	AUTO UNLOADING
208	209	AUTO CLEANER
210	211	AUTO 1CYCLE
222	223	AUTO LINEAUTO
224	225	AUTO MASTER MODULE
226	227	AUTO OUT MODULE
228	229	AUTO HF1
230	231	AUTO HF2
232	233	AUTO HF3
234	235	AUTO HF4
250	251	STANDBY FRAME LOADING
252	253	STANDBY TAB LOADING
254	255	STANDBY LOADING
256	257	STANDBY UNLOADING
258	259	STANDBY CLEANER
260	261	STANDBY 1CYCLE
270	271	STANDBY LINESTANDBY
272	273	STANDBY MASTER MODULE
274	275	STANDBY OUT MODULE
276	277	STANDBY HF1
278	279	STANDBY HF2
280	281	STANDBY HF3
282	283	STANDBY HF4

Copyright(c)2007-2015, TOWA Corporation.

8-3-4 Equipment Mode Change Events(Primary HF1～HF4):

CEID(HF Module)								Description
HF-1		HF-2		HF-3		HF-4		
ON	OFF	ON	OFF	ON	OFF	ON	OFF	
500	501	600	601	700	701	800	801	USED
502	503	602	603	702	703	802	803	LINEAUTO USED
504	505	604	605	704	705	804	805	SERVO
506	507	606	607	706	707	806	807	HEATER
512	513	612	613	712	713	812	813	KEEP HEAT
514	515	614	615	714	715	814	815	ILLUMINATION
516	517	616	617	716	717	816	817	CHASE CHANGE
520	521	620	621	720	721	820	821	CLEANING(NORMAL)
522	523	622	623	722	723	822	823	CLEANING(DUMMY)
524	525	624	625	724	725	824	825	CLEANING(CONDITION)
528	529	628	629	728	729	828	829	COVER(F)
530	531	630	631	730	731	830	831	COVER(B)

8-3-5 Equipment Mode Change Events(Primary Other Module):

ON-CEID	OFF-CEID	DESCRIPTION
400	401	SERVO
402	403	BUZZER
404	405	ILLMINATE
408	409	PREHEATER
418	419	TAB DISCHARGE
420	421	TAB TEST
424	425	ALL INITIALIZE
426	427	KIT CHANGE MODE
430	431	DRYRUNNING MODE

8-3-6 Shot Count Events:

CEID	DESCRIPTION
30	HF1 SHOT END
31	HF2 SHOT END
32	HF3 SHOT END
33	HF4 SHOT END

Copyright(c)2007-2015, TOWA Corporation.

8-3-7 Variable Data Limit Events(HF1～HF4):

CEID(HF Module)				Description	Min. (Default)	Max. (Default)
HF-1	HF-2	HF-3	HF-4			
1500	1600	1700	1800	Counter MONITOR 01 POWER ON TIME	0	99999999
1501	1601	1701	1801	Counter MONITOR 02 READY ON TIME	0	99999999
1502	1602	1702	1802	Counter MONITOR 03 SERVO ON TIME	0	99999999
1503	1603	1703	1803	Counter MONITOR 04 HEATER ON TIME	0	99999999
1504	1604	1704	1804	Counter MONITOR 05 Plunger Cleaning	0	99999999
1505	1605	1705	1805	Counter MONITOR 06 Pot&Plunger	0	99999999
1506	1606	1706	1806	Counter MONITOR 07	0	99999999
1507	1607	1707	1807	Counter MONITOR 08	0	99999999
1508	1608	1708	1808	Counter MONITOR 09	0	99999999
1509	1609	1709	1809	Counter MONITOR 10	0	99999999
1510	1610	1710	1810	Counter MONITOR 11	0	99999999
1511	1611	1711	1811	Counter MONITOR 12	0	99999999
1512	1612	1712	1812	Counter MONITOR 13	0	99999999
1513	1613	1713	1813	Counter MONITOR 14 SHOT COUNT 1	0	99999999
1514	1614	1714	1814	Counter MONITOR 15 SHOT COUNT 2	0	99999999
1515	1615	1715	1815	Counter MONITOR 16 SHOT COUNT 3	0	99999999

8-3-8 Variable Data Limit Events(Master Module):

CEID	Description	Min.	Max.
1000	Counter MONITOR 01 POWER ON TIME	0	99999999
1001	Counter MONITOR 02 READY ON TIME	0	99999999
1002	Counter MONITOR 03 SERVO ON TIME	0	99999999
1003	Counter MONITOR 04 LOADER PREHEATER ON TIME	0	99999999
1004	Counter MONITOR 05 NG TAB BOX (TAB FEEDER)	0	99999999
1005	Counter MONITOR 06	0	99999999
1006	Counter MONITOR 07	0	99999999
1007	Counter MONITOR 08	0	99999999
1008	Counter MONITOR 09	0	99999999
1009	Counter MONITOR 10	0	99999999
1010	Counter MONITOR 11	0	99999999
1011	Counter MONITOR 12	0	99999999
1012	Counter MONITOR 13	0	99999999
1013	Counter MONITOR 14	0	99999999
1014	Counter MONITOR 15	0	99999999
1015	Counter MONITOR 16	0	99999999

Copyright(c)2007-2015, TOWA Corporation.

8-3-9 Material Movement Events(HF1～HF4):

CEID(HF Module)								Description
HF-1		HF-2		HF-3		HF-4		
ON	OFF	ON	OFF	ON	OFF	ON	OFF	
560	561	660	661	760	761	860	861	Frame(L)
562	563	662	663	762	763	862	863	Frame(R)
568	569	668	669	768	769	868	869	Product(L)
570	571	670	671	770	771	870	871	Product(R)
576	577	676	677	776	777	876	877	Tab
578	579	678	679	778	779	878	879	Cull
584	585	684	685	784	785	884	885	Cleaned Die
588	589	688	689	788	789	888	889	Cleaned Plunger

8-3-10 Material Movement Events(Master Module):

ON-CEID	OFF-CEID	DESCRIPTION
1100	1101	MG CODE IMSL SUPPLY STAGE
1102	1103	MG CODE IMSL ELEVATOR
1104	1105	MG CODE IMSL DISCAHRGE STAGE
1108	1109	MG CODE OMST1 ELEVATOR
1110	1111	MG CODE OMST2 ELEVATOR
1116	1117	MG CODE OMSL SUPPLY STAGE
1118	1119	MG CODE OMSL ELEVATOR
1120	1121	MG CODE OMSL DISCHARGE STARGE
1122	1123	TABLET CODE LOADER
1124	1125	TABLET CODE HOPPER
1126	1127	TABLET CODE PARTS FEEDER
1128	1129	TABLET CODE TAB LINE UP
1130	1131	TABLET CODE TLF TAB CHUTE
1200	1201	FRAME CODE IMSL SUPPLY STAGE
1202	1203	FRAME CODE IMSL ELEVATOR
1204	1205	FRAME CODE IMSL GATE
1206	1207	FRAME CODE GRIP FEEDER
1208	1209	FRAME CODE ALIGNMENT(L)
1210	1211	FRAME CODE ALIGNMENT(R)
1216	1217	FRAME CODE LOADER(L)
1218	1219	FRAME CODE LOADER(R)
1224	1225	PRODUCT CODE UNLOADER(L)
1226	1227	PRODUCT CODE UNLOADER(R)
1232	1233	PRODUCT CODE CARRIER(L)
1234	1235	PRODUCT CODE CARRIER(R)
1300	1301	PRODUCT CODE PPO(L)
1302	1303	PRODUCT CODE PPO(R)
1304	1305	PRODUCT CODE OMST1
1306	1307	PRODUCT CODE OMST2
1312	1313	PRODUCT CODE OMSL RAIL
1314	1315	PRODUCT CODE OMSL ELEVATOR PRESENT STEP
1316	1317	PRODUCT CODE OMSL ELEVATOR
1318	1319	PRODUCT CODE OMSL DISCHARGE STAGE
1328	1329	CULL CODE UNLOADER
1332	1333	CULL CODE PPC
1334	1335	CULL CODE CARRIER

Copyright(c)2007-2015, TOWA Corporation.

8-4. Host Command ID Lists

8-4-1 Remote Commands:

RMCD	Description	CPNAME
PP-SELECT	Process Program Select Command	PPID
STOP	Stop Command	
ABORT	Abort Command	
RELEASE	Operator Start Release Command	
LOCK	Operator Start Lock Command	

8-4-2 Command Parameters:

CPNAMD	Format	Description
PPID	ASC	Process Program ID (30bytes)

8-5. Equipment Constant

ECID	Format	CHG-CEID	Description	Min	Max	Default
5000	U4	15000	MAX SPOOL TRANSMIT	0	100	5
5001	U2	15001	MULTI BLOCK INQUIRE TIME	0	9999	10
5002	U2	15002	OVER WRITE SPOOL	0	1	0

※This ID is saved for the compatibility of a old version. It does not function by the current system.

8-6. EQUIPMENT TERMINAL ID

TID	Description
1	EQUIPMENT DISPLAY

Copyright(c)2007-2015, TOWA Corporation.

8-7. EQUIPMENT MODEL TYPE

MDLN:YPM001

8-8. SOFTWARE REVISION CODE

SOFTREV:4.0000

8-9. SPOOLING CONDITION

Over write spool is false.

8-10. TRACE CONDITION

5 CONCURRENT TRACES

Copyright(c)2007-2015, TOWA Corporation.

9. Appendix

9-1. Range allowed and resolution for each parameter

Parameter Name	Value Range	Resolution	Default	Description
T3 Reply Timeout	1 - 120 seconds	1 second	45 seconds	Reply timeout. Specifies maximum amount of time an entity expecting a reply message will wait for that reply.
T5 Connect Separation Timeout	1 - 240 seconds	1 second	10 seconds	Connection Separation Timeout. Specifies the amount of time which must elapse between successive attempts to connect to a given remote entity.
T6 Control Transaction Timeout	1 - 240 seconds	1 second	5 seconds	Control Transaction Timeout. Specifies the time which a control transaction may remain open before it is considered a communications failure.
T7 NOT SELECTED Timeout	1 - 240 seconds	1 second	10 seconds	Time which a TCP/IP connection can remain in NOT SELECTED state (i.e., no HSMS activity) before it is considered a communications failure.
T8 Network Character Timeout	1 - 120 seconds	1 second	5 seconds	Maximum time between successive bytes of a single HSMS message which may expire before it is considered a communications failure.
Connect Mode	PASSIVE, ACTIVE	-	-	Connect Mode. Specifies the logic this local entity will use during HSMS connection establishment.
Local Entity IP Address and Port number	determined by TCP/IP conventions	-	-	Required for any entity operating in PASSIVE mode. Determines the address on which the local entity will listen for incoming connection requests.
Remote Entity IP Address and Port Number	determined by TCP/IP conventions	-	-	Required for any entity operating in ACTIVE mode. Determines the address of the remote entity to which the local entity will attempt to connect.

Copyright(c)2007-2015, TOWA Corporation.