MCU can power the V BACKup of the GNSS module or it can be always on by connecting thru R1. V Bakcup 6 uA it keeps in the GNSS module the previous location

