PLAY/STOP [1]
VOL-UP [1]
VOL-DOWN [1]
PLAY/STOP [2]
VOL-UP [2]
VOL-DOWN [2]
DC INPUT
RESET
BOOT0
BOOT1
PROGRAMMING
LED1
PLAY/STOP [3]
VOL-UP [3]
VOL-DOWN [3]
PLAY/STOP [4]
VOL-UP [4]
VOL-DOWN [4]
SPDIF OUT1
SPDIF OUT2
SPDIF OUT3
SPDIF OUT4
SDPIF IN

