MSM Device Configuration Procedures

OTA

- For OTA, the device has to be connected to SFTP, so follow the SFTP procedure if not done already.
- First, check for any updates by pressing the Check Updates button on the OTA screen available in Factory Settings / System.
- Select an MSM application version you want to update the device to from a drop-down menu.
- Once you select your desired version, press Start OTA. The device will start the OTA from there and will reboot on successful OTA.
- You can verify the version of the OTA from the bottom right of the screen.

Device Provisioning (MQTTs)

- On a fresh device
    - Set MQTTS_ENDPOINT and MQTTS_INTERVAL, then press Save.
    - Next, press the Fetch Claim button and wait for a success notification.
    - If Fetch Claim is successful (CA1 cert, Claim cert, Claim key all get ticked), then press Provision and wait for a success notification.
    - The Device Certificate and Device Key boxes will show check marks indicating successful provisioning.
- On a provisioned device
    - Most probably, MQTTS_ENDPOINT and MQTTS_INTERVAL will be set already. If not, do so, or edit the endpoint to the desired AWS MQTTs server.
    - Press Fetch Claim to get the latest Claim certs, and wait for a success notification.
    - Press Provision and wait for success.
    - The device will be provisioned with the latest Claim certs.

SFTP

- SFTP configuration requires SFTP_IP, SFTP_USER, SFTP_PASSWORD, INTERVAL, and SCHEDULE. Populate them accordingly.
- Press Save and SFTP will be configured.

MQTT

- MQTT configuration requires MQTT_ENDPOINT, MQTT_USERNAME, MQTT_PASSWORD, and INTERVAL. Populate them accordingly.
- Press Save and MQTT will be configured, followed by a confirmation notification if fields are valid.

NTP

- NTP configuration comes pre-configured with default NTP servers.
- You can modify them with your own desired ones by entering them and then pressing Save.

Factory Reset

- Take an empty usb drive and copy the reboot named file inside it.
- Once copied, eject the drive and insert it in the MSM device.
- The MSM device will reboot itself. One the reboot screen appears, remove the usb drive from the device.
- Once rebooted, the device will ask you for the UID and Password which indicates that the device has been factory reset successfully.

USB Export

- After inserting USB, USB export Pop Up will show, only if you are logged in, else it will show Login Prompt. If it still does not show the USB export Pop up, you can manually activate it using the Export Button available in either of the settings (factory/System or Admin).
- After the USB Export Popup select the timeline for the date you require.
- User can Select wither from the pre define radio buttons or enter custom interval in days.
- Press Load after selecting interval, which will load the data in the USB.
- You can now eject the USB.