GRIPPATANK B2B CHARGER - WIRING DIAGRAM

12 Volt to 12 Volt Battery Converter / Charger, 25 Amp

INSTRUCTIONS FOR USE

GENERAL

This unit is a switching type voltage converter / Charger intended for use on vehicles with a 12V electrical system to charge nominal 12V battery packs. The unit has been designed with features to ensure trouble free operation with STOP START technology vehicles.The unit can deliver 25A continuous and 30A intermittent charging currents. The unit has output overload and over temperature protection with a fully automatic reset. The 12V input and 12V outputs share a common negative. The switching converter provides a low noise output closely regulated against variation of input voltage and changes in output load current and completely software controlled to optimise the battery charging cycle. The charging cycle is optimised for a Gel Battery but can easily be reprogrammed to fit any other batteries or to a customer specification. The metal case is fuly isolated from the working parts and it should be grounded to the vehicle meltal work, a small area of the anodised finish may be removed around a fixing hole to facilitate this. The installation should be carried out by a competent auto electrican.

SPECIFICATION

Input:	Nominal 12 volts
Output	Nominal 12 volts
Current	Maximum continuous current of 25 amps

LED STATUS INDICATOR

Battery Charger delivering maximum power to the battery LED RED ON (Constant Current Mode).
Battery charging battery at 14.1V LED AMBER ON (Boost/Bulk Charge Mode).
Battery charged LED GREEN (Battery charged / Float charging at 13.8V).

MOUNTING

This unit may be mounted in any position subject to unrestricted free air ventalation. The cooling of the unit wil be aided by mounting in contact with the metal structure of thevehicle. DO NOT fit near heat sources such as exhaust or heater pipes. Do not fit near heat sensitive material or components such as other electronic units, wiring or plastic parts, this unit may reach temperatures of up to 75 C.

Warning! sustained overload or overheating will result in automatic shutdown of the electonics to protect itself. The overload must be removed to restore normal operation.

CONNECTIONS

Additional wiring should be at least 28/0.30 mm conductor cable or larger for runs over 6sq mm.

Black:	Common Output 12 volts negative (-)
Red:	Input 12 volts positive (+)
Purple:	Output 12 volts posititve (+)
Yellow:	Vin Remote

Warning! Fit 40A Fuses in INPUT & OUTPUT, To protect Vehicle Wiring
Fit 1A Fuse in VIN Remote, To protect Vehicle Wiring

Finally, double check that the connections are correct. Incorrect connections can destroythe unit.
DO NOT fit higher rated fuses.