Set Up - Tank Filling

To start filling the tank simply press the 'FILL'. This will activate the pump and the solenoid valve, allowing water to fill the tank, until the float switch detects that the tank is full.

FILL

FILL

While the pump and solenoid valve are on and the tank is filling, the display will flash the message FILL. Whilst FILL is active the unit will keep filling every time the level switch drops, hence maintaining the correct level.

FILL

To manually stop the tank filling, press the 'FILL' button again. The display will stop showing the FIL message and display message STOP.

FILL

STOP

To manually turn the pump on (over riding the FILL operation) press the PUMP button. The display will change to ON.

PUMP

ON

To manually turn the pump off (over riding the FILL operation) press the PUMP button. The display will change to OFF.

PUMP

OFF

Additional Wiring

Wire the solenoid valve and float switch following this diagram. Use only the wires shown.

