

软件环境: RVDS2.2+JLINK 4.12 驱动


硬件环境: OK6410+JLINK V8

安装好 RVDS2.2











编译 LED 程序 OK



注: 6410 的 RAM 是从: 0x5000000 开始的



然后安装 JLINK 驱动。



把开发板与仿真器相连, 并上电。


可以检测到内核。


```
SEGGER J-Link Commander U4.12 ('?' for help)
Compiled Feb 26 2010 19:23:14
DLL version U4.12, compiled Feb 26 2010 19:22:53
Firmware: J-Link ARM U8 compiled May 20 2010 17:07:46
Hardware: U8.00
S/N: 15.0 206
Feature(s): RDI,FlashDL,FlashBP,JFlash,GDBFull
Info: TotalIRLen = 9, IRPrint = 0x0011
UTarget = 3.300U
Found 2 JTAG devices, Total IRLen = 5:
#0 1d: 0x28900F0F, IRLen: 04, IRPrint: 0x0, ARM ETB
#1 1d: 0x28900F0F, IRLen: 05, IRPrint: 0x1, ARM1176 Core
ARM11 identified.
JTAG speed: 1000 kHz
J-Link>
```

然后把 JLINKARM.dll 复制到: RVDS2。2 的安装目录中。


 $D:\ Program \ Files\ ARM\ RDI\ AXD\ 1.3.1\ 98\ win_32-pentium$

运行 AXD







选中 RDI









如果没有 U BOOT,则要自行写初始化脚本







装载程序:

