Counter	MD AC	MQ	
10000	0000010100001001 0		
10000			1000011001100110Step 1
10000	0000010100001001	000000000000000000000000000000000000000	0100001100110011 -Step 2
01111			0100001100110011 Step 1
01111	0000010100001001 0	0000001010000100	1010000110011001 Step 2
01110			1010000110011001Step 1
01110	0000010100001001	0000001111000110	1101000011001100 Step 2
01101			1101000011001100Step 1
01101	0000010100001001	0000000111100011	0110100001100110Step 2
01100	0000010100001001	0000000111100011	0110100001100110Step 1
01100	0000010100001001	0000000011110001	1011010000110011 Step 2
01011	0000010100001001	0000010111111010	1011010000110011Step 1
01011	0000010100001001 0	0000001011111101	0101101000011001 Step 2
01010	0000010100001001	0000100000000110	0101101000011001Step 1
01010	0000010100001001	0000010000000011	0010110100001100 Step 2
01001			0010110100001100Step 1
01001	0000010100001001 0	0000001000000001	1001011010000110 Step 2
01000	0000010100001001 0	0000001000000001	1001011010000110Step 1
01000	0000010100001001 0	0000000100000000	1100101101000011 Step 2
00111			1100101101000011Step 1
00111			1110010110100001 Step 2
00110			1110010110100001Step 1
00110	0000010100001001 0	0000010000000110	1111001011010000 Step 2
00101			1111001011010000Step 1
00101	0000010100001001 0	0000001000000011	0111100101101000 Step 2
00100			0111100101101000Step 1
00100	0000010100001001 0	0000000100000001	1011110010110100 Step 2
00011			1011110010110100 Step 1
00011	0000010100001001 0	0000000010000000	1101111001011010 Step 2
00010			1101111001011010Step 1
00010	0000010100001001 0	0000000001000000	0110111100101101 Step 2
00001			0110111100101101Step 1
00001	0000010100001001 0	0000001010100100	1011011110010110Step 2

Counter	MD	AC	MQ			
10000	1000011001	100110	00000000	0000000	0000010100001001	
10000					0000010100001001Ste	
10000	1000011001	100110	010000110	00110011	0000001010000100Ste	∌p 2
01111					0000001010000100Ste	
01111	1000011001	100110	00100001	10011001	1000000101000010Ste	₽ 2
01110					1000000101000010 -Ste	
01110					1100000010100001Ste	•
01101					1100000010100001 Ste	
01101					0110000001010000Ste	•
01100					0110000001010000 -Ste	
01100					1011000000101000Ste	•
01011					1011000000101000 -Ste	
01011					0101100000010100Ste	
01010					0101100000010100 -Ste	
01010					0010110000001010 Ste	
01001					0010110000001010Ste	
01001					1001011000000101Ste	-
01000					1001011000000101 Ste	
01000					1100101100000010Ste	
00111					1100101100000010 -Ste	
00111					1110010110000001Ste	•
00110					1110010110000001 -Ste	
00110					1111001011000000Ste	•
00101					1111001011000000 -Ste	
00101					0111100101100000Ste	•
00100					0111100101100000 -Ste	•
00100					1011110010110000 -Ste	•
00011					1011110010110000 -Ste	
00011					1101111001011000 -Ste	•
00010					1101111001011000 -Ste	
00010					0110111100101100 -Ste	
00001					0110111100101100 -Ste	
00001	1000011001	100110	00000010	10100100	10110111110010110 -Ste	p 2

Counter	MD	AC	MQ			
10000					000000100100100	
10000					000000100100100	
10000	000000011	1001100	00000000	1100110	000000010010010	00Step 2
01111					000000010010010	
01111	000000011	1001100	000000000	0110011	00000001001001	10Step 2
01110					00000001001001	
01110					10000000100100	•
01101					10000000100100	
01101					110000000010010	•
01100					11000000010010	
01100					011000000001001	•
01011					01100000001001	
01011					101100000000100	•
01010					101100000000100	
01010					010110000000010	•
01001					010110000000010	
01001					001011000000001	•
01000					001011000000001	
01000					000101100000000	•
00111					000101100000000	
00111					100010110000000	•
00110					100010110000000	
00110					010001011000000	•
00101					010001011000000	
00101					001000101100000	•
00100					001000101100000	•
00100					100100010110000	•
00011					100100010110000	
00011					010010001011000	•
00010					010010001011000	
00010					101001000101100	•
00001					101001000101100	
00001	0000000011	1001100	000000000	0000001	110100100010110	00Step 2

Counter	MD A	С	MQ			
10000	000000100100	1001	0000000000	000000	00000001100	1100
10000					00000001100	
10000	000000100100	1001	0000000000	0000000	00000000110	0110Step 2
01111					00000000110	
01111	000000100100	1001 (0000000000	000000	00000000011	0011Step 2
01110					00000000011	
01110					100000000001	•
01101					10000000001	
01101					110000000000	•
01100					11000000000	
01100					011000000000	•
01011					01100000000	
01011					101100000000	•
01010					101100000000	
01010					010110000000	•
01001					010110000000	
01001					001011000000	•
01000					001011000000	
01000					000101100000	•
00111					000101100000	
00111					100010110000	•
00110					100010110000	
00110					010001011000	·
00101					010001011000	
00101					001000101100	•
00100					001000101100	•
00100					100100010110	•
00011					100100010110	
00011					010010001011	•
00010					010010001011	
00010					101001000101	•
00001					101001000101	
00001	000000100100	1001	0000000000	0000001	110100100010	1100Step 2