
xD2000 Parameter Settings for Compressor

1.) Access All Parameters:

Press **Home** button and Go to **My preferences Menu (nyp)**
Go to- **Access level (LAC)** and Select **Expert (EPr)**

2.) Set Motor Parameters and Acc/Dec :

Press **Home** Button and Go to **Simply Start (Sys)** -> **Simply Start**
Set below parameters:

Acceleration (ACC)	: 10 Sec
Deceleration (dEC)	: 10 Sec
Low Speed (LSP)	: 0Hz
High Speed (HSP)	: 50Hz

Press **Home** Button and Go to **Complete settings (CSt-)**
Go to - **Motor parameters (MPA-)** and set below parameters

Motor Standard-	: 50Hz
Nominal motor Power-	: As per Motor Name plate
Nom Motor Voltage-	: As per Motor Name plate
Nom Motor Current-	: As per Motor Name plate
Nominal Motor Freq-	: 50Hz
Nominal Motor Speed-	: As per Motor Name plate
Max Frequency-	: 60Hz
Motor Control Type-	: U/F VC Standard (Std)

Press **ESC** Button and Go to **Complete settings > Command and Reference**
set below parameters

Stop Key Enable-	: Stop Key Priority All (ALL)
-------------------------	-------------------------------

3.) PID controller settings

Press **Home** Button & go to **Complete settings -> Generic functions -> PID controller**

Go to **Feedback >>**

Type of Control	: PRESSURE
PID feedback Assign	: AI-1 (Pressure Feedback from field- 4-20mA)
AI1 Type	: Current
AI1 min value	: 4mA
AI1 max value	: 20mA
Min PID feedback-	: 0 bar (As per Pressure transmitter range)
Max PID feedback-	: 10 bar (As per Pressure transmitter range)
Min Fbk Warning-	: 0
Max Fbk Warning-	: Keep it higher than "Max PID feedback"

ESC and Go to **PID Reference -**

Internal PID Reference	: Yes
Min PID Process	: 0 (As per requirement, min setpoint pressure)



Max PID Process
Internal PID ref

: 10 Bar (As per requirement, max limit for setpoint pressure)
: Enter / Set the required pressure reference

Esc & Goto **Settings-**

PID ramp : 5 Sec
PID Min Output : 0 Hz
PID Max Output : 50 Hz

4.) Relay Output configuration

Press **Home** Button and Go to **Complete settings -> Input/Output ->**

R1 configuration -> R1 Assignment : Select **Operating State Fault**

R2 configuration -> R2 Assignment : Select **Device Running**

