

SECTION 1

GENERAL

1.1 GENERAL

This manual contains the information necessary for safe and efficient operation of the BO-105 helicopter.

The user is assumed to have flying experience, therefore elementary instructions and basic principles have been omitted.

1.2 ORGANIZATION OF THE MANUAL

This flight manual is largely organized in the standardized format recommended by the Helicopter Association International.

It is divided into an **approved part** consisting of sections 1 thru 5, 10 and 11, and into a **non-approved part** consisting of sections 6 thru 9 and 12.

1.2.1 Approved Data

This manual meets all certificating authority requirements for approved data.

1.2.2 Description of the Sections

The sections of the manual are fairly independent with each section beginning with its own table of contents.

Approved Part

SECTION 1 GENERAL

presents information of general interest to the pilot, basic helicopter data and conversion tables. In addition it provides definitions and explanations of symbols, abbreviations, and terminology used in the manual.

SECTION 2 LIMITATIONS

contains those limitations required by regulation or necessary for safe operation of the helicopter and approved by the regulatory authority.

SECTION 3 EMERGENCY AND MALFUNCTION PROCEDURES

contains the recommended procedures for coping with various types of emergencies, malfunctions or critical situations.

SECTION 4 NORMAL PROCEDURES

contains the recommended procedures for normal ground and air operation of the helicopter.

SECTION 5 PERFORMANCE DATA

contains airworthiness and performance information necessary for preflight and inflight mission planning.

SECTION 10 OPTIONAL EQUIPMENT

contains Flight Manual Supplements (FMS) providing operating instructions of approved optional equipment.

SECTION 11 SPECIAL OPERATIONS

contains Flight Manual Supplements (FMS) with instructions for special operations (e.g. IFR, operation with opened doors, etc.).

Non-approved Part**SECTION 6 MASS AND BALANCE**

contains the definitions for various mass and balance locations and the procedure for the determination of the center of gravity.

Appended to this section are the **Mass and Balance Record** form for maintaining a continuous record of changes in structure and equipment affecting the mass and balance, and the **Equipment List** form for the listing of optional equipment with data necessary for mass and balance computations.

SECTION 7 SYSTEM DESCRIPTION

contains a brief description of the helicopter, its systems and the various standard equipment with information considered most important to the flight crew.

SECTION 8 HANDLING, SERVICING, AND MAINTENANCE

contains servicing data, cleaning and care procedures as well as information for ground handling.

SECTION 9 OPERATIONAL INFORMATION

contains information for flight planning such as fuel consumption and max cruising speed diagrams.

SECTION 12 APPENDIX

contains Flight Manual Appendices (FMA) for non-approved optional equipment and special operations.

1.2.3 Page Numbering

The numbering of pages within each section consists of the section number or designation, a dash and the consecutive number of the page beginning with "1"; e.g. for Section 3: 3 - 1, 3 - 2, etc.

Figures are likewise numbered consecutively by section, such as Fig. 3-1, Fig. 3-2, etc.

Exceptions:

- The numbering of the **Table of Contents** pages preceding each section in this manual consists of the section number, a dash and the consecutive Roman numeral (lower case) of the page, beginning with "i"; e.g. for Section 3: 3 - i, 3 - ii, etc.
- The page numbers of the flight manual supplements and appendices consist of the section number, a dash, the number of the supplement/appendix, a dash and the consecutive number of the page; e.g. 10 - 17 - 1, 10 - 17 - 2, etc.
- Figures within a flight manual supplement/appendix are numbered consecutively, such as Fig. 1, Fig. 2, etc.

The numbers of blank reversed pages are printed on the preceding page by using dual page numbering; e.g. 3 - 9/(3 - 10 blank).

If, at a later date, pages have to be added to the initial printing, the new pages may carry the number of the preceding page plus a letter suffix; e.g. 2 - 6A, 2 - 6B, etc.

1.2.4 **Flight Manual Supplements (FMS)**

Each FMS is self-contained and corresponds in its general arrangement to the basic flight manual, but only additional information or different data will be the subject of an FMS.

Each FMS, although complete in nature, shall therefore be used in conjunction with the basic flight manual.

A Log of Supplements is provided for each applicable section as an index listing the current supplements.

The manufacturer retains the right to convert optional equipment to standard equipment at any time as a product improvement program. FLM coverage of the converted optional equipment, however, will remain as an FMS in Section 10 and also as an optional equipment item entry in the Equipment List. An entry in the STD EQPT EFFECTIVITY column of the Log of Supplements is used to indicate the converted optional equipment by providing an effectivity statement of the affected helicopters.

1.2.5 **Flight Manual Appendices (FMA)**

Each FMA is self-contained and corresponds in its general arrangement to the basic flight manual, but only additional information or different data will be the subject of an FMA.

Each FMA, although complete in nature, shall therefore be used in conjunction with the approved flight manual.

When two or more appendices are issued, a Log of Appendices will be provided as an index listing the current appendices.