

3. EMERGENCY AND MALFUNCTION PROCEDURES

3.1 CAUTION LIGHT INDICATIONS

CAUTION LIGHT INDICATIONS

HOOK

EFFECTIVITY Hook Assembly P/N 105-80332

Conditions/Indications

Hook is "open"

- **HOOK** caution light on

- NOTE**
- During external cargo operations, the **HOOK** caution light comes on after releasing a load to remind the pilot of a trailing hook assembly with its reduced airspeed requirement.
 - The **HOOK** caution light will go off when the hook is closed or retracted.

Procedure

CAUTION **HOOK** CAUTION LIGHT GOING OFF ONLY INDICATES THAT THE HOOK IS CLOSED OR RETRACTED. THE 60-KIAS LIMIT REMAINS IN EFFECT UNLESS THE HOOK ASSEMBLY IS PROPERLY SECURED TO ITS RETAINER (STOWED) OR VERIFIED RETRACTED.

Airspeed – Max 60 KIAS

EFFECTIVITY Hook Assemblies P/N 105-80337 and 117-80127

Conditions/Indications

Hook assembly is unloaded and trailing (not stowed or retracted)

- **HOOK** caution light on

- NOTE**
- During external cargo operations, the **HOOK** caution light comes on after releasing a load to remind the pilot of a trailing hook assembly with its reduced airspeed requirement.
 - The **HOOK** caution light must go off when:
 - a load is attached to and hanging from the hook assembly, or
 - the hook assembly is properly stowed or retracted.

Procedure

Airspeed – Max 60 KIAS

EFFECTIVITY ALL