

1.3 EFFECTIVITY STATEMENTS

1.3.1 Definition of Effectivity Identification

The contents of this manual applies to all the BO-105 helicopter model variants listed on the title page and defined in this section. However, certain portions of the manual may apply to only specific models, variants, serial numbered helicopters, etc. Therefore, an effectivity identification system is used to indicate where differences brought about by helicopter modifications, Service Bulletins, customer options, variations of the basic model helicopter, etc. occur within the manual.

This system comprises effectivity statements, identified by the word **EFFECTIVITY** followed by the definition of applicability. The applicability may be defined using:

- a specified model or variant type,
- an eight-digit numeric indicator,
- a Service Bulletin (SB) modification number, and/or
- a clear text definition.

The eight-digit numeric indicator begins with the four digits of the lowest assigned manufacturer's serial number, to indicate first effectivity, and ends with the four digits of the highest assigned manufacturer's serial number, to indicate last effectivity, of an unbroken sequence of assigned serial numbered helicopters. A hyphen is shown between the two numbers. Open ended effectivity is indicated by "9999" in the last effectivity, e.g. 0415-9999 indicates helicopter serial number S-415 and subsequent.

An SB effectivity is indicated as either "Before SB....." or "After SB....." meaning respectively before and after incorporation of the specific numbered Service Bulletin on the helicopter.

1.3.2 Method of Indicating Effectivity

The amount of manual coverage required by the differences brought about by model, variants or modification differences (effectivity) varies from small or minor (portions of text) to extensive (entire pages). Therefore, the effectivity statements may apply to portions of a page or an entire page.

Effectivity statements applying to portions of a page immediately precede and are located in the extreme left hand margin directly above the text to which they relate. When the defined applicability ends, an effectivity statement defined as "ALL" is used to mean that the information following applies again to all models, variants, etc. as listed on the FLM title page or, when applicable, as defined by the page effectivity statement.

Effectivity statements applying to the entire page content will be located at the bottom of the page adjacent to the page number.