

3.2 EXTERNAL LOAD JETTISONING

Conditions/Indications

Certain helicopter inflight emergencies (e.g. single-engine failure or loss of power) may dictate manually jettisoning the external load.

Procedure

LOAD HOOK switch – OPEN

or

Mechanical release lever – Kick to OPEN

EFFECTIVITY Up to and including S-100

NOTE Loss of one generator will automatically shut off electrical power to the cargo hook system resulting in loss of the electrical release capability and the **HOOK** caution light.

EFFECTIVITY ALL

3.3 HOOK RETRACTION WINCH FAILURE

If the winch (if installed) fails to retract the cargo hook (EXTD'D advisory light remains on) or if the retraction (or extension) process is interrupted due to an equipment failure (MOVE advisory light remains on) maintain an airspeed below the maximum for flights when trailing an unloaded hook assembly (60 KIAS).

4. NORMAL PROCEDURES

4.1 PREFLIGHT CHECK

- | | |
|--|---|
| Hook assembly, cables and attachments | – Condition, secured |
| Hook assembly electrical and mechanical releases | – Function |
| LOAD HOOK switch | – CLOSED |
| Mechanical release lever | – CLOSED |
| Hook retraction winch (if installed) | – Check |
| Winch | – Condition, security of mounting, function |
| Winch cable | – Condition |
| Load Hook | – Ensure fully retracted |

4.2 EXTERNAL LOAD OPERATIONS

4.2.1 General

External loads may be divided into three basic categories based upon their different characteristics in flight:

- high density load, offers best stability
- low density load, least stable
- aerodynamic load, exhibits both instability and stability (instability inherent until load streamlining occurs)

The category, size and mass of the load must be determined during the preflight phase of the operation.

Refer to the appropriate performance charts (Section 5) for airspeed, altitude, gross mass, HOGE, HIGE, etc in determining the load-carrying capabilities of the helicopter.

Slings and cargo nets to be used must be thoroughly inspected for any evidence of frayed or cut webbing.

The flight and ground crew members must be qualified for and briefed on their duties and the mission to be performed. Included in this briefing are signaling procedures and emergency procedures covering all phases of the operation. Basic signaling may incorporate the use of radios, hand signals, etc.

4.2.2 Load Pickup

Hook assembly	– Release from hook retainer or extend as required
---------------	--

LOAD HOOK switch	– OPEN; HOOK caution light comes on
	– CLOSE; HOOK caution light remains on

If Hook Retraction Winch is installed:

HOOK WINCH switch	– EXTEND; MOVE advisory light comes on for approx 15 seconds and then EXT'D advisory light comes on
-------------------	---

HOOK caution light	– Check on
---------------------------	------------

Hover flight	– Establish at adequate height above load
--------------	---

WARNING DISCHARGE HELICOPTER STATIC ELECTRICITY BEFORE ATTACHING LOAD.

Helicopter static electricity	– Discharge
-------------------------------	-------------