

- | | |
|----------------------------|---|
| Load sling | – Secure to hook |
| Slow vertical climb | – Establish with helicopter centered above load |
| TORQUE and TOT indications | – Check within limits while lifting load |
| HOOK caution light | – Check off |
| Pre-takeoff check | – Complete |

4.2.3 Load Release

- | | |
|-----------------------|---|
| Prelanding check | – Complete |
| Hover flight | – Establish with load well clear of surface |
| Slow vertical descent | – Lower load to surface |

CAUTION BEFORE RELEASING LOAD CHECK TORQUE INDICATIONS TO VERIFY THAT LOAD IS ON THE SURFACE.

- | | |
|---------------------------|------------|
| LOAD HOOK switch | – OPEN |
| HOOK caution light | – Check on |

WARNING **HOOK** CAUTION LIGHT COMING ON DOES NOT GUARANTEE THAT LOAD IS RELEASED.

- | | |
|--|--|
| Load released | – Verify |
| LOAD HOOK switch | – CLOSED |
| Hook assembly | – Secure to hook retainer as required, or |
| If Hook Retraction Winch is installed: | |
| HOOK WINCH switch | – RETRACT; EXTD'D advisory light goes off and MOVE advisory light comes on for approx 15 seconds |
| HOOK caution light | – Check off |

5. PERFORMANCE DATA

NOTE No change when hook assembly is stowed or fully retracted. Climb and hover performance may be reduced dependent upon the amount of additional drag created by the external load.