

8. HANDLING, SERVICING, AND MAINTENANCE

8.1 REVERSING SEAT DIRECTION

8.1.1 For Aft-facing Seat

1. Remove LH cyclic stick and collective lever as required.
2. Remove seat rail pip pins.
3. Slide seat aft until free of rails, reverse seat direction and insert in seat rails.
4. Install seat rail pip pins.
5. Release lap belt sections from rear fittings and install at forward fittings.

8.1.2 For Forward-facing Seat

1. Remove seat rail pip pins.
2. Slide seat aft until free of rails, reverse seat direction and insert in seat rails.
3. Install seat rail pip pins.
4. Release lap belt sections from forward fittings and install at rear fittings.
5. Install LH cyclic stick and collective lever as required.

NOTE Make certain that knurled knob at base of cyclic stick is secured with safety wire.

